

COMPATIBILITE

FR V2

POUR CITROEN

iCarsoft France

Compatibilité Citroën - Batterie

● : Compatible

※ : Peut être compatible en fonction de l'état du véhicule

○ : N'est pas compatible

▲ : Nouvelle compatibilité sur ce modèle

Vehicle	BMS
BERLINGO (B9)	●
C3 (A51)	●
C3 (PICASSO)	●
C3 (XR)	●
C4	●
C4 (CACTUS)	●
C4 (PICASSO)	●
C4 (SEDAN)	●
C4L	●
C5 (X7)	●
C6	●
DS3	●
DS4	●
DS5	●
DS5 (Hybird 4)	●
DS 5LS	●
DS6	●
JUMPY (DISPATCH)	●

Compatibilité Citroën - Système BLD

● : Compatible

※ : Peut être compatible en fonction de l'état du véhicule

○ : N'est pas compatible

▲ : Nouvelle compatibilité sur ce modèle

Vehicle	System Type	BLD
BERLINGO (B9)	ABS81	●
BERLINGO (B9)	ESP8.1	●
BERLINGO 2	ABS81	●
BERLINGO 2	ESP81	●
BERLINGO Electric (B9E)	ABS81	●
BERLINGO Electric (B9E)	ESP8.1	●
C-ELYSEE	ABSMK100	●
C-ELYSEE	ESPMK100	●
C-QUATRE 4	ESP8.1	●
C-QUATRE 5	ESP8.1	●
C-TRIOMPHE	ESP8.1	●
C3 (A51)	ABSMK70_1	●
C3 (A51)	ABSMK100	●
C3 (A51)	ESPMK60_0	●
C3 (A51)	ESPMK100	●
C3 AIRCROSS (Ai58)	ABSMK70_1	●
C3 AIRCROSS (Ai58)	ESPMK60_0	●
C3 (Ai58)	ABSMK70_1	●
C3 (Ai58)	ESPMK60_0	●
C3 (PICASSO) (A58)	ABSMK70_1	●
C3 (PICASSO) (A58)	ABSMK100	●
C3 (PICASSO) (A58)	ESPMK60_0	●
C3 (PICASSO) (A58)	ESPMK100	●
C3 (PICASSO) (Ai58)	ABSMK70_1	●
C3 (PICASSO) (Ai58)	ESPMK60_0	●
C4	ABS8_BOSCH	●
C4	ABS81	●
C4	ESP8BOSCH	●
C4	ESP8.1	●
C4 (PICASSO)	ABS8_BOSCH	●
C4 (PICASSO)	ABS81	●
C4 (PICASSO)	ESP8BOSCH	●
C4 (PICASSO)	ESP8.1	●
C4 (PICASSO) (B78)	ESP90	●
C4 (SEDAN)	ABS8_BOSCH	●
C4 (SEDAN)	ABS81	●
C4 (SEDAN)	ESP8BOSCH	●
C4 (SEDAN)	ESP8.1	●
C4 (B7)	ABS81	●
C4 (B7)	ESP8.1	●
C4L (B7)	ABS81	●
C4L (B7)	ESP8.1	●
C5 (X7)	ESP8.1	●
C6	ESP8.1	●
C6	ESPEBC440	●
C8 (CAN)	ESP8BOSCH	●

C8 (CAN)	ESP8.1	●
DS 5LS	ESP8.1	●
DS 6	ESP8.1	●
DS3	ESPMK60_0	●
DS3	ESPMK100	●
DS4	ABS81	●
DS4	ESP8.1	●
DS5	ESP8.1	●
DS5 (Hybird 4)	ESP8.1	●
JUMPER 3	ABS80	●
JUMPER 3	ASR80	●
JUMPER 3 (MiniBus)	ABS80	●
JUMPER 3 (MiniBus)	ASR80	●
JUMPY 3	ABS8_BOSCH	●
JUMPY 3	ABS81	●
JUMPY 3	ESP8BOSCH	●
JUMPY 3	ESP8.1	●

Compatibilité Citroën - Diagnostic

● : Compatible

※ : Peut être compatible en fonction de l'état du véhicule

○ : N'est pas compatible

▲ : Nouvelle compatibilité sur ce modèle

Vehicle	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData
BERLINGO	Engine Control Moduel	●	●	●	●
BERLINGO	Anti-lock Brake System	●	●	●	●
BERLINGO	Airbag	●	●	●	●
BERLINGO	Control Panel	●	●	●	●
BERLINGO	Built-in System Interface	●	●	●	●
BERLINGO	Parking Assistance Module	●	●	●	●
BERLINGO	Steering Wheel With Fixed Central Control	●	●	●	●
BERLINGO	Rain/Brightness Sensor	●	●	●	●
BERLINGO	Additional Heating	●	●	●	●
BERLINGO	Multifunction Display A	●	●	●	●
BERLINGO	Service Module	●	●	●	●
BERLINGO	CD Player	●	●	●	●
BERLINGO	Radio	●	●	●	●
BERLINGO	Alarm	●	●	●	●
BERLINGO (B9)	Engine Control Moduel	●	●	●	●
BERLINGO (B9)	Auto Gearbox	●	●	●	●
BERLINGO (B9)	Anti-lock Brake System	●	●	●	●
BERLINGO (B9)	Airbag	●	●	●	●
BERLINGO (B9)	Control Panel	●	●	●	●
BERLINGO (B9)	Built-in System Interface (BSI)	●	●	●	●
BERLINGO (B9)	Air Conditioning	●	●	●	●
BERLINGO (B9)	Passenger Compartment Air Heating Resistor	●	●	●	●
BERLINGO (B9)	Engine Relay Unit	●	●	●	●
BERLINGO (B9)	Trailer Relay Unit	●	●	●	●
BERLINGO (B9)	Electric Machine Management	●	●	●	●
BERLINGO (B9)	Electric Power Steering	●	●	●	●
BERLINGO (B9)	Electric Vehicle Management	●	●	●	●
BERLINGO (B9)	Steering Wheel With Fixed Central Control	●	●	●	●
BERLINGO (B9)	Parking Assistance Module	●	●	●	●
BERLINGO (B9)	Rain/Brightness Sensor	●	●	●	●
BERLINGO (B9)	Display/Telematics	●	●	●	●
BERLINGO (B9)	Multifunction Display	●	●	●	●
BERLINGO (B9)	Battery Change Status Unit	●	●	●	●
BERLINGO (B9)	Multiplexed Additive Adding Pump	●	●	●	●
BERLINGO (B9)	Hands-free Control Unit	●	●	●	●
BERLINGO (B9)	High Frequency Receiver	●	●	●	●
BERLINGO (B9)	Deflation Detection	●	●	●	●
BERLINGO (B9)	Bodywork Conversion Unit	●	●	●	●
BERLINGO (B9)	Anti-slip Mode Selector	●	●	●	●
BERLINGO (B9)	Service Module	●	●	●	●
BERLINGO (B9)	Traction Battery	●	●	●	●
BERLINGO (B9)	Onboard Charger Of The Traction Battery	●	●	●	●
BERLINGO (B9)	Traction Battery Cells Management 1	●	●	●	●
BERLINGO (B9)	Traction Battery Cells Management 2	●	●	●	●
BERLINGO (B9)	Traction Battery Cells Management 3	●	●	●	●
BERLINGO (B9)	Traction Battery Cells Management 4	●	●	●	●
BERLINGO (B9)	Traction Battery Cells Management 5	●	●	●	●
BERLINGO (B9)	Traction Battery Cells Management 7	●	●	●	●
BERLINGO (B9)	Traction Battery Cells Management 8	●	●	●	●
BERLINGO (B9)	Traction Battery Cells Management 9	●	●	●	●

BERLINGO (B9)	Traction Battery Cells Management 10	●	●	●	●
BERLINGO (B9)	CD Player	●	●	●	●
BERLINGO (B9)	Radio	●	●	●	●
BERLINGO (B9)	Alarm	●	●	●	●
C-ZERO	Electric Machine Management	●	●	●	●
C-ZERO	Electric Vehicle Management	●	●	●	●
C-ZERO	ASC	●	●	●	●
C-ZERO	ORC	●	●	●	●
C-ZERO	Instrument Cluster	●	●	●	●
C-ZERO	Air Conditioning	●	●	●	●
C-ZERO	Electric Power Steering	●	●	●	●
C-ZERO	Steering Wheel Angle Sensor	●	●	●	●
C-ZERO	Gateway Wiring Housing	●	●	●	●
C-ZERO	Direct Voltage Transformer	●	●	●	●
C-ZERO	Onboard Charger Of The Traction Battery	●	●	●	●
C-ZERO	Traction Battery	●	●	●	●
C-ZERO	Traction Battery Cells Management 1	●	●	●	●
C-ZERO	Traction Battery Cells Management 2	●	●	●	●
C-ZERO	Traction Battery Cells Management 3	●	●	●	●
C-ZERO	Traction Battery Cells Management 4	●	●	●	●
C-ZERO	Traction Battery Cells Management 5	●	●	●	●
C-ZERO	Traction Battery Cells Management 7	●	●	●	●
C-ZERO	Traction Battery Cells Management 8	●	●	●	●
C-ZERO	Traction Battery Cells Management 9	●	●	●	●
C-ZERO	Traction Battery Cells Management 10	●	●	●	●
C-ZERO	Traction Battery Cells Management 11	●	●	●	●
C-ZERO	Service Module	●	●	●	●
C-ZERO	Radio	●	●	●	●
C1	Engine Control Moduel	●	●	●	●
C1	Manual Gearbox	●	●	●	●
C1	ABS/ESP	●	●	●	●
C1	Airbag	●	●	●	●
C1	Electric Power Steering	●	●	●	●
C1	Immobiliser	●	●	●	●
C1 (B4)	Engine Control Moduel	●	●	●	●
C1 (B4)	Auto Gearbox	●	●	●	●
C1 (B4)	Anti-lock Brake System	●	●	●	●
C1 (B4)	Airbag	●	●	●	●
C1 (B4)	Instrument Cluster	●	●	●	●
C1 (B4)	Air Conditioning	●	●	●	●
C1 (B4)	Electric Power Steering	●	●	●	●
C1 (B4)	Engine immobiliser/hands free starting access electric module	●	●	●	●
C1 (B4)	Start/Stop Control	●	●	●	●
C1 (B4)	Multifunction Display	●	●	●	●
C2	Engine Control Moduel	●	●	●	●
C2	Manual Gearbox	●	●	●	●
C2	Anti-lock Brake System	●	●	●	●
C2	Airbag	●	●	●	●
C2	Control Panel	●	●	●	●
C2	Built-in System Interface (BSI)	●	●	●	●
C2	Air Conditioning	●	●	●	●
C2	Electric Power Steering	●	●	●	●
C2	Steering Wheel With Fixed Central Control	●	●	●	●
C2	Engine Relay Unit	●	●	●	●
C2	Trailer Relay Unit	●	●	●	●
C2	Parking Assistance Module	●	●	●	●
C2	Hands-free Control Unit	●	●	●	●
C2	Start/Stop Control	●	●	●	●

C2	Rain/Brightness Sensor	●	●	●	●
C2	High Frequency Receiver	●	●	●	●
C2	Multifunction Display C	●	●	●	●
C2	Telematic Unit	●	●	●	●
C2	CD Player	●	●	●	●
C2	Radio	●	●	●	●
C2	Alarm	●	●	●	●
C2 (CHINA)	Engine Control Moduel	●	●	●	●
C2 (CHINA)	Auto Gearbox	●	●	●	●
C2 (CHINA)	Anti-lock Brake System	●	●	●	●
C2 (CHINA)	Airbag	●	●	●	●
C2 (CHINA)	Instrument Cluster	●	●	●	●
C2 (CHINA)	Built-in System Interface	●	●	●	●
C2 (CHINA)	Air Conditioning	●	●	●	●
C2 (CHINA)	Steering Wheel With Fixed Central Control	●	●	●	●
C3	Engine Control Moduel	●	●	●	●
C3	Auto Gearbox	●	●	●	●
C3	Anti-lock Brake System	●	●	●	●
C3	Airbag	●	●	●	●
C3	Control Panel	●	●	●	●
C3	Built-in System Interface	●	●	●	●
C3	Air Conditioning	●	●	●	●
C3	Electric Power Steering	●	●	●	●
C3	Steering Wheel With Fixed Central Control	●	●	●	●
C3	Parking Assistance Module	●	●	●	●
C3	Diesel Additive Function	●	●	●	●
C3	Rain/Brightness Sensor	●	●	●	●
C3	Multifunction Display A	●	●	●	●
C3	CD Player	●	●	●	●
C3	Radio	●	●	●	●
C3	Alarm	●	●	●	●
C3 (A51)	Engine Control Moduel	●	●	●	●
C3 (A51)	Auto Gearbox	●	●	●	●
C3 (A51)	Anti-lock Brake System	●	●	●	●
C3 (A51)	Airbag	●	●	●	●
C3 (A51)	Control Panel	●	●	●	●
C3 (A51)	Built-in System Interface	●	●	●	●
C3 (A51)	Air Conditioning	●	●	●	●
C3 (A51)	Engine Relay Unit	●	●	●	●
C3 (A51)	Trailer Relay Unit	●	●	●	●
C3 (A51)	Electric Power Steering	●	●	●	●
C3 (A51)	Steering Wheel With Fixed Central Control	●	●	●	●
C3 (A51)	Multiplexed Diesel Additive Pump	●	●	●	●
C3 (A51)	Driver Door Control Panel	●	●	●	●
C3 (A51)	Seat Belt Reminder LED	●	●	●	●
C3 (A51)	Battery Change Status Unit	●	●	●	●
C3 (A51)	Hands-free Control Unit	●	●	●	●
C3 (A51)	High Frequency Receiver	●	●	●	●
C3 (A51)	Driver School Module	●	●	●	●
C3 (A51)	Rain/Brightness Sensor	●	●	●	●
C3 (A51)	Parking Assistance Module	●	●	●	●
C3 (A51)	Display/Telematics	●	●	●	●
C3 (A51)	Multifunction Display	●	●	●	●
C3 (A51)	Service Module	●	●	●	●
C3 (A51)	Radio	●	●	●	●
C3 (A51)	Alarm	●	●	●	●
C3 (AIRCROSS)	Engine Control Moduel	●	●	●	●
C3 (AIRCROSS)	Auto Gearbox	●	●	●	●

C3 (AIRCROSS)	Anti-lock Brake System	●	●	●	●
C3 (AIRCROSS)	Airbag	●	●	●	●
C3 (AIRCROSS)	Control Panel	●	●	●	●
C3 (AIRCROSS)	Built-in System Interface	●	●	●	●
C3 (AIRCROSS)	Air Conditioning	●	●	●	●
C3 (AIRCROSS)	Electric Power Steering	●	●	●	●
C3 (AIRCROSS)	Steering Wheel With Fixed Central Control	●	●	●	●
C3 (AIRCROSS)	Parking Assistance Module	●	●	●	●
C3 (AIRCROSS)	Rain/Brightness Sensor	●	●	●	●
C3 (AIRCROSS)	Trailer Relay Unit	●	●	●	●
C3 (AIRCROSS)	Stolen Vehicle Location Control Unit	●	●	●	●
C3 (AIRCROSS)	Telematic Unit	●	●	●	●
C3 (AIRCROSS)	Service Module	●	●	●	●
C3 (AIRCROSS)	Radio	●	●	●	●
C3 (AIRCROSS)	Alarm	●	●	●	●
C3 (NEW LOOK)	Engine Control Moduel	●	●	●	●
C3 (NEW LOOK)	Auto Gearbox	●	●	●	●
C3 (NEW LOOK)	Anti-lock Brake System	●	●	●	●
C3 (NEW LOOK)	Airbag	●	●	●	●
C3 (NEW LOOK)	Control Panel	●	●	●	●
C3 (NEW LOOK)	Built-in System Interface	●	●	●	●
C3 (NEW LOOK)	Air Conditioning	●	●	●	●
C3 (NEW LOOK)	Electric Power Steering	●	●	●	●
C3 (NEW LOOK)	Steering Wheel With Fixed Central Control	●	●	●	●
C3 (NEW LOOK)	Parking Assistance Module	●	●	●	●
C3 (NEW LOOK)	Engine Relay Unit	●	●	●	●
C3 (NEW LOOK)	Hands-free Control Unit	●	●	●	●
C3 (NEW LOOK)	Rain/Brightness Sensor	●	●	●	●
C3 (NEW LOOK)	Multifunction Display C	●	●	●	●
C3 (NEW LOOK)	Telematic RT3	●	●	●	●
C3 (NEW LOOK)	CD Player	●	●	●	●
C3 (NEW LOOK)	Radio	●	●	●	●
C3 (NEW LOOK)	Alarm	●	●	●	●
C3 (PLURIEL)	Engine Control Moduel	●	●	●	●
C3 (PLURIEL)	Manual Gearbox	●	●	●	●
C3 (PLURIEL)	Anti-lock Brake System	●	●	●	●
C3 (PLURIEL)	Airbag	●	●	●	●
C3 (PLURIEL)	Control Panel	●	●	●	●
C3 (PLURIEL)	Built-in System Interface	●	●	●	●
C3 (PLURIEL)	Air Conditioning	●	●	●	●
C3 (PLURIEL)	Electric Power Steering	●	●	●	●
C3 (PLURIEL)	Steering Wheel With Fixed Central Control	●	●	●	●
C3 (PLURIEL)	Parking Assistance Module	●	●	●	●
C3 (PLURIEL)	Engine Relay Unit	●	●	●	●
C3 (PLURIEL)	Hands-free Control Unit	●	●	●	●
C3 (PLURIEL)	Rain/Brightness Sensor	●	●	●	●
C3 (PLURIEL)	Multifunction Display C	●	●	●	●
C3 (PLURIEL)	Telematic RT3	●	●	●	●
C3 (PLURIEL)	CD Player	●	●	●	●
C3 (PLURIEL)	Radio	●	●	●	●
C3 (PICASSO)	Engine Control Moduel	●	●	●	●
C3 (PICASSO)	Auto Gearbox	●	●	●	●
C3 (PICASSO)	Anti-lock Brake System	●	●	●	●
C3 (PICASSO)	Airbag	●	●	●	●
C3 (PICASSO)	Control Panel	●	●	●	●
C3 (PICASSO)	Built-in System Interface (BSI)	●	●	●	●
C3 (PICASSO)	Air Conditioning	●	●	●	●
C3 (PICASSO)	Electric Power Steering	●	●	●	●

C3 (PICASSO)	Steering Wheel With Fixed Central Control	●	●	●	●
C3 (PICASSO)	Parking Assistance Module	●	●	●	●
C3 (PICASSO)	Engine Relay Unit	●	●	●	●
C3 (PICASSO)	Trailer Relay Unit	●	●	●	●
C3 (PICASSO)	Driver Door Control Panel	●	●	●	●
C3 (PICASSO)	Multiplexed Diesel Additive Pump	●	●	●	●
C3 (PICASSO)	High Frequency Receiver	●	●	●	●
C3 (PICASSO)	Rain/Brightness Sensor	●	●	●	●
C3 (PICASSO)	Hands-free Control Unit	●	●	●	●
C3 (PICASSO)	Battery Charge Status Unit	●	●	●	●
C3 (PICASSO)	Seat Belt Reminder LED	●	●	●	●
C3 (PICASSO)	Service Module	●	●	●	●
C3 (PICASSO)	Multifunction Display	●	●	●	●
C3 (PICASSO)	Display/Telematics	●	●	●	●
C3 (PICASSO)	Alarm	●	●	●	●
C3 (PICASSO)	Radio	●	●	●	●
C3 (XR)	Engine Control Moduel	●	●	●	●
C3 (XR)	Auto Gearbox	●	●	●	●
C3 (XR)	Anti-lock Brake System	●	●	●	●
C3 (XR)	Airbag	●	●	●	●
C3 (XR)	Control Panel	●	●	●	●
C3 (XR)	Built-in System Interface (BSI)	●	●	●	●
C3 (XR)	Electric Steering Lock	●	●	●	●
C3 (XR)	Electric Power Steering	●	●	●	●
C3 (XR)	Steering Wheel With Fixed Central Control	●	●	●	●
C3 (XR)	Parking Assistance Module	●	●	●	●
C3 (XR)	Hands-free Control Unit	●	●	●	●
C3 (XR)	Electric Key Reader	●	●	●	●
C3 (XR)	Battery Charge Status Unit	●	●	●	●
C3 (XR)	Anti-slip Mode Selector	●	●	●	●
C3 (XR)	Multiplexed Control Panel	●	●	●	●
C3 (XR)	Voltage Retaining Device	●	●	●	●
C3 (XR)	Multifunction Display	●	●	●	●
C3 (XR)	Telematic Unit	●	●	●	●
C3 (XR)	Service Module	●	●	●	●
C3 (XR)	Radio	●	●	●	●
C4	Engine Control Moduel	●	●	●	●
C4	Auto Gearbox	●	●	●	●
C4	Anti-lock Brake System	●	●	●	●
C4	Electric Secondary Brake	●	●	●	●
C4	Airbag	●	●	●	●
C4	Control Panel	●	●	●	●
C4	Built-in System Interface	●	●	●	●
C4	Air Conditioning	●	●	●	●
C4	Electric Power Steering	●	●	●	●
C4	Steering Wheel With Fixed Central Control	●	●	●	●
C4	Engine Relay Unit	●	●	●	●
C4	Diesel Additive Function	●	●	●	●
C4	Unit Rev Counter	●	●	●	●
C4	Driver Door Control Panel	●	●	●	●
C4	Passenger Door Module	●	●	●	●
C4	Driver Seat Memorizing Unit	●	●	●	●
C4	Parking Assistance Module	●	●	●	●
C4	Hands-free Control Unit	●	●	●	●
C4	Rain/Brightness Sensor	●	●	●	●
C4	Directional Headlamps	●	●	●	●
C4	High Frequency Receiver	●	●	●	●
C4	Lane Departure Warning System	●	●	●	●

C4	Light Pack Unit	●	●	●	●
C4	Pneumatic Suspension	●	●	●	●
C4	Trailer Relay Unit	●	●	●	●
C4	Windscreen Wiper	●	●	●	●
C4	Multifunction Display	●	●	●	●
C4	Display/Telematics	●	●	●	●
C4	Battery Charge Status Unit	●	●	●	●
C4	Multiplexed Additive Adding Pump	●	●	●	●
C4	Service Module	●	●	●	●
C4	Deflation Detection	●	●	●	●
C4	Audio Amplifier	●	●	●	●
C4	Driver School Module	●	●	●	●
C4	CD Player	●	●	●	●
C4	Radio	●	●	●	●
C4	Alarm	●	●	●	●
C4 (AIRCROSS)	Engine Control Moduel	●	●	●	●
C4 (AIRCROSS)	Auto Gearbox	●	●	●	●
C4 (AIRCROSS)	Anti-lock Brake System	●	●	●	●
C4 (AIRCROSS)	Airbag	●	●	●	●
C4 (AIRCROSS)	Control Panel	●	●	●	●
C4 (AIRCROSS)	Air Conditioning	●	●	●	●
C4 (AIRCROSS)	Electric Power Steering	●	●	●	●
C4 (AIRCROSS)	Steering Wheel Angle Sensor	●	●	●	●
C4 (AIRCROSS)	Parking Assistance Module	●	●	●	●
C4 (AIRCROSS)	Start/Stop Control	●	●	●	●
C4 (AIRCROSS)	Starting Authorisation	●	●	●	●
C4 (AIRCROSS)	Locking And Immobiliser Control Module	●	●	●	●
C4 (AIRCROSS)	Rear Final Drive Piloted Clutch	●	●	●	●
C4 (AIRCROSS)	Navigation	●	●	●	●
C4 (AIRCROSS)	Radio	●	●	●	●
C4 (CACTUS)	Engine Control Moduel	●	●	●	●
C4 (CACTUS)	Auto Gearbox	●	●	●	●
C4 (CACTUS)	Anti-lock Brake System	●	●	●	●
C4 (CACTUS)	Airbag	●	●	●	●
C4 (CACTUS)	Control Panel	●	●	●	●
C4 (CACTUS)	Built-in System Interface (BSI)	●	●	●	●
C4 (CACTUS)	Air Conditioning	●	●	●	●
C4 (CACTUS)	Diesel Additive Function	●	●	●	●
C4 (CACTUS)	Electric Power Steering	●	●	●	●
C4 (CACTUS)	Steering Wheel With Fixed Central Control	●	●	●	●
C4 (CACTUS)	Parking Assistance Module	●	●	●	●
C4 (CACTUS)	Seat Belts Not Fastened LED Unit	●	●	●	●
C4 (CACTUS)	Trailer Relay Unit	●	●	●	●
C4 (CACTUS)	Rain/Brightness Sensor	●	●	●	●
C4 (CACTUS)	Battery Charge Status Unit	●	●	●	●
C4 (CACTUS)	Voltage Retaining Device	●	●	●	●
C4 (CACTUS)	Multiplexed Control Panel	●	●	●	●
C4 (CACTUS)	Service Module	●	●	●	●
C4 (CACTUS)	External CD Player	●	●	●	●
C4 (CACTUS)	Telematic Unit	●	●	●	●
C4 (CACTUS)	Touch Screen	●	●	●	●
C4 (PICASSO)	Engine Control Moduel	●	●	●	●
C4 (PICASSO)	Auto Gearbox	●	●	●	●
C4 (PICASSO)	Anti-lock Brake System	●	●	●	●
C4 (PICASSO)	Electric Secondary Brake	●	●	●	●
C4 (PICASSO)	Airbag	●	●	●	●
C4 (PICASSO)	Control Panel	●	●	●	●
C4 (PICASSO)	Built-in System Interface	●	●	●	●

C4 (PICASSO)	Air Conditioning	●	●	●	●
C4 (PICASSO)	Engine Relay Unit	●	●	●	●
C4 (PICASSO)	Trailer Relay Unit	●	●	●	●
C4 (PICASSO)	Diesel Additive Function	●	●	●	●
C4 (PICASSO)	Electric Power Steering	●	●	●	●
C4 (PICASSO)	Electric Steering Lock	●	●	●	●
C4 (PICASSO)	Steering Wheel With Fixed Central Control	●	●	●	●
C4 (PICASSO)	Parking Assistance Module	●	●	●	●
C4 (PICASSO)	Driver Door Control Panel	●	●	●	●
C4 (PICASSO)	Passenger Door Module	●	●	●	●
C4 (PICASSO)	Driver Seat Memorizing Unit	●	●	●	●
C4 (PICASSO)	Right Reversible Seat Belt Reel	●	●	●	●
C4 (PICASSO)	Left Reversible Seat Belt Reel	●	●	●	●
C4 (PICASSO)	Body Control Module	●	●	●	●
C4 (PICASSO)	Hands-free Control Unit	●	●	●	●
C4 (PICASSO)	Multiplexed Additive Adding Pump	●	●	●	●
C4 (PICASSO)	Electric Key Reader	●	●	●	●
C4 (PICASSO)	Battery Charge Status Unit	●	●	●	●
C4 (PICASSO)	Rain/Brightness Sensor	●	●	●	●
C4 (PICASSO)	Directional Headlamps	●	●	●	●
C4 (PICASSO)	Unit Rev Counter	●	●	●	●
C4 (PICASSO)	Deflation Detection	●	●	●	●
C4 (PICASSO)	Pneumatic Suspension	●	●	●	●
C4 (PICASSO)	Driver School Module	●	●	●	●
C4 (PICASSO)	High Frequency Receiver	●	●	●	●
C4 (PICASSO)	Lane Departure Warning System	●	●	●	●
C4 (PICASSO)	Light Pack Unit	●	●	●	●
C4 (PICASSO)	Multifunction Camera	●	●	●	●
C4 (PICASSO)	Vehicle Distance Assistance	●	●	●	●
C4 (PICASSO)	Multiplexed Control Panel	●	●	●	●
C4 (PICASSO)	Signalling Fuse Box	●	●	●	●
C4 (PICASSO)	Supply Protection And Management Unit	●	●	●	●
C4 (PICASSO)	Windscreen Wiper	●	●	●	●
C4 (PICASSO)	Display/Telematics	●	●	●	●
C4 (PICASSO)	Multifunction Display	●	●	●	●
C4 (PICASSO)	Service Module	●	●	●	●
C4 (PICASSO)	Audio Amplifier	●	●	●	●
C4 (PICASSO)	CD Player	●	●	●	●
C4 (PICASSO)	Radio	●	●	●	●
C4 (PICASSO)	Alarm	●	●	●	●
C4 (PICASSO)	Siren	●	●	●	●
C4 (SEDAN)	Engine Control Moduel	●	●	●	●
C4 (SEDAN)	Auto Gearbox	●	●	●	●
C4 (SEDAN)	Anti-lock Brake System	●	●	●	●
C4 (SEDAN)	Electric Secondary Brake	●	●	●	●
C4 (SEDAN)	Airbag	●	●	●	●
C4 (SEDAN)	Control Panel	●	●	●	●
C4 (SEDAN)	Built-in System Interface	●	●	●	●
C4 (SEDAN)	Air Conditioning	●	●	●	●
C4 (SEDAN)	Engine Relay Unit	●	●	●	●
C4 (SEDAN)	Trailer Relay Unit	●	●	●	●
C4 (SEDAN)	Diesel Additive Function	●	●	●	●
C4 (SEDAN)	Electric Power Steering	●	●	●	●
C4 (SEDAN)	Steering Wheel With Fixed Central Control	●	●	●	●
C4 (SEDAN)	Parking Assistance Module	●	●	●	●
C4 (SEDAN)	Driver Door Control Panel	●	●	●	●
C4 (SEDAN)	Passenger Door Module	●	●	●	●
C4 (SEDAN)	Driver Seat Memorizing Unit	●	●	●	●

C4 (SEDAN)	Hands-free Control Unit	●	●	●	●
C4 (SEDAN)	Rain/Brightness Sensor	●	●	●	●
C4 (SEDAN)	Multiplexed Additive Adding Pump	●	●	●	●
C4 (SEDAN)	Directional Headlamps	●	●	●	●
C4 (SEDAN)	Driver School Module	●	●	●	●
C4 (SEDAN)	High Frequency Receiver	●	●	●	●
C4 (SEDAN)	Lane Departure Warning System	●	●	●	●
C4 (SEDAN)	Light Pack Unit	●	●	●	●
C4 (SEDAN)	Pneumatic Suspension	●	●	●	●
C4 (SEDAN)	Deflation Detection	●	●	●	●
C4 (SEDAN)	Unit Rev Counter	●	●	●	●
C4 (SEDAN)	Display/Telematics	●	●	●	●
C4 (SEDAN)	Multifunction Display	●	●	●	●
C4 (SEDAN)	Service Module	●	●	●	●
C4 (SEDAN)	Battery Change Status Unit	●	●	●	●
C4 (SEDAN)	Audio Amplifier	●	●	●	●
C4 (SEDAN)	Windscreen Wiper	●	●	●	●
C4 (SEDAN)	CD Player	●	●	●	●
C4 (SEDAN)	Radio	●	●	●	●
C4 (SEDAN)	Alarm	●	●	●	●
C4L	Engine Control Moduel	●	●	●	●
C4L	Auto Gearbox	●	●	●	●
C4L	Anti-lock Brake System	●	●	●	●
C4L	Electric Secondary Brake	●	●	●	●
C4L	Airbag	●	●	●	●
C4L	Control Panel	●	●	●	●
C4L	Air Conditioning	●	●	●	●
C4L	Engine Relay Unit	●	●	●	●
C4L	Trailer Relay Unit	●	●	●	●
C4L	Electric Power Steering	●	●	●	●
C4L	Electric Steering Lock	●	●	●	●
C4L	Steering Wheel With Fixed Central Control	●	●	●	●
C4L	Driver Door Control Panel	●	●	●	●
C4L	Driver Seat Memorizing Unit	●	●	●	●
C4L	Seat Belts Not Fastened LED Unit	●	●	●	●
C4L	Parking Assistance Module	●	●	●	●
C4L	Directional Headlamps	●	●	●	●
C4L	Matrix Screen Integral To The Instrument Panel	●	●	●	●
C4L	Multiplexed Control Panel	●	●	●	●
C4L	Battery Change Status Unit	●	●	●	●
C4L	Electric Key Reader	●	●	●	●
C4L	Service Module	●	●	●	●
C4L	Supply Protection And Management Unit	●	●	●	●
C4L	Monitoring Of The Blind Spot	●	●	●	●
C4L	Driver School Module	●	●	●	●
C4L	Rain/Brightness Sensor	●	●	●	●
C4L	Lane Departure Warning System	●	●	●	●
C4L	Deflation Detection	●	●	●	●
C4L	Multiplexed Additive Adding Pump	●	●	●	●
C4L	Display/Telematics	●	●	●	●
C4L	Multifunction Display	●	●	●	●
C4L	Audio Amplifier	●	●	●	●
C4L	Radio	●	●	●	●
C4L	Alarm	●	●	●	●
C5	Engine Control Moduel	●	●	●	●
C5	Auto Gearbox	●	●	●	●
C5	Airbag	●	●	●	●
C5	Control Panel	●	●	●	●

C5	Built-in System Interface	●	●	●	●
C5	Air Conditioning	●	●	●	●
C5	Steering Wheel With Fixed Central Control	●	●	●	●
C5	Parking Assistance Module	●	●	●	●
C5	Rain/Brightness Sensor	●	●	●	●
C5	Multifunction Display A	●	●	●	●
C5	ADDGO 2	●	●	●	●
C5	ADDITIF FAP	●	●	●	●
C5	MDP PASSAG	●	●	●	●
C5	MDP CONDUCT	●	●	●	●
C5	CD Player	●	●	●	●
C5	Radio	●	●	●	●
C5	Alarm	●	●	●	●
C5 (NEW)	Engine Control Moduel	●	●	●	●
C5 (NEW)	Auto Gearbox	●	●	●	●
C5 (NEW)	Anti-lock Brake System	●	●	●	●
C5 (NEW)	Airbag	●	●	●	●
C5 (NEW)	Built-in System Interface	●	●	●	●
C5 (NEW)	Air Conditioning	●	●	●	●
C5 (NEW)	Engine Relay Unit	●	●	●	●
C5 (NEW)	Electric Power Steering	●	●	●	●
C5 (NEW)	Steering Wheel With Fixed Central Control	●	●	●	●
C5 (NEW)	Parking Assistance Module	●	●	●	●
C5 (NEW)	Hands-free Control Unit	●	●	●	●
C5 (NEW)	Rain/Brightness Sensor	●	●	●	●
C5 (NEW)	Directional Headlamps	●	●	●	●
C5 (NEW)	Deflation Detection	●	●	●	●
C5 (NEW)	Ecotech Suspension	●	●	●	●
C5 (NEW)	Multifunction Display C	●	●	●	●
C5 (NEW)	Telematic RT3	●	●	●	●
C5 (NEW)	ADDGO 3	●	●	●	●
C5 (NEW)	MDP CONDUCT	●	●	●	●
C5 (NEW)	MDP PASSAG	●	●	●	●
C5 (NEW)	CD Player	●	●	●	●
C5 (NEW)	Radio	●	●	●	●
C5 (NEW)	Alarm	●	●	●	●
C5 (X7)	Engine Control Moduel	●	●	●	●
C5 (X7)	Auto Gearbox	●	●	●	●
C5 (X7)	Anti-lock Brake System	●	●	●	●
C5 (X7)	Electric Secondary Brake	●	●	●	●
C5 (X7)	Airbag	●	●	●	●
C5 (X7)	Control Panel	●	●	●	●
C5 (X7)	Built-in System Interface	●	●	●	●
C5 (X7)	Air Conditioning	●	●	●	●
C5 (X7)	Electric Power Steering	●	●	●	●
C5 (X7)	Steering Wheel With Fixed Central Control	●	●	●	●
C5 (X7)	Engine Relay Unit	●	●	●	●
C5 (X7)	Trailer Relay Unit	●	●	●	●
C5 (X7)	Body Control Module	●	●	●	●
C5 (X7)	Driver Door Control Panel	●	●	●	●
C5 (X7)	Driver Seat Memorizing Unit	●	●	●	●
C5 (X7)	Seat Belt Reminder LED	●	●	●	●
C5 (X7)	Battery Change Status Unit	●	●	●	●
C5 (X7)	Hands-free Control Unit	●	●	●	●
C5 (X7)	Rain/Brightness Sensor	●	●	●	●
C5 (X7)	Parking Assistance Module	●	●	●	●
C5 (X7)	Suspension System Control	●	●	●	●
C5 (X7)	Active Damper Electronic Unit	●	●	●	●

C5 (X7)	High Frequency Receiver	●	●	●	●
C5 (X7)	Lane Departure Warning System	●	●	●	●
C5 (X7)	Display/Telematics	●	●	●	●
C5 (X7)	Service Module	●	●	●	●
C5 (X7)	Multifunction Display	●	●	●	●
C5 (X7)	Directional Headlamps	●	●	●	●
C5 (X7)	Deflation Detection	●	●	●	●
C5 (X7)	Additional Heating	●	●	●	●
C5 (X7)	Audio Amplifier	●	●	●	●
C5 (X7)	BASHE5	●	●	●	●
C5 (X7)	Windscreen Wiper	●	●	●	●
C5 (X7)	CD Player	●	●	●	●
C5 (X7)	Radio	●	●	●	●
C5 (X7)	Alarm	●	●	●	●
C6	Engine Control Moduel	●	●	●	●
C6	Auto Gearbox	●	●	●	●
C6	Anti-lock Brake System	●	●	●	●
C6	Electric Secondary Brake	●	●	●	●
C6	Airbag	●	●	●	●
C6	Control Panel	●	●	●	●
C6	Built-in System Interface (BSI)	●	●	●	●
C6	Engine Relay Unit	●	●	●	●
C6	Trailer Relay Unit	●	●	●	●
C6	Boot Relay Unit	●	●	●	●
C6	Suspension	●	●	●	●
C6	Air Conditioning	●	●	●	●
C6	Rear Air Conditioning Panel	●	●	●	●
C6	Parking Assistance Module	●	●	●	●
C6	Steering Wheel With Fixed Central Control	●	●	●	●
C6	Driver Door Control Panel	●	●	●	●
C6	Passenger Door Module	●	●	●	●
C6	Driver Seat Memorizing Unit	●	●	●	●
C6	Passenger Seat Memorisation Unit	●	●	●	●
C6	Left Seat Switch Panel	●	●	●	●
C6	Right Seat Switch Panel	●	●	●	●
C6	Rear Seat Memorising Unit	●	●	●	●
C6	Battery Change Status Unit	●	●	●	●
C6	Rain/Brightness Sensor	●	●	●	●
C6	Directional Headlamps	●	●	●	●
C6	Deflation Detection	●	●	●	●
C6	Additional Heating	●	●	●	●
C6	Hands-free Control Unit	●	●	●	●
C6	High Frequency Receiver	●	●	●	●
C6	High Head Vision	●	●	●	●
C6	Lane Departure Warning System	●	●	●	●
C6	Headlamp (Left)	●	●	●	●
C6	Headlamp (Right)	●	●	●	●
C6	Moving Panel Deflector	●	●	●	●
C6	Pedestrian Impact Detection	●	●	●	●
C6	Windscreen Wiper	●	●	●	●
C6	Boitier Telematique	●	●	●	●
C6	Multifunction Display	●	●	●	●
C6	CD Player	●	●	●	●
C6	Radio	●	●	●	●
C6	Alarm	●	●	●	●
C8	Engine Control Moduel	●	●	●	●
C8	Auto Gearbox	●	●	●	●
C8	Anti-lock Brake System	●	●	●	●

C8	Airbag	●	●	●	●
C8	Control Panel	●	●	●	●
C8	Built-in System Interface (BSI)	●	●	●	●
C8	Air Conditioning	●	●	●	●
C8	Engine Relay Unit	●	●	●	●
C8	Trailer Relay Unit	●	●	●	●
C8	Diesel Additive Function	●	●	●	●
C8	Electric Power Steering	●	●	●	●
C8	Steering Wheel With Fixed Central Control	●	●	●	●
C8	Parking Assistance Module	●	●	●	●
C8	Driver Door Control Panel	●	●	●	●
C8	Passenger Door Module	●	●	●	●
C8	Sliding Side Door Module	●	●	●	●
C8	Driver Seat Memorizing Unit	●	●	●	●
C8	Hands-free Control Unit	●	●	●	●
C8	Additional Heating	●	●	●	●
C8	Rain/Brightness Sensor	●	●	●	●
C8	Multifunction Display	●	●	●	●
C8	Headlamp (Left)	●	●	●	●
C8	Headlamp (Right)	●	●	●	●
C8	Display/Telematics	●	●	●	●
C8	Telematic Unit	●	●	●	●
C8	LEDs And Odometer	●	●	●	●
C8	Deflation Detection	●	●	●	●
C8	Front Sunroof	●	●	●	●
C8	Middle Sunroof	●	●	●	●
C8	Rear Sunroof	●	●	●	●
C8	CD Player	●	●	●	●
C8	Radio	●	●	●	●
C8	Alarm	●	●	●	●
C-CROSSER	Engine Control Moduel	●	●	●	●
C-CROSSER	Auto Gearbox	●	●	●	●
C-CROSSER	Anti-lock Brake System	●	●	●	●
C-CROSSER	Electronic Stability Program	●	●	●	●
C-CROSSER	Airbag	●	●	●	●
C-CROSSER	Control Panel	●	●	●	●
C-CROSSER	Air Conditioning	●	●	●	●
C-CROSSER	Steering Wheel Angle Sensor	●	●	●	●
C-CROSSER	Parking Assistance Module	●	●	●	●
C-CROSSER	Driver Door Control Panel	●	●	●	●
C-CROSSER	Passenger Door Switch Panel	●	●	●	●
C-CROSSER	Rear Left Door Switch Panel	●	●	●	●
C-CROSSER	Rear Right Door Switch Panel	●	●	●	●
C-CROSSER	Rear Final Drive Piloted Clutch	●	●	●	●
C-CROSSER	Locking And Immobiliser Control Module	●	●	●	●
C-CROSSER	Headlamp Beam Corrector	●	●	●	●
C-CROSSER	Rain/Brightness Sensor	●	●	●	●
C-CROSSER	Hands-free Control Unit	●	●	●	●
C-CROSSER	Gear Lever (DCT)	●	●	●	●
C-CROSSER	Sunroof	●	●	●	●
C-CROSSER	Navigation	●	●	●	●
C-CROSSER	Radio	●	●	●	●
C-ELYSEE	Engine Control Moduel	●	●	●	●
C-ELYSEE	Auto Gearbox	●	●	●	●
C-ELYSEE	Anti-lock Brake System	●	●	●	●
C-ELYSEE	SAC (SIEMENS)	●	●	●	●
C-ELYSEE (M3/M4)	Engine Control Moduel	●	●	●	●
C-ELYSEE (M3/M4)	Auto Gearbox	●	●	●	●

C-ELYSEE (M3/M4)	Anti-lock Brake System	●	●	●	●
C-ELYSEE (M3/M4)	Airbag	●	●	●	●
C-ELYSEE (M3/M4)	Control Panel	●	●	●	●
C-ELYSEE (M3/M4)	Built-in System Interface (BSI)	●	●	●	●
C-ELYSEE (M3/M4)	Electric Power Steering	●	●	●	●
C-ELYSEE (M3/M4)	Steering Wheel With Fixed Central Control	●	●	●	●
C-ELYSEE (M3/M4)	Parking Assistance Module	●	●	●	●
C-ELYSEE (M3/M4)	Trailer Relay Unit	●	●	●	●
C-ELYSEE (M3/M4)	Multiplexed Addition Pump	●	●	●	●
C-ELYSEE (M3/M4)	Multifunction Display	●	●	●	●
C-ELYSEE (M3/M4)	Radio	●	●	●	●
C-ELYSEE (M3/M4)	Siren	●	●	●	●
C-QUATRE	Engine Control Moduel	●	●	●	●
C-QUATRE	Auto Gearbox	●	●	●	●
C-QUATRE	Anti-lock Brake System	●	●	●	●
C-QUATRE	Airbag (AUTOLIV)	●	●	●	●
C-QUATRE	Control Panel	●	●	●	●
C-QUATRE	Built-in System Interface (BSI)	●	●	●	●
C-QUATRE	Air Conditioning	●	●	●	●
C-QUATRE	Engine Relay Unit	●	●	●	●
C-QUATRE	Electric Power Steering	●	●	●	●
C-QUATRE	Steering Wheel With Fixed Central Control	●	●	●	●
C-QUATRE	Parking Assistance Module	●	●	●	●
C-QUATRE	Rain/Brightness Sensor	●	●	●	●
C-QUATRE	Hands-free Control Unit	●	●	●	●
C-QUATRE	Multifunction Display	●	●	●	●
C-QUATRE	MDP CONDUCT	●	●	●	●
C-QUATRE	MDP PASSAG	●	●	●	●
C-QUATRE	Telematic RT3	●	●	●	●
C-QUATRE	CD Player	●	●	●	●
C-QUATRE	Radio	●	●	●	●
C-TRIOMPHE	Engine Control Moduel	●	●	●	●
C-TRIOMPHE	Auto Gearbox	●	●	●	●
C-TRIOMPHE	Anti-lock Brake System	●	●	●	●
C-TRIOMPHE	Airbag	●	●	●	●
C-TRIOMPHE	Built-in System Interface	●	●	●	●
C-TRIOMPHE	Air Conditioning	●	●	●	●
C-TRIOMPHE	Engine Relay Unit	●	●	●	●
C-TRIOMPHE	Engine Service Box	●	●	●	●
C-TRIOMPHE	Tachometer Control Box	●	●	●	●
C-TRIOMPHE	Electric Power Steering	●	●	●	●
C-TRIOMPHE	Steering Wheel With Fixed Central Control	●	●	●	●
C-TRIOMPHE	Passenger Door Module	●	●	●	●
C-TRIOMPHE	Adjustable Headlight	●	●	●	●
C-TRIOMPHE	Parking Assistance Module	●	●	●	●
C-TRIOMPHE	Hands-free Control Unit	●	●	●	●
C-TRIOMPHE	Rain/Brightness Sensor	●	●	●	●
C-TRIOMPHE	Multifunction Display C	●	●	●	●
C-TRIOMPHE	MDP CONDUCT	●	●	●	●
C-TRIOMPHE	Telematic RT3	●	●	●	●
C-TRIOMPHE	CD Player	●	●	●	●
C-TRIOMPHE	Radio	●	●	●	●
C-TRIOMPHE	Alarm	●	●	●	●
DS3	Engine Control Moduel	●	●	●	●
DS3	Auto Gearbox	●	●	●	●
DS3	Anti-lock Brake System	●	●	●	●
DS3	Airbag	●	●	●	●
DS3	Control Panel	●	●	●	●

DS3	Built-in System Interface	●	●	●	●
DS3	Air Conditioning	●	●	●	●
DS3	Engine Relay Unit	●	●	●	●
DS3	Trailer Relay Unit	●	●	●	●
DS3	Electric Power Steering	●	●	●	●
DS3	Steering Wheel With Fixed Central Control	●	●	●	●
DS3	Multiplexed Diesel Additive Pump	●	●	●	●
DS3	Parking Assistance Module	●	●	●	●
DS3	Battery Charge Status Unit	●	●	●	●
DS3	Hands-free Control Unit	●	●	●	●
DS3	High Frequency Receiver	●	●	●	●
DS3	Rain/Brightness Sensor	●	●	●	●
DS3	Seat Belt Reminder LED	●	●	●	●
DS3	Service Module	●	●	●	●
DS3	Multifunction Display	●	●	●	●
DS3	Display/Telematics	●	●	●	●
DS3	Radio	●	●	●	●
DS3	Alarm	●	●	●	●
DS4	Engine Control Moduel	●	●	●	●
DS4	Auto Gearbox	●	●	●	●
DS4	Anti-lock Brake System	●	●	●	●
DS4	Electric Secondary Brake	●	●	●	●
DS4	Airbag	●	●	●	●
DS4	Control Panel	●	●	●	●
DS4	Built-in System Interface (BSI)	●	●	●	●
DS4	Air Conditioning	●	●	●	●
DS4	Trailer Relay Unit	●	●	●	●
DS4	Engine Relay Unit	●	●	●	●
DS4	Electric Power Steering	●	●	●	●
DS4	Steering Wheel With Fixed Central Control	●	●	●	●
DS4	Battery Charge Status Unit	●	●	●	●
DS4	Matrix Screen Integral To The Instrument Panel	●	●	●	●
DS4	Multiplexed Additive Adding Pump	●	●	●	●
DS4	Lane Departure Warning System	●	●	●	●
DS4	Parking Assistance Module	●	●	●	●
DS4	Driver Door Control Panel	●	●	●	●
DS4	Driver Seat Memorizing Unit	●	●	●	●
DS4	Seat Belts Not Fastened LED Unit	●	●	●	●
DS4	Rain/Brightness Sensor	●	●	●	●
DS4	Driver School Module	●	●	●	●
DS4	Monitoring Of The Blind Spot	●	●	●	●
DS4	Supply Protection And Management Unit	●	●	●	●
DS4	Directional Headlamps	●	●	●	●
DS4	Multifunction Display	●	●	●	●
DS4	Display/Telematics	●	●	●	●
DS4	Multiplexed Control Panel	●	●	●	●
DS4	Deflation Detection	●	●	●	●
DS4	Audio Amplifier	●	●	●	●
DS4	Service Module	●	●	●	●
DS4	Alarm	●	●	●	●
DS4	Radio	●	●	●	●
DS5	Engine Control Moduel	●	●	●	●
DS5	Auto Gearbox	●	●	●	●
DS5	Anti-lock Brake System	●	●	●	●
DS5	Airbag	●	●	●	●
DS5	Control Panel	●	●	●	●
DS5	Air Conditioning	●	●	●	●
DS5	Engine Relay Unit	●	●	●	●

DS5	Trailer Relay Unit	●	●	●	●
DS5	Electric Steering Lock	●	●	●	●
DS5	Electric Power Steering	●	●	●	●
DS5	Steering Wheel With Fixed Central Control	●	●	●	●
DS5	Parking Assistance Module	●	●	●	●
DS5	Hands-free Control Unit	●	●	●	●
DS5	Electric Key Reader	●	●	●	●
DS5	Rain/Brightness Sensor	●	●	●	●
DS5	Driver Seat Memorizing Unit	●	●	●	●
DS5	Seat Belts Not Fastened LED Unit	●	●	●	●
DS5	Battery Charge Status Unit	●	●	●	●
DS5	Directional Headlamps	●	●	●	●
DS5	Traction Battery	●	●	●	●
DS5	Matrix Screen Integral To The Instrument Panel	●	●	●	●
DS5	Multiplexed Additive Adding Pump	●	●	●	●
DS5	Supply Protection And Management Unit	●	●	●	●
DS5	Service Module	●	●	●	●
DS5	Multifunction Display	●	●	●	●
DS5	Display/Telematics	●	●	●	●
DS5	Windscreen Wiper	●	●	●	●
DS5	Telematic Navigator	●	●	●	●
DS5	Vibrators Control	●	●	●	●
DS5	Multifunction Camera	●	●	●	●
DS5	Deflation Detection	●	●	●	●
DS5	High Head Vision	●	●	●	●
DS5	Audio Amplifier	●	●	●	●
DS5	Multiplexed Control Panel	●	●	●	●
DS5	Hybrid Mode Selector	●	●	●	●
DS5	Hybrid Control 1	●	●	●	●
DS5	Clock	●	●	●	●
DS5	Radio	●	●	●	●
DS5	Alarm	●	●	●	●
DS5 (Hybird 4)	Engine Control Moduel	●	●	●	●
DS5 (Hybird 4)	Auto Gearbox	●	●	●	●
DS5 (Hybird 4)	Anti-lock Brake System	●	●	●	●
DS5 (Hybird 4)	Airbag	●	●	●	●
DS5 (Hybird 4)	Control Panel	●	●	●	●
DS5 (Hybird 4)	Air Conditioning	●	●	●	●
DS5 (Hybird 4)	Engine Relay Unit	●	●	●	●
DS5 (Hybird 4)	Trailer Relay Unit	●	●	●	●
DS5 (Hybird 4)	Electric Steering Lock	●	●	●	●
DS5 (Hybird 4)	Electric Power Steering	●	●	●	●
DS5 (Hybird 4)	Steering Wheel With Fixed Central Control	●	●	●	●
DS5 (Hybird 4)	Parking Assistance Module	●	●	●	●
DS5 (Hybird 4)	Hands-free Control Unit	●	●	●	●
DS5 (Hybird 4)	Electric Key Reader	●	●	●	●
DS5 (Hybird 4)	Driver Seat Memorizing Unit	●	●	●	●
DS5 (Hybird 4)	Seat Belts Not Fastened LED Unit	●	●	●	●
DS5 (Hybird 4)	Directional Headlamps	●	●	●	●
DS5 (Hybird 4)	Matrix Screen Integral To The Instrument Panel	●	●	●	●
DS5 (Hybird 4)	Battery Charge Status Unit	●	●	●	●
DS5 (Hybird 4)	Multiplexed Additive Adding Pump	●	●	●	●
DS5 (Hybird 4)	Supply Protection And Management Unit	●	●	●	●
DS5 (Hybird 4)	Rain/Brightness Sensor	●	●	●	●
DS5 (Hybird 4)	Service Module	●	●	●	●
DS5 (Hybird 4)	Multifunction Display	●	●	●	●
DS5 (Hybird 4)	Display/Telematics	●	●	●	●
DS5 (Hybird 4)	Windscreen Wiper	●	●	●	●

DS5 (Hybird 4)	Hybrid Mode Selector	●	●	●	●
DS5 (Hybird 4)	Traction Battery	●	●	●	●
DS5 (Hybird 4)	Hybrid Control 1	●	●	●	●
DS5 (Hybird 4)	Hybrid Control 2	●	●	●	●
DS5 (Hybird 4)	Telematic Navigator	●	●	●	●
DS5 (Hybird 4)	Vibrators Control	●	●	●	●
DS5 (Hybird 4)	Multifunction Camera	●	●	●	●
DS5 (Hybird 4)	Multiplexed Control Panel	●	●	●	●
DS5 (Hybird 4)	Deflation Detection	●	●	●	●
DS5 (Hybird 4)	High Head Vision	●	●	●	●
DS5 (Hybird 4)	Audio Amplifier	●	●	●	●
DS5 (Hybird 4)	Clock	●	●	●	●
DS5 (Hybird 4)	Radio	●	●	●	●
DS5 (Hybird 4)	Alarm	●	●	●	●
DS 5LS	Engine Control Moduel	●	●	●	●
DS 5LS	Auto Gearbox	●	●	●	●
DS 5LS	Anti-lock Brake System	●	●	●	●
DS 5LS	Electric Secondary Brake	●	●	●	●
DS 5LS	Airbag	●	●	●	●
DS 5LS	Control Panel	●	●	●	●
DS 5LS	Air Conditioning	●	●	●	●
DS 5LS	Engine Relay Unit	●	●	●	●
DS 5LS	Electric Power Steering	●	●	●	●
DS 5LS	Electric Steering Lock	●	●	●	●
DS 5LS	Steering Wheel With Fixed Central Control	●	●	●	●
DS 5LS	Parking Assistance Module	●	●	●	●
DS 5LS	Battery Charge Status Unit	●	●	●	●
DS 5LS	Rain/Brightness Sensor	●	●	●	●
DS 5LS	Matrix Screen Integral To The Instrument Panel	●	●	●	●
DS 5LS	Supply Protection And Management Unit	●	●	●	●
DS 5LS	Hands-free Control Unit	●	●	●	●
DS 5LS	Electric Key Reader	●	●	●	●
DS 5LS	Audio Amplifier	●	●	●	●
DS 5LS	Directional Headlamps	●	●	●	●
DS 5LS	Services Module	●	●	●	●
DS 5LS	Under Inflation Detection	●	●	●	●
DS 5LS	Multifunction Display	●	●	●	●
DS 5LS	Audio/Navigation/Air Conditioning	●	●	●	●
DS 5LS	Telematic Unit	●	●	●	●
DS 5LS	Radio	●	●	●	●
DS 5LS	Alarm	●	●	●	●
DS6	Engine Control Moduel	●	●	●	●
DS6	Auto Gearbox	●	●	●	●
DS6	Anti-lock Brake System	●	●	●	●
DS6	Electric Secondary Brake	●	●	●	●
DS6	Airbag	●	●	●	●
DS6	Control Panel	●	●	●	●
DS6	Air Conditioning	●	●	●	●
DS6	Engine Relay Unit	●	●	●	●
DS6	Electric Steering Lock	●	●	●	●
DS6	Electric Power Steering	●	●	●	●
DS6	Steering Wheel With Fixed Central Control	●	●	●	●
DS6	Parking Assistance Module	●	●	●	●
DS6	Body Control Module	●	●	●	●
DS6	Rain/Brightness Sensor	●	●	●	●
DS6	Directional Headlamps	●	●	●	●
DS6	Hands-free Control Unit	●	●	●	●
DS6	Electric Key Reader	●	●	●	●

DS6	Under Inflation Detection	●	●	●	●
DS6	Voltage Retaining Device	●	●	●	●
DS6	Matrix Screen Integral To The Instrument Panel	●	●	●	●
DS6	Supply Protection And Management Unit	●	●	●	●
DS6	Battery Charge Status Unit	●	●	●	●
DS6	Signalling Fuse Box	●	●	●	●
DS6	Anti-slip Mode Selector	●	●	●	●
DS6	Audio Amplifier	●	●	●	●
DS6	Services Module	●	●	●	●
DS6	Multifunction Display	●	●	●	●
DS6	Audio/Navigation/Air Conditioning	●	●	●	●
DS6	Telematic Unit	●	●	●	●
DS6	Alarm	●	●	●	●
ELYSEE	Engine Control Moduel	●	●	●	●
ELYSEE	Auto Gearbox	●	●	●	●
ELYSEE	Anti-lock Brake System	●	●	●	●
ELYSEE	Airbag (SIEMENS)	●	●	●	●
ELYSEE	Airbag (AUTOLIV)	●	●	●	●
ELYSEE	Electric Key Reader	●	●	●	●
EVASION (SYNERGIE)	Engine Control Moduel	●	●	●	●
EVASION (SYNERGIE)	Auto Gearbox	●	●	●	●
EVASION (SYNERGIE)	ABS (5.3)	●	●	●	●
EVASION (SYNERGIE)	Airbag (AUTOLIV)	●	●	●	●
FUKANG	Engine Control Moduel	●	●	●	●
FUKANG	Auto Gearbox	●	●	●	●
FUKANG	Anti-lock Brake System	●	●	●	●
JUMPY (DISPATCH)	Engine Control Moduel	●	●	●	●
JUMPY (DISPATCH)	Auto Gearbox	●	●	●	●
JUMPY (DISPATCH)	Anti-lock Brake System	●	●	●	●
JUMPY (DISPATCH)	Airbag	●	●	●	●
JUMPY (DISPATCH)	Control Panel	●	●	●	●
JUMPY (DISPATCH)	Built-in System Interface	●	●	●	●
JUMPY (DISPATCH)	Air Conditioning	●	●	●	●
JUMPY (DISPATCH)	Rear Air Conditioning Panel	●	●	●	●
JUMPY (DISPATCH)	Engine Relay Unit	●	●	●	●
JUMPY (DISPATCH)	Trailer Relay Unit	●	●	●	●
JUMPY (DISPATCH)	Electric Power Steering	●	●	●	●
JUMPY (DISPATCH)	Steering Wheel With Fixed Central Control	●	●	●	●
JUMPY (DISPATCH)	Parking Assistance Module	●	●	●	●
JUMPY (DISPATCH)	Hands-free Control Unit	●	●	●	●
JUMPY (DISPATCH)	Additional Heating	●	●	●	●
JUMPY (DISPATCH)	Multifunction Display	●	●	●	●
JUMPY (DISPATCH)	Rain/Brightness Sensor	●	●	●	●
JUMPY (DISPATCH)	Bodywork Conversion Unit	●	●	●	●
JUMPY (DISPATCH)	Pneumatic Suspension	●	●	●	●
JUMPY (DISPATCH)	Anti-slip Mode Selector	●	●	●	●
JUMPY (DISPATCH)	Battery Change Status Unit	●	●	●	●
JUMPY (DISPATCH)	High Frequency Receiver	●	●	●	●
JUMPY (DISPATCH)	Deflation Detection	●	●	●	●
JUMPY (DISPATCH)	Display/Telematics	●	●	●	●
JUMPY (DISPATCH)	CD Player	●	●	●	●
JUMPY (DISPATCH)	Radio	●	●	●	●
JUMPY (DISPATCH)	Alarm	●	●	●	●
JUMPER (RELAY)	Engine Control Moduel	●	●	●	●
JUMPER (RELAY)	Anti-lock Brake System	●	●	●	●
JUMPER (RELAY)	Control Panel	●	●	●	●
JUMPER (RELAY)	Air Conditioning	●	●	●	●
JUMPER (RELAY)	Electric Power Steering	●	●	●	●

JUMPER (RELAY)	Parking Assistance Module	●	●	●	●
JUMPER (RELAY)	Additional Heating	●	●	●	●
NEMO	Auto Gearbox	●	●	●	●
NEMO	Anti-lock Brake System	●	●	●	●
NEMO	Airbag	●	●	●	●
NEMO	Control Panel	●	●	●	●
NEMO	Parking Assistance Module	●	●	●	●
SAXO	Engine Control Moduel	●	●	●	●
SAXO	Auto Gearbox	●	●	●	●
SAXO	Anti-lock Brake System	●	●	●	●
SAXO	Airbag	●	●	●	●
SAXO	Electric Key Reader	●	●	●	●
XSARA	Engine Control Moduel	●	●	●	●
XSARA	Auto Gearbox	●	●	●	●
XSARA	Anti-lock Brake System	●	●	●	●
XSARA	Airbag	●	●	●	●
XSARA	Control Panel	●	●	●	●
XSARA	Built-in System Interface	●	●	●	●
XSARA	Air Conditioning	●	●	●	●
XSARA	Parking Assistance Module	●	●	●	●
XSARA	Steering Wheel With Fixed Central Control	●	●	●	●
XSARA	Rain/Brightness Sensor	●	●	●	●
XSARA	Multifunction Display B	●	●	●	●
XSARA	Radio	●	●	●	●
XSARA	CD Player	●	●	●	●
XSARA	Alarm	●	●	●	●
XSARA (PICASSO)	Engine Control Moduel	●	●	●	●
XSARA (PICASSO)	Auto Gearbox	●	●	●	●
XSARA (PICASSO)	Anti-lock Brake System	●	●	●	●
XSARA (PICASSO)	Airbag	●	●	●	●
XSARA (PICASSO)	Instrument Cluster	●	●	●	●
XSARA (PICASSO)	Built-in System Interface	●	●	●	●
XSARA (PICASSO)	Air Conditioning	●	●	●	●
XSARA (PICASSO)	Parking Assistance Module	●	●	●	●
XSARA (PICASSO)	Steering Wheel With Fixed Central Control	●	●	●	●
XSARA (PICASSO)	Rain/Brightness Sensor	●	●	●	●
XSARA (PICASSO)	Multifunction Display B	●	●	●	●
XSARA (PICASSO)	ADDGO 2	●	●	●	●
XSARA (PICASSO)	CD Player	●	●	●	●
XSARA (PICASSO)	Radio	●	●	●	●
XSARA (PICASSO)	Alarm	●	●	●	●
XSARA (PICASSO)	Engine Control Moduel	●	●	●	●
XSARA (PICASSO) (CHINA)	Auto Gearbox	●	●	●	●
XSARA (PICASSO) (CHINA)	Anti-lock Brake System	●	●	●	●
XSARA (PICASSO) (CHINA)	Airbag (AUTOLIV)	●	●	●	●
XSARA (PICASSO) (CHINA)	Control Panel	●	●	●	●
XSARA (PICASSO) (CHINA)	Air Conditioning	●	●	●	●
XSARA (PICASSO) (CHINA)	Parking Assistance Module	●	●	●	●
XSARA (PICASSO) (CHINA)	Steering Wheel With Fixed Central Control	●	●	●	●
XSARA (PICASSO) (CHINA)	Rain/Brightness Sensor	●	●	●	●
XSARA (PICASSO) (CHINA)	Multifunction Display B	●	●	●	●
XSARA (PICASSO) (CHINA)	ADDGO 2	●	●	●	●
XSARA (PICASSO) (CHINA)	CD Player	●	●	●	●

XSARA (PICASSO) (CHINA)	Radio	●	●	●	●
XANTIA	Engine Control Moduel	●	●	●	●
XANTIA	Airbag	●	●	●	●
XANTIA	Airbag (Left)	●	●	●	●
XANTIA	CPH_TEXTON	●	●	●	●
XANTIA	TEVES_MK20E	●	●	●	●
XM	Engine Control Moduel	●	●	●	●
XM	Anti-lock Brake System	●	●	●	●
ZX	Engine Control Moduel	●	●	●	●
ZX	Auto Gearbox	●	●	●	●

Compatibilité Citroën - Système EPB

● : Compatible

※ : Peut être compatible en fonction de l'état du véhicule

○ : N'est pas compatible

▲ : Nouvelle compatibilité sur ce modèle

Vehicle	EPB
C4	●
C4 (PICASSO)	●
C4 (SEDAN)	●
C4L	●
C5 (X7)	●
C6	●
DS4	●
DS 5LS	●
DS6	●

Compatibilité Citroën - Système ETC

● : Compatible

* : Peut être compatible en fonction de l'état du véhicule

○ : N'est pas compatible

▲ : Nouvelle compatibilité sur ce modèle

Vehicle	ETC
BERLINGO	●
C1	●
C2	●
C3	●
C4	●
C5	●
C6	●
C8	●
C-ELYSEE	●
C-QUATRE	●
C-TRIOMPHE	●
DS3	●
DS4	●
DS5	●
DS 5LS	●
DS6	●
ELYSEE	●
EVASION (SYNERGIE)	●
FUKANG	●
JUMPY (DISPATCH)	●
JUMPER (RELAY)	●
SAXO	●
XSARA	●
ZX	●

Compatibilité Citroën - Système FAP

● : Compatible

※ : Peut être compatible en fonction de l'état du véhicule

○ : N'est pas compatible

▲ : Nouvelle compatibilité sur ce modèle

Vehicle	Chassis	DPF
BERLINGO B9	HDI_SID807	●
BERLINGO B9	HDI_SID807_BR2	●
C3 A51	EDC17C10	●
C3 A51	EDC17C10_BR2	●
C3 A51	HDI_SID807	●
C3 A51	HDI_SID807_BR2	●
C3	EDC16C34_DV6	●
C3 R	EDC16C34_DV6	●
C3 PICASSO (A58)	EDC17C10	●
C3 PICASSO (A58)	HDI_SID807	●
C3 PICASSO (A58)	HDI_SID807_BR2	●
C4	HDI_SID803	●
C4	EDC16C3	●
C4	HDI_SID803A	●
C4	DCM34	●
C4	DCM35	●
C4	HDI_SID807_BR2	●
C4 (B7)	DCM35_BR2	●
C4 (B7)	HDI_SID807_BR2	●
C4 (B7)	EDC17C10_BR2	●
C4 SEDAN	HDI_SID803	●
C4 SEDAN	EDC16C3	●
C4 SEDAN	HDI_SID803A	●
C4 SEDAN	DCM34	●
C4 SEDAN	DCM35	●
C4 SEDAN	HDI_SID807_BR2	●
C4 PICASSO	EDC16C3	●
C4 PICASSO	HDI_SID803A	●
C4 PICASSO	DCM34	●
C4 PICASSO	DCM35	●
C4 PICASSO	DCM35_BR2	●
C4 PICASSO	HDI_SID807	●
C4 PICASSO	HDI_SID807_BR2	●
C4 PICASSO (B78)	DCM62	●
C4 PICASSO (B78)	HDI_SID807_BR2	●
C4 AIRCROSS	HDI_SID807_J3J4	●
C5 (X7)	HDI_SID201	●
C5 (X7)	EDC16CP39	●
C5 (X7)	DCM34	●
C5 (X7)	DCM34_P	●
C5 (X7)	DCM35	●
C5 (X7)	DCM35_BR2	●
C5 (X7)	EDC16C3	●
C5 (X7)	EDC17CP11	●
C5 (X7)	EDC17CP42	●
C5 (X7)	HDI_SID807	●

C5 (X7)	HDI_SID807_BR2	●
C5	EDC15C2	●
C5 R	EDC16CP39	●
C5 R	HDI_SID803A	●
C5 R	HDI_SID803	●
C6	EDC16CP39	●
C6	EDC17CP11	●
C6	HDI_SID201	●
C8 CAN	EDC15C2	●
C8 CAN	HDI_SID803A	●
C8 CAN	EDC16CP39	●
C8 CAN	DCM35	●
C8 CAN	DCM35_BR2	●
C8	EDC15C2	●
C-CROSSER	EDC16CP39	●
C-CROSSER	EDC16CP39_E5	●
DS3	EDC17C10	●
DS3	EDC17C10_BR2	●
DS3	HDI_SID807	●
DS3	HDI_SID807_BR2	●
DS4	DCM35_BR2	●
DS4	EDC17C10_BR2	●
DS4	HDI_SID807_BR2	●
DS5	DCM35_BR2	●
DS5	HDI_SID807_BR2	●
DS5 Hybird 4	DCM35_HY	●
JUMPY 3	HDI_SID803A	●
JUMPY 3	DCM35	●
JUMPY 3	DCM35_BR2	●
JUMPER 3	EDC17CP52	●
JUMPER 3 MINIBUS	EDC17CP52	●
NEMO	HDI_8DF2	●

Compatibilité Citroën - Injections

● : Compatible

※ : Peut être compatible en fonction de l'état du véhicule

○ : N'est pas compatible

▲ : Nouvelle compatibilité sur ce modèle

Vehicle	Chassis	INJ
BERLINGO	EDC16C3	●
BERLINGO (B9)	EDC16C3	●
BERLINGO (B9)	EDC17C10_BR2	●
BERLINGO (B9)	HDI_SID807	●
C2	EDC16C3	●
C2 (CHINA)	EDC16C3	●
C3	EDC16C3	●
C3 (A51)	EDC17C10	●
C3 (A51)	EDC17C10_BR2	●
C3 (A51)	EDC16C3_DV4	●
C3 (A51)	HDI_SID807	●
C3 (A51)	HDI_SID807_BR2	●
C3 (NEW LOOK)	EDC16C3	●
C3 (PICASSO) (A58)	EDC17C10	●
C3 (PICASSO) (A58)	EDC17C10_BR2	●
C3 (PICASSO) (A58)	EDC16C3	●
C3 (PICASSO) (A58)	HDI_SID807	●
C3 (PICASSO) (A58)	HDI_SID807_BR2	●
C3 (PLURIEL)	EDC16C3	●
C4	DCM35	●
C4	DCM34	●
C4	EDC16C3	●
C4	HDI_SID807_BR2	●
C4 (B7)	DCM35_BR2	●
C4 (B7)	HDI_SID807_BR2	●
C4 (B7)	EDC17C10_BR2	●
C4 (PICASSO)	DCM35	●
C4 (PICASSO)	DCM35_BR2	●
C4 (PICASSO)	EDC16C3	●
C4 (PICASSO)	HDI_SID807	●
C4 (PICASSO)	DCM34	●
C4 (PICASSO)	HDI_SID807_BR2	●
C4 (PICASSO) (B78)	EDC17C10_BR2	●
C4 (SEDAN)	DCM35	●
C4 (SEDAN)	EDC16C3	●
C4 (SEDAN)	HDI_SID807_BR2	●
C4 (SEDAN)	DCM34	●
C5	EDC16C3	●
C5 (X7)	DCM34_P	●
C5 (X7)	DCM35	●
C5 (X7)	EDC16CP39	●
C5 (X7)	DCM34	●
C5 (X7)	DCM35_BR2	●
C5 (X7)	EDC16C3	●
C5 (X7)	EDC17CP11	●
C5 (X7)	HDI_SID807	●

C5 (X7)	HDI_SID807_BR2	●
C6	EDC16CP39	●
C6	EDC17CP11	●
C6	EDC16C3	●
C8	EDC16C3	●
C8 (CAN)	EDC16CP39	●
C8 (CAN)	DCM35	●
C_ELYSEE	EDC16C3	●
C_ELYSEE	EDC17C10_BR2	●
DS3	EDC16C3	●
DS3	EDC17C10	●
DS3	EDC17C10_BR2	●
DS3	HDI_SID807	●
DS3	HDI_SID807_BR2	●
DS4	DCM35_BR2	●
DS4	EDC17C10_BR2	●
DS4	HDI_SID807_BR2	●
DS5	DCM35_BR2	●
DS5	HDI_SID807_BR2	●
ELYSEE	EDC16C3	●
FUKANG	EDC16C3	●
EVASION (SYNERGIE)	EDC16C3	●
JUMPER (RELAY)	EDC16C3	●
JUMPY 3	DCM35	●
JUMPY 3	DCM35_BR2	●
JUMPY 3	EDC16C3	●
JUMPY 3	EDC17C10_BR2	●
JUMPY (DISPATCH)	EDC16C3	●
SAXO	EDC16C3	●
XANTIA	EDC16C3	●
XSARA	EDC16C3	●
XSARA (PICASSO)	EDC16C3	●
XSARA (PICASSO) (CHINA)	EDC16C3	●
ZX	EDC16C3	●

Compatibilité Citroën - Entretien / Vidanges

- : Compatible
- ※ : Peut être compatible en fonction de l'état du véhicule
- : N'est pas compatible
- ▲ : Nouvelle compatibilité sur ce modèle

Vehicle	OIL
BERLINGO	●
C2	●
C3	●
C4	●
C5	●
C6	●
C8	●
C-CROSSER	●
C-ELYSEE	●
C-QUATRE	●
C-TRIOMPHE	●
DS3	●
DS4	●
DS5	●
DS 5LS	●
DS6	●
EVASION (SYNERGIE)	●
JUMPY (DISPATCH)	●
JUMPER (RELAY)	●
NEMO	●
SAXO	●
XSARA	●
XANTIA	●

Compatibilité Citroën - Système SAS

● : Compatible

* : Peut être compatible en fonction de l'état du véhicule

○ : N'est pas compatible

▲ : Nouvelle compatibilité sur ce modèle

Vehicle	SAS
BERLINGO	●
C-ZERO	●
C1	●
C2	●
C3	●
C4	●
C5	●
C6	●
C8	●
C-CROSSER	●
C-ELYSEE	●
C-QUATRE	●
C-TRIOMPHE	●
DS3	●
DS4	●
DS5	●
DS 5LS	●
DS6	●
ELYSEE	●
FUKANG	●
JUMPY (DISPATCH)	●
JUMPER (RELAY)	●
NEMO	●
SAXO	●
XSARA	●