

DAEWOO Diag Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData
CRUZE	Engine Control Module(1.6L)	●	●	●	●
CRUZE	Engine Control Module(1.8L)	●	●	●	●
CRUZE	Engine Control Module(2.0L DIESEL)	●	●	●	●
CRUZE	TCM (Transmission Control Module)	●	●	●	●
CRUZE	ABS (With Stability System)	●	●	●	●
CRUZE	ABS (Without Stability System)	●	●	●	●
CRUZE	BCM (Body Control Module)	●	●	●	●
DAMAS/RABO	Engine Control Module(0.8L)	●	●	●	●
GENTRA/AVEO	Engine Control Module(1.2L)	●	●	●	●
GENTRA/AVEO	Engine Control Module(1.4L)	●	●	●	●
GENTRA/AVEO	Engine Control Module(1.5L)	●	●	●	●
GENTRA/AVEO	Engine Control Module(1.6L)	●	●	●	●
GENTRA/AVEO	TCM (Transmission Control Module) - Aisin	●	●	●	●
GENTRA/AVEO	ABS (Anti-Lock Brake System)	●	●	●	●
GENTRA/AVEO	SRS (Airbag Control Module)	●	●	●	●
KALOS/AVEO	Engine Control Module(1.2L)	●	●	●	●
KALOS/AVEO	Engine Control Module(1.5L)	●	●	●	●
KALOS/AVEO	Engine Control Module(1.6L)	●	●	●	●
KALOS/AVEO	Engine Control Module(1.8L)	●	●	●	●
KALOS/AVEO	TCM (Transmission Control Module)	●	●	●	●
KALOS/AVEO	ABS (Anti-Lock Brake System)	●	●	●	●
KALOS/AVEO	SRS (Airbag Control Module)	●	●	●	●
LACETTI/OPTRA/EXCELLE	Engine Control Module(1.5L)	●	●	●	●
LACETTI/OPTRA/EXCELLE	Engine Control Module(1.6L)	●	●	●	●
LACETTI/OPTRA/EXCELLE	Engine Control Module(1.8L)	●	●	●	●
LACETTI/OPTRA/EXCELLE	Engine Control Module(2.0L DIESEL)	●	●	●	●
LACETTI/OPTRA/EXCELLE	TCM (Transmission Control Module) - Aisin (Gasoline)	●	●	●	●
LACETTI/OPTRA/EXCELLE	TCM (Transmission Control Module) - Aisin (Diesel)	●	●	●	●
LACETTI/OPTRA/EXCELLE	TCM (Transmission Control Module) - Aisin 4Gear (Gas 1.8L)	●	●	●	●
LACETTI/OPTRA/EXCELLE	ABS (Anti-Lock Brake System)	●	●	●	●
LACETTI/OPTRA/EXCELLE	SRS (Airbag Control Module)	●	●	●	●
LACETTI/PREMIERE/CRUZE	Engine Control Module(1.6L DIESEL)	●	●	●	●
LACETTI/PREMIERE/CRUZE	Engine Control Module(1.8L DIESEL)	●	●	●	●
LACETTI/PREMIERE/CRUZE	Engine Control Module(FAM)	●	●	●	●
LACETTI/PREMIERE/CRUZE	TCM (Transmission Control Module) - GF6	●	●	●	●
LACETTI/PREMIERE/CRUZE	ABS (Anti-Lock Brake System)	●	●	●	●
LEGANZA	Engine Control Module(1.8L)	●	●	●	●
LEGANZA	Engine Control Module(2.0L)	●	●	●	●
LEGANZA	Engine Control Module(2.2L)	●	●	●	●
LEGANZA	TCM (Transmission Control Module)	●	●	●	●
LEGANZA	ABS (Anti-Lock Brake System)	●	●	●	●

LEGANZA	SRS (Airbag Control Module)	●	●	●	●
MAGNUS	Engine Control Module(L4)	●	●	●	●
MAGNUS	Engine Control Module(L6)	●	●	●	●
MAGNUS	TCM (Transmission Control Module) - Gasoline(2001MY)	●	●	●	●
MAGNUS	TCM (Transmission Control Module) - Gasoline(2002MY)	●	●	●	●
MAGNUS	TCM (Transmission Control Module) - LPG	●	●	●	●
MAGNUS	ABS (Anti-Lock Brake System)	●	●	●	●
MAGNUS	SRS (Airbag Control Module)	●	●	●	●
MAGNUS	ISU	●	●	●	●
MATIZ (M200)	Engine Control Module(0.8L)	●	●	●	●
MATIZ (M200)	Engine Control Module(1.0L)	●	●	●	●
MATIZ (M200)	TCM (Transmission Control Module) - Jatco	●	●	●	●
MATIZ (M200)	ABS (Anti-Lock Brake System)	●	●	●	●
MATIZ (M300)/SPARK	Engine Control Module(ECU-D52)	●	●	●	●
MATIZ (M300)/SPARK	Engine Control Module(ICM-LPGI)	●	●	●	●
MATIZ (M300)/SPARK	Engine Control Module(A/T)	●	●	●	●
MATIZ (M300)/SPARK	EBCM (Electronic Brake Control Module)	●	●	●	●
MATIZ (M300)/SPARK	SRS (Airbag Control Module)	●	●	●	●
MATIZ (M300)/SPARK	IPC (Instrument Cluster Control Module)	●	●	●	●
MATIZ/SPARK	Engine Control Module(0.8L)	●	●	●	●
MATIZ/SPARK	Engine Control Module(1.0L)	●	●	●	●
NEW BROUGHAM	ECM (Engine Control Module)	●	●	●	●
NEW BROUGHAM	ABS (Anti-Lock Brake System)	●	●	●	●
NEW-LANOS	Engine Control Module(1.5L)	●	●	●	●
NEW-LANOS	TCM (Transmission Control Module)	●	●	●	●
NEW-LANOS	ABS (Anti-Lock Brake System)	●	●	●	●
NEW-NEXIA	Engine Control Module(1.5L)	●	●	●	●
NEW-NEXIA	Engine Control Module(1.6L)	●	●	●	●
NEW-NEXIA	TCM (Transmission Control Module)	●	●	●	●
NEW-NEXIA	ABS (Anti-Lock Brake System)	●	●	●	●
NUBIRA II	Engine Control Module(1.5L)	●	●	●	●
NUBIRA II	Engine Control Module(1.6L)	●	●	●	●
NUBIRA II	Engine Control Module(2.0L)	●	●	●	●
NUBIRA II	TCM (Transmission Control Module)	●	●	●	●
NUBIRA II	ABS (Anti-Lock Brake System)	●	●	●	●
NUBIRA II	SRS (Airbag Control Module)	●	●	●	●
REZZO/TACUMA	Engine Control Module(LPG)	●	●	●	●
REZZO/TACUMA	Engine Control Module(1.6L)	●	●	●	●
REZZO/TACUMA	Engine Control Module(1.8L)	●	●	●	●
REZZO/TACUMA	TCM (Transmission Control Module) - 4HP16	●	●	●	●
REZZO/TACUMA	TCM (Transmission Control Module) - Aisin	●	●	●	●
REZZO/TACUMA	TCM (Transmission Control Module) - Gasoline	●	●	●	●
REZZO/TACUMA	TCM (Transmission Control Module) - LPG	●	●	●	●
REZZO/TACUMA	ABS (Anti-Lock Brake System)	●	●	●	●
REZZO/TACUMA	SRS (Airbag Control Module)	●	●	●	●
STATEMAN	Engine Control Module(V6)	●	●	●	●
STATEMAN	TCM (Transmission Control Module)	●	●	●	●
STATEMAN	ABS (Anti-Lock Brake System)	●	●	●	●
STATEMAN	ABS/ETC(Disable)	●	●	●	●
STATEMAN	SRS (Airbag Control Module)	●	●	●	●
STATEMAN	Instrument	●	●	●	●
TOSCA/EPICA	Engine Control Module(1.8L)	●	●	●	●

TOSCA/EPICA	Engine Control Module(2.0L)	●	●	●	●
TOSCA/EPICA	Engine Control Module(2.5L)	●	●	●	●
TOSCA/EPICA	Engine Control Module(2.0L LPG)	●	●	●	●
TOSCA/EPICA	Engine Control Module(2.0L DIESEL)	●	●	●	●
TOSCA/EPICA	ABS (Anti-Lock Brake System)	●	●	●	●
TOSCA/EPICA	TCM (Transmission Control Module) - Aisin 4Gear (Gas 1.8L)	●	●	●	●
TOSCA/EPICA	TCM (Transmission Control Module) - Aisin 4Gear(LPG 2.0L)	●	●	●	●
TOSCA/EPICA	TCM (Transmission Control Module) - Aisin 5Gear(Gas 2.0/2.5)	●	●	●	●
TOSCA/EPICA	TCM (Transmission Control Module) - Aisin (Diesel)	●	●	●	●
TOSCA/EPICA	SRS (Airbag Control Module)	●	●	●	●
TOSCA/EPICA	ISU	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	Engine Control Module(2.4L)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	Engine Control Module(3.2L)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	Engine Control Module(DIESEL)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	TCM (Transmission Control Module) - Aisin CAN	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	ABS (Anti-Lock Brake System)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	TCCM (Transfer Case Control Module)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	BCM (Body Control Module)	●	●	●	●

DAEWOO Diag Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData
CRUZE	Engine Control Module(1.6L)	●	●	●	●
CRUZE	Engine Control Module(1.8L)	●	●	●	●
CRUZE	Engine Control Module(2.0L DIESEL)	●	●	●	●
CRUZE	TCM (Transmission Control Module)	●	●	●	●
CRUZE	ABS (With Stability System)	●	●	●	●
CRUZE	ABS (Without Stability System)	●	●	●	●
CRUZE	BCM (Body Control Module)	●	●	●	●
DAMAS/RABO	Engine Control Module(0.8L)	●	●	●	●
GENTRA/AVEO	Engine Control Module(1.2L)	●	●	●	●
GENTRA/AVEO	Engine Control Module(1.4L)	●	●	●	●
GENTRA/AVEO	Engine Control Module(1.5L)	●	●	●	●
GENTRA/AVEO	Engine Control Module(1.6L)	●	●	●	●
GENTRA/AVEO	TCM (Transmission Control Module) - Aisin	●	●	●	●
GENTRA/AVEO	ABS (Anti-Lock Brake System)	●	●	●	●
GENTRA/AVEO	SRS (Airbag Control Module)	●	●	●	●
KALOS/AVEO	Engine Control Module(1.2L)	●	●	●	●
KALOS/AVEO	Engine Control Module(1.5L)	●	●	●	●
KALOS/AVEO	Engine Control Module(1.6L)	●	●	●	●
KALOS/AVEO	Engine Control Module(1.8L)	●	●	●	●
KALOS/AVEO	TCM (Transmission Control Module)	●	●	●	●
KALOS/AVEO	ABS (Anti-Lock Brake System)	●	●	●	●
KALOS/AVEO	SRS (Airbag Control Module)	●	●	●	●
LACETTI/OPTRA/EXCELLE	Engine Control Module(1.5L)	●	●	●	●
LACETTI/OPTRA/EXCELLE	Engine Control Module(1.6L)	●	●	●	●
LACETTI/OPTRA/EXCELLE	Engine Control Module(1.8L)	●	●	●	●
LACETTI/OPTRA/EXCELLE	Engine Control Module(2.0L DIESEL)	●	●	●	●
LACETTI/OPTRA/EXCELLE	TCM (Transmission Control Module) - Aisin (Gasoline)	●	●	●	●
LACETTI/OPTRA/EXCELLE	TCM (Transmission Control Module) - Aisin (Diesel)	●	●	●	●
LACETTI/OPTRA/EXCELLE	TCM (Transmission Control Module) - Aisin 4Gear (Gas 1.8L)	●	●	●	●
LACETTI/OPTRA/EXCELLE	ABS (Anti-Lock Brake System)	●	●	●	●
LACETTI/OPTRA/EXCELLE	SRS (Airbag Control Module)	●	●	●	●
LACETTI/PREMIERE/CRUZE	Engine Control Module(1.6L DIESEL)	●	●	●	●
LACETTI/PREMIERE/CRUZE	Engine Control Module(1.8L DIESEL)	●	●	●	●
LACETTI/PREMIERE/CRUZE	Engine Control Module(FAM)	●	●	●	●
LACETTI/PREMIERE/CRUZE	TCM (Transmission Control Module) - GF6	●	●	●	●
LACETTI/PREMIERE/CRUZE	ABS (Anti-Lock Brake System)	●	●	●	●
LEGANZA	Engine Control Module(1.8L)	●	●	●	●
LEGANZA	Engine Control Module(2.0L)	●	●	●	●
LEGANZA	Engine Control Module(2.2L)	●	●	●	●
LEGANZA	TCM (Transmission Control Module)	●	●	●	●
LEGANZA	ABS (Anti-Lock Brake System)	●	●	●	●

LEGANZA	SRS (Airbag Control Module)	●	●	●	●
MAGNUS	Engine Control Module(L4)	●	●	●	●
MAGNUS	Engine Control Module(L6)	●	●	●	●
MAGNUS	TCM (Transmission Control Module) - Gasoline(2001MY)	●	●	●	●
MAGNUS	TCM (Transmission Control Module) - Gasoline(2002MY)	●	●	●	●
MAGNUS	TCM (Transmission Control Module) - LPG	●	●	●	●
MAGNUS	ABS (Anti-Lock Brake System)	●	●	●	●
MAGNUS	SRS (Airbag Control Module)	●	●	●	●
MAGNUS	ISU	●	●	●	●
MATIZ (M200)	Engine Control Module(0.8L)	●	●	●	●
MATIZ (M200)	Engine Control Module(1.0L)	●	●	●	●
MATIZ (M200)	TCM (Transmission Control Module) - Jatco	●	●	●	●
MATIZ (M200)	ABS (Anti-Lock Brake System)	●	●	●	●
MATIZ (M300)/SPARK	Engine Control Module(ECU-D52)	●	●	●	●
MATIZ (M300)/SPARK	Engine Control Module(ICM-LPGI)	●	●	●	●
MATIZ (M300)/SPARK	Engine Control Module(A/T)	●	●	●	●
MATIZ (M300)/SPARK	EBCM (Electronic Brake Control Module)	●	●	●	●
MATIZ (M300)/SPARK	SRS (Airbag Control Module)	●	●	●	●
MATIZ (M300)/SPARK	IPC (Instrument Cluster Control Module)	●	●	●	●
MATIZ/SPARK	Engine Control Module(0.8L)	●	●	●	●
MATIZ/SPARK	Engine Control Module(1.0L)	●	●	●	●
NEW BROUGHAM	ECM (Engine Control Module)	●	●	●	●
NEW BROUGHAM	ABS (Anti-Lock Brake System)	●	●	●	●
NEW-LANOS	Engine Control Module(1.5L)	●	●	●	●
NEW-LANOS	TCM (Transmission Control Module)	●	●	●	●
NEW-LANOS	ABS (Anti-Lock Brake System)	●	●	●	●
NEW-NEXIA	Engine Control Module(1.5L)	●	●	●	●
NEW-NEXIA	Engine Control Module(1.6L)	●	●	●	●
NEW-NEXIA	TCM (Transmission Control Module)	●	●	●	●
NEW-NEXIA	ABS (Anti-Lock Brake System)	●	●	●	●
NUBIRA II	Engine Control Module(1.5L)	●	●	●	●
NUBIRA II	Engine Control Module(1.6L)	●	●	●	●
NUBIRA II	Engine Control Module(2.0L)	●	●	●	●
NUBIRA II	TCM (Transmission Control Module)	●	●	●	●
NUBIRA II	ABS (Anti-Lock Brake System)	●	●	●	●
NUBIRA II	SRS (Airbag Control Module)	●	●	●	●
REZZO/TACUMA	Engine Control Module(LPG)	●	●	●	●
REZZO/TACUMA	Engine Control Module(1.6L)	●	●	●	●
REZZO/TACUMA	Engine Control Module(1.8L)	●	●	●	●
REZZO/TACUMA	TCM (Transmission Control Module) - 4HP16	●	●	●	●
REZZO/TACUMA	TCM (Transmission Control Module) - Aisin	●	●	●	●
REZZO/TACUMA	TCM (Transmission Control Module) - Gasoline	●	●	●	●
REZZO/TACUMA	TCM (Transmission Control Module) - LPG	●	●	●	●
REZZO/TACUMA	ABS (Anti-Lock Brake System)	●	●	●	●
REZZO/TACUMA	SRS (Airbag Control Module)	●	●	●	●
STATEMAN	Engine Control Module(V6)	●	●	●	●
STATEMAN	TCM (Transmission Control Module)	●	●	●	●
STATEMAN	ABS (Anti-Lock Brake System)	●	●	●	●
STATEMAN	ABS/ETC(Disable)	●	●	●	●
STATEMAN	SRS (Airbag Control Module)	●	●	●	●
STATEMAN	Instrument	●	●	●	●
TOSCA/EPICA	Engine Control Module(1.8L)	●	●	●	●

TOSCA/EPICA	Engine Control Module(2.0L)	●	●	●	●
TOSCA/EPICA	Engine Control Module(2.5L)	●	●	●	●
TOSCA/EPICA	Engine Control Module(2.0L LPG)	●	●	●	●
TOSCA/EPICA	Engine Control Module(2.0L DIESEL)	●	●	●	●
TOSCA/EPICA	ABS (Anti-Lock Brake System)	●	●	●	●
TOSCA/EPICA	TCM (Transmission Control Module) - Aisin 4Gear (Gas 1.8L)	●	●	●	●
TOSCA/EPICA	TCM (Transmission Control Module) - Aisin 4Gear(LPG 2.0L)	●	●	●	●
TOSCA/EPICA	TCM (Transmission Control Module) - Aisin 5Gear(Gas 2.0/2.5)	●	●	●	●
TOSCA/EPICA	TCM (Transmission Control Module) - Aisin (Diesel)	●	●	●	●
TOSCA/EPICA	SRS (Airbag Control Module)	●	●	●	●
TOSCA/EPICA	ISU	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	Engine Control Module(2.4L)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	Engine Control Module(3.2L)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	Engine Control Module(DIESEL)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	TCM (Transmission Control Module) - Aisin CAN	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	ABS (Anti-Lock Brake System)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	TCCM (Transfer Case Control Module)	●	●	●	●
WINSTORM/CAPTIVA/ANTABA	BCM (Body Control Module)	●	●	●	●

DAEWOO BLD Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	BLD
LEGANZA	●
REZZO/TACUMA	●

DAEWOO DPF Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	DPF
CRUZE	●

DAEWOO EPB Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	EPB
CRUZE	●

DAEWOO ETC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Dynamic Type	Displacement	ETC
LACETTI PREMIERE/CRUZE	ENGINE CONTROL	ECM-GEN3 1.6D&1.8D	●
GENTRA/AVEO (08MY-)	ENGINE CONTROL	GEN-III 1.4/1.6D (DELPHI)	●
MATIZ (M200)	ENGINE SOHC	1.0 SOHC (EURO-II)	●
MATIZ (M200)	ENGINE SOHC	1.0 SOHC (EURO-III&IV)	●
MATIZ (M200)	ENGINE SOHC	0.8 SOHC KOBD (2007MY)	●
MATIZ/SPARK	ENGINE SOHC	0.8L	●
MATIZ/SPARK	ENGINE SOHC	1.0L	●
REZZO/TACUMA	ENGINE CONTROL	1.6 DOHC	●
REZZO/TACUMA	ENGINE CONTROL	1.8 DOHC	●
KALOS/AVEO (-05MY)	ENGINE CONTROL	1.2 SOHC (SIEMENS)	●
KALOS/AVEO (-05MY)	ENGINE CONTROL	SOHC	●
KALOS/AVEO (06MY-)	ENGINE CONTROL	1.2 SOHC (SIEMENS)	●
NEW-NEXIA	ENGINE CONTROL	1.6 SOHC	●
GENTRA	ENGINE CONTROL	1.2 DOHC (SIEMENS)	●
GENTRA	ENGINE CONTROL	1.2 SOHC (SIEMENS)	●
LACETTI/OPTRA/EXCELLE (06-)	ENGINE CONTROL	1.5 DOHC (SIEMENS)	●
LACETTI/OPTRA/EXCELLE (06-)	ENGINE CONTROL	1.6 DOHC (SIEMENS)	●
LEGANZA	ENGINE SOHC	1.8L	●
LEGANZA	ENGINE SOHC	2.0L	●
LEGANZA	ENGINE DOHC	1.8L	●
LEGANZA	ENGINE DOHC	2.0L	●
LEGANZA	ENGINE DOHC	2.2L	●
NUBIRA II	ENGINE DOHC	1.5L	●
MATIZ (M300) /SPARK	POWER TRAIN	ENG. CONTROL MOD. (ECU-D52)	●
BARINA (2006-)			●
VIVA (2006-)			●
NEW-LANOS			●
NEXIA			●
STATEMAN			●
TOSCA/EPICA			●

DAEWOO OIL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Fuel Type	OIL
CRUZE	Gasoline	●
CRUZE	Diesel	●
TOSCA/EPICA	Diesel	●
WINSTORM/CAPTIVA/ANTABA	Gasoline	●
WINSTORM/CAPTIVA/ANTABA	Diesel	●

DAEWOO SAS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	SAS
CRUZE	●