

RENAULT (SAMSUNG) Diag Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Systemlist	EcuInfo.	ReadCodes	EraseCodes	LiveData	ActTest
CAPTUR/ QM3/ KABIN	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Communications Unit	●	●	●	●	●
	Hands Free Kit	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	○
	Radio	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	○
	UCH	●	●	●	●	●
UPC	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	
CLIO IV	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Communications Unit	●	●	●	●	○
	Hands Free Kit	●	●	●	●	●
	Parking Prox Can	●	●	●	●	○
	Radio	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	●
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
Variable P.A.S	●	●	●	●	●	
KOLEOS II CN/ QM6 CN	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	4 Wheels Drive	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Front Camera	●	●	●	●	○
	Front Radar	●	●	●	●	○
	Left-Hand Door	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Power Back Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Seat Management	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	○
	UCH	●	●	●	●	●
UPC	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	

KOLEOS II/ QM6	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	4 Wheels Drive	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Front Camera	●	●	●	●	○
	Front Radar	●	●	●	●	○
	Left-Hand Door	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Power Back Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Seat Management	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	○
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
Urea Dosing Control Module	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	
KOLEOS/ QM5	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	○
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	TPM (Tire Pressure Monitoring)	●	●	●	●	●
	Auto Front Lighting	●	●	●	●	●
	Discharge Lamp	●	●	●	●	●
	4 Wheels Drive	●	●	●	●	○
	Amplifier	●	●	●	●	●
	Blind Spot Detection	●	●	●	●	●
	Communications Unit	●	●	●	※	○
	Multimed. Connection	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Radio	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	●
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
Variable P.A.S	●	●	●	●	●	
LATITUDE/ SM5	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Blind Spot Detection	●	●	●	●	○
	Communications Unit	●	●	●	●	●
	Driver's Door	●	●	●	●	●
	Left-Hand Door	●	●	●	●	●
	Multimed. Connection	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	○
	Passenger's Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Right-Hand Door	●	●	●	●	●
	Seat Management	●	●	●	●	●
Telematic Ctrl Unit	●	●	●	●	●	
UCH	●	●	●	●	●	
UPC	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	

MEGANE IV SEDAN	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Front Camera	●	●	●	●	●
	Front Radar	●	●	●	●	○
	Left-Hand Door	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Radio	●	●	●	●	●
	Seat Management	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	○
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
	Urea Dosing Control Module	●	●	●	●	●
	Variable P. A. S	●	●	●	●	●
NEW SM3/ FLUENCE/ MEGANE	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	PEB	●	●	●	●	○
	Parking Brake	●	●	●	●	●
	BMS	●	●	●	●	○
	BMS Safety	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	BCB	●	●	●	●	●
	Blind Spot Detection	●	●	●	●	●
	Communications Unit	●	●	●	●	●
	Driver's Door	●	●	●	●	●
	EVC	●	●	●	●	●
	Multimed. Connection	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	○
	Radio	●	●	●	●	●
	Sunroof Control Unit	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	●
	Tracker	●	●	●	●	●
UCH	●	●	●	●	●	
UPC	●	●	●	●	●	
Variable P. A. S	●	●	●	●	●	
SAFRANE2. 0/ SM5 - DF	ECM (Engine Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	○	●
	Airbag	●	●	●	●	●
	Discharge Lamp	●	●	●	●	●
	Seat Management	●	●	●	●	●
	UCH	●	●	●	●	●
	Variable P. A. S	●	●	●	●	●
SAFRANE2. 3/ SM7 - LF	TCM (Transmission Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
	Discharge Lamp	●	●	●	●	○
	Seat Management	●	●	●	●	●
	UCH	●	●	●	●	●
Variable P. A. S	●	●	●	●	●	
SCALA/ SM3-CF	ECM (Engine Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	Parking Assistance	●	●	●	●	●
SM3	ECM (Engine Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
SM5	Airbag	●	●	●	●	●
	Gas Inj	●	●	●	●	●

SM5 - EX	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	Discharge Lamp	●	●	●	●	●
	Parking Assistance	●	●	●	●	●
	Seat Management	●	●	●	●	●
UCH	●	●	●	●	●	
SM7	TCM (Transmission Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	Discharge Lamp	●	●	●	●	●
	Parking Assistance	●	●	●	●	●
	Seat Management	●	●	●	●	○
UCH	●	●	●	●	●	
SM7 - L47	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Blind Spot Detection	●	●	●	●	○
	Communications Unit	●	●	●	●	●
	Driver's Door	●	●	●	●	●
	Left-Hand Door	●	●	●	●	●
	Multimed. Connection	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Passenger's Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Right-Hand Door	●	●	●	●	●
	Seat Management	●	●	●	●	●
UCH	●	●	●	●	●	
UPC	●	●	●	●	●	
Variable P.A.S	●	●	●	●	○	
TALISMAN/SM6	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	4 Wheels Steering	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Front Camera	●	●	●	●	●
	Front Radar	●	●	●	●	●
	Left-Hand Door	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Piloted Suspension	●	●	●	●	○
	Power Back Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Seat Management	●	●	●	●	○
	Telematic Ctrl Unit	●	●	●	●	●
	UCH	●	●	●	●	●
UPC	●	●	●	●	●	
Urea Dosing Control Module	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	
TWIZY	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	BMS	●	●	●	●	●
	Adaptation Unit	●	●	●	●	●
	UCH	●	●	●	●	●

RENAULT\_SAMSUNG Diagnostic Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Systemlist	EcuInfo.	ReadCodes	EraseCodes	LiveData	ActTest
CAPTUR/ QM3/ KABIN	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Communications Unit	●	●	●	●	●
	Hands Free Kit	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	○
	Radio	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	○
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
Variable P.A.S	●	●	●	●	●	
CLIO IV	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Communications Unit	●	●	●	●	○
	Hands Free Kit	●	●	●	●	●
	Parking Prox Can	●	●	●	●	○
	Radio	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	●
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
	Variable P.A.S	●	●	●	●	●
KOLEOS II CN/ QM6 CN	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	4 Wheels Drive	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Front Camera	●	●	●	●	○
	Front Radar	●	●	●	●	○
	Left-Hand Door	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Power Back Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Seat Management	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	○
	UCH	●	●	●	●	●
UPC	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	

KOLEOS II/ QM6	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	4 Wheels Drive	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Front Camera	●	●	●	●	○
	Front Radar	●	●	●	●	○
	Left-Hand Door	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Power Back Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Seat Management	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	○
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
Urea Dosing Control Module	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	
KOLEOS/ QM5	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	○
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	TPM (Tire Pressure Monitoring)	●	●	●	●	●
	Auto Front Lighting	●	●	●	●	●
	Discharge Lamp	●	●	●	●	●
	4 Wheels Drive	●	●	●	●	○
	Amplifier	●	●	●	●	●
	Blind Spot Detection	●	●	●	●	●
	Communications Unit	●	●	●	※	○
	Multimed. Connection	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Radio	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	●
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
Variable P.A.S	●	●	●	●	●	
LATITUDE/ SM5	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Blind Spot Detection	●	●	●	●	○
	Communications Unit	●	●	●	●	●
	Driver's Door	●	●	●	●	●
	Left-Hand Door	●	●	●	●	●
	Multimed. Connection	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	○
	Passenger's Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Right-Hand Door	●	●	●	●	●
	Seat Management	●	●	●	●	●
Telematic Ctrl Unit	●	●	●	●	●	
UCH	●	●	●	●	●	
UPC	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	

MEGANE IV SEDAN	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Front Camera	●	●	●	●	●
	Front Radar	●	●	●	●	○
	Left-Hand Door	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Radio	●	●	●	●	●
	Seat Management	●	●	●	●	●
	Telematic Ctrl Unit	●	●	●	●	○
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
	Urea Dosing Control Module	●	●	●	●	●
Variable P.A.S	●	●	●	●	●	
NEW SM3/ FLUENCE/ MEGANE	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	PEB	●	●	●	●	○
	Parking Brake	●	●	●	●	●
	BMS	●	●	●	●	○
	BMS Safety	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	BCB	●	●	●	●	●
	Blind Spot Detection	●	●	●	●	●
	Communications Unit	●	●	●	●	●
	Driver's Door	●	●	●	●	●
	EVC	●	●	●	●	●
	Multimed. Connection	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	○
	Radio	●	●	●	●	●
Sunroof Control Unit	●	●	●	●	●	
Telematic Ctrl Unit	●	●	●	●	●	
Tracker	●	●	●	●	●	
UCH	●	●	●	●	●	
UPC	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	
SAFRANE2.0/ SM5 - DF	ECM (Engine Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	○	●
	Airbag	●	●	●	●	●
	Discharge Lamp	●	●	●	●	●
	Seat Management	●	●	●	●	●
	UCH	●	●	●	●	●
Variable P.A.S	●	●	●	●	●	
SAFRANE2.3/ SM7 - LF	TCM (Transmission Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
	Discharge Lamp	●	●	●	●	○
	Seat Management	●	●	●	●	●
	UCH	●	●	●	●	●
Variable P.A.S	●	●	●	●	●	
SCALA/ SM3-CF	ECM (Engine Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	Parking Assistance	●	●	●	●	●
SM3	ECM (Engine Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
SM5	Airbag	●	●	●	●	●
	Gas Inj	●	●	●	●	●

SM5 - EX	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	Discharge Lamp	●	●	●	●	●
	Parking Assistance	●	●	●	●	●
	Seat Management	●	●	●	●	●
UCH	●	●	●	●	●	
SM7	TCM (Transmission Control Module)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	Discharge Lamp	●	●	●	●	●
	Parking Assistance	●	●	●	●	●
	Seat Management	●	●	●	●	○
UCH	●	●	●	●	●	
SM7 - L47	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	Lighting	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Blind Spot Detection	●	●	●	●	○
	Communications Unit	●	●	●	●	●
	Driver's Door	●	●	●	●	●
	Left-Hand Door	●	●	●	●	●
	Multimed. Connection	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Passenger's Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Right-Hand Door	●	●	●	●	●
	Seat Management	●	●	●	●	●
UCH	●	●	●	●	●	
UPC	●	●	●	●	●	
Variable P.A.S	●	●	●	●	○	
TALISMAN/SM6	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-lock Braking System)	●	●	●	●	●
	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	Parking Brake	●	●	●	●	●
	4 Wheels Steering	●	●	●	●	●
	Amplifier	●	●	●	●	●
	Front Camera	●	●	●	●	●
	Front Radar	●	●	●	●	●
	Left-Hand Door	●	●	●	●	●
	Multimedia Interface	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	Piloted Suspension	●	●	●	●	○
	Power Back Door	●	●	●	●	●
	Radio	●	●	●	●	●
	Seat Management	●	●	●	●	○
	Telematic Ctrl Unit	●	●	●	●	●
	UCH	●	●	●	●	●
UPC	●	●	●	●	●	
Urea Dosing Control Module	●	●	●	●	●	
Variable P.A.S	●	●	●	●	●	
TWIZY	Airbag	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	BMS	●	●	●	●	●
	Adaptation Unit	●	●	●	●	●
UCH	●	●	●	●	●	
	ECM (Engine Control Module)	●	●	●	●	●
	TCM (Transmission Control Module)	●	●	●	●	●
	ABS (Anti-Lock Braking System)	●	●	●	●	●



XM3	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
	IC (Instrument Cluster)	●	●	●	●	●
	AC (Air Conditioning)	●	●	●	●	●
	BMS 12V	●	●	●	●	※
	Parking Brake	●	●	●	●	●
	Parking Prox Can	●	●	●	●	●
	UCH	●	●	●	●	●
	UPC	●	●	●	●	●
	BSG	●	●	●	●	※
	EVC	●	●	●	●	※
	Central Gateway	●	●	●	●	※
	Check Chassis	●	●	●	●	○
	Brake Booster	●	●	●	●	●
	Amplifier	●	●	●	●	※
	Communications Unit	●	●	●	●	○
	Driving Assistance Supervisor	●	●	●	●	●
	Front Camera	●	●	●	●	●
	Front Radar	●	●	●	●	●
	Hands-Free Module	●	●	●	●	※
	Left Rear Side Radar	●	●	●	●	●
	Right Rear Side Radar	●	●	●	●	●
	Left-Hand Door	●	●	●	●	●
	Multimedia Interface	●	●	●	●	※
	Radio	●	●	●	●	●
	Seat Management	●	●	●	●	●
	Supervisor	●	●	●	●	※
	Telematic Control Unit	●	●	●	●	●
	Telephone Induction Charger	●	●	●	●	●
	Variable P. A. S	●	●	●	●	●

RENAULT\_SAMSUNG BMS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	BMS
NEW SM3/FLUENCE/MEGANE	●
TWIZY	●

BMS Function List

Autonomy Battery

Battery Corrosion Counter

Calculate Battery Wear Counters

Corrosion Battery Counter Memorised

Corrosion Battery Counter Estimated

Battery Cycle Counter Memorised

Battery Cycle Counter Estimated

Battery Cycle Counter

Timed + Batt

100 Ah Traction Battery

Change Battery Compartment

Battery Filling Reinitialisation

Internal Battery

Traction Battery Relay

RENAULT\_SAMSUNG DPF Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	DPF
CAPTUR/QM3/KABIN	●
CLIO IV	●
KOLEOS II/QM6	●
KOLEOS/QM5	●
LATITUDE/SM5	●
MEGANE IV SEDAN	●
NEW SM3/FLUENCE/MEGANE	●
TALISMAN/SM6	●

DPF Function List

Particle Filter Pressure Diff. Sensor
Adaptives After Replacing Cabin Filter
Cabin Filter Regeneration
Particle Filter Relative Pressure Sensor
Adaptives After Regenerating Particle Filter
Particle Filter Adaptives
Particle Filter
Particle Filter Regeneration

RENAULT\_SAMSUNG EPB Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	EPB
KOLEOS II CN/QM6 CN	●
KOLEOS II/QM6	●
KOLEOS/QM5	●
LATITUDE/SM5	●
MEGANE IV SEDAN	●
NEW SM3/FLUENCE/MEGANE	●
SM7 - L47	●
TALISMAN/SM6	●

EPB Function List

Electrical Parking Brake Apply and Release

RENAULT\_SAMSUNG ETC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	ETC
CAPTUR/QM3/KABIN	●
CLIO IV	●
KOLEOS II/QM6	●
KOLEOS/QM5	●
LATITUDE/SM5	●
MEGANE IV SEDAN	●
NEW SM3/FLUENCE/MEGANE	●
TALISMAN/SM6	●

ETC Function List

Programming Throttle Limits

RENAULT\_SAMSUNG INJ Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	INJ
CAPTUR/QM3/KABIN	●
CLIO IV	●
KOLEOS II/QM6	●
KOLEOS/QM5	●
LATITUDE/SM5	●
MEGANE IV SEDAN	●
NEW SM3/FLUENCE/MEGANE	●
TALISMAN/SM6	●

INJ Function List

Injector Adaptives

Cylinder Injector Code

Injection Pump Adaptatives

Fuel Pump Programming

Injector Adaptives No 1, 2, 3, 4

Enter Injector Codes

Enter Injector Calibration Data

RENAULT\_SAMSUNG SAS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	SAS
CAPTUR/QM3/KABIN	●
CLIO IV	●
KOLEOS II CN/QM6 CN	●
KOLEOS II/QM6	●
KOLEOS/QM5	●
LATITUDE/SM5	●
MEGANE IV SEDAN	●
NEW SM3/FLUENCE/MEGANE	●
SM7 - L47	●
TALISMAN/SM6	●

SAS Function List

Steering Wheel Angle Offset Sensor

Steering Wheel Angle Sensor Programming

Steering Wheel Angle Sensor

Steering Angle Sensor Initialisation

Steering Angle Offset

RENAULT\_SAMSUNG TPM Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	TPM
KOLEOS II CN/QM6 CN	●
KOLEOS II/QM6	●
KOLEOS/QM5	●
LATITUDE/SM5	●
MEGANE IV SEDAN	●
NEW SM3/FLUENCE/MEGANE	●
SM7 - L47	●
TALISMAN/SM6	●

TPM Function List

Enter Recommended Pressures

Programming A Valve Code

Programming The Codes Of The Four Valves

Read Valve Set And Memorised Codes



RENAULT\_SAMSUNG OIL Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	OIL
KOLEOS II CN/QM6 CN	●
KOLEOS II/QM6	●
KOLEOS/QM5	●
LATITUDE/SM5	●
MEGANE IV SEDAN	●
NEW SM3/FLUENCE/MEGANE	●
SM7 - L47	●
TALISMAN/SM6	●

OIL Function List

Distance Before Next Oil Change
Oil Change Interval In Km
Oil Change Range: Current Value In Km
Oil Change Interval In Months
Oil Change Range: current Value In Months
Oil Change Interval In Miles
Oil Change Range: current Value In Miles
Personalised Oil Change Frequency
Distance Before Next Oil Change Configuration