# COMPATIBILITE CR PRO

**POUR CITROEN** 

## iCarsoft France

#### Compatibilité Citroën - Batterie

• : Compatible

\* : Peut être compatible en fonction de l'état du véhicule

o: N'est pas compatible

Vehicle	BMS
BERLINGO (B9)	•
C3 (A51)	•
C3 (PICASSO)	•
C3 (XR)	•
C4	•
C4 (CACTUS)	•
C4 (PICASSO)	•
C4 (SEDAN)	•
C4L	•
C5 (X7)	•
C6	•
DS3	•
DS4	•
DS5	•
DS5 (Hybird 4)	•
DS 5LS	•
DS6	•
JUMPY (DISPATCH)	•

#### Compatibilité Citroën - Système BLD

• : Compatible

\* : Peut être compatible en fonction de l'état du véhicule

o: N'est pas compatible

Vehicle	System Type	BLD
BERLINGO (B9)	ABS81	● DED
		•
BERLINGO (B9)	ESP8. 1	•
BERLINGO 2	ABS81	•
BERLINGO 2	ESP81	•
BERLINGO Electric (B9E)	ABS81	<u> </u>
BERLINGO Electric (B9E)	ESP8. 1	•
C-ELYSEE	ABSMK100	•
C-ELYSEE	ESPMK100	•
C-QUATRE 4	ESP8. 1	•
C-QUATRE 5	ESP8. 1	•
C-TRIOMPHE	ESP8. 1	•
C3 (A51)	ABSMK70_1	•
C3 (A51)	ABSMK100	•
C3 (A51)	ESPMK60_0	•
C3 (A51)	ESPMK100	•
C3 AIRCROSS (Ai58)	ABSMK70_1	•
C3 AIRCROSS (Ai58)	ESPMK60_0	•
C3 (Ai58)	ABSMK70_1	•
C3 (Ai58)	ESPMK60_0	•
C3 (PICASSO) (A58)	ABSMK70_1	•
C3 (PICASSO) (A58)	ABSMK100	•
C3 (PICASSO) (A58)	ESPMK60_0	•
C3 (PICASSO) (A58)	ESPMK100	•
C3 (PICASSO) (A158)	ABSMK70_1	•
		•
C3 (PICASSO) (Ai58)	ESPMK60_0	•
C4	ABS8_BOSCH	•
C4	ABS81	•
C4	ESP8BOSCH	•
C4	ESP8. 1	•
C4 (PICASSO)	ABS8_BOSCH	•
C4 (PICASSO)	ABS81	•
C4 (PICASSO)	ESP8B0SCH	•
C4 (PICASSO)	ESP8. 1	•
C4 (PICASSO) (B78)	ESP90	•
C4 (SEDAN)	ABS8_BOSCH	•
C4 (SEDAN)	ABS81	•
C4 (SEDAN)	ESP8BOSCH	•
C4 (SEDAN)	ESP8. 1	•
C4 (B7)	ABS81	•
C4 (B7)	ESP8. 1	•
C4L (B7)	ABS81	•
C4L (B7)	ESP8. 1	•
C5 (X7)	ESP8. 1	•
C6	ESP8. 1	•
C6	ESPEBC440	•
C8 (CAN)	ESP8B0SCH	•
00 (0/11/)	EST ODODOTI	ļ.

C8 (CAN)	ESP8. 1	•
DS 5LS	ESP8. 1	•
DS 6	ESP8. 1	•
DS3	ESPMK60_0	•
DS3	ESPMK100	•
DS4	ABS81	•
DS4	ESP8. 1	•
DS5	ESP8. 1	•
DS5 (Hybird 4)	ESP8. 1	•
JUMPER 3	ABS80	•
JUMPER 3	ASR80	•
JUMPER 3 (MiniBus)	ABS80	•
JUMPER 3 (MiniBus)	ASR80	•
JUMPY 3	ABS8_BOSCH	•
JUMPY 3	ABS81	•
JUMPY 3	ESP8BOSCH	•
JUMPY 3	ESP8. 1	•

#### Compatibilité Citroën - Diagnostic

#### • : Compatible

### \* : Peut être compatible en fonction de l'état du véhicule o : N'est pas compatible

Vehicle	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData
BERLINGO	Engine Control Moduel	•	•	•	•
BERLINGO	Anti-lock Brake System	•	•	•	•
BERLINGO	Airbag	•	•	•	•
BERLINGO	Control Panel	•	•	•	•
BERLINGO	Built-in System Interface	•	•	•	•
BERLINGO	Parking Assistance Module	•	•	•	•
BERLINGO	Steering Wheel With Fixed Central Control	•	•	•	•
BERLINGO	Rain/Brightness Sensor	•	•	•	•
BERLINGO	Additional Heating	•	•	•	•
BERLINGO	Multifunction Display A	•	•	•	•
BERLINGO	Service Module	•	•	•	•
BERLINGO	CD Player	•	•	•	•
BERLINGO	Radio	•	•	•	•
BERLINGO	Alarm	•	•	•	•
BERLINGO (B9)	Engine Control Moduel	•	•	•	•
BERLINGO (B9)	Auto Gearbox	•	•	•	•
BERLINGO (B9)	Anti-lock Brake System	•	•	•	•
BERLINGO (B9)	Airbag	•	•	•	•
BERLINGO (B9)	Control Panel	•	•	•	•
BERLINGO (B9)	Built-in System Interface (BSI)	•	•	•	•
BERLINGO (B9)	Air Conditioning	•	•	•	•
BERLINGO (B9)	Passenger Compartment Air Heanting Resistor	•	•	•	•
BERLINGO (B9)	Engine Relay Unit	•	•	•	•
BERLINGO (B9)	Trailer Relay Unit	•	•	•	•
BERLINGO (B9)	Electric Machine Management	•	•	•	•
BERLINGO (B9)	Electric Power Steering	•	•	•	•
BERLINGO (B9)	Electric Vehicle Management	•	•	•	•
BERLINGO (B9)	Steering Wheel With Fixed Central Control	•	•	•	•
BERLINGO (B9)	Parking Assistance Module	•	•	•	•
BERLINGO (B9)	Rain/Brightness Sensor	•	•	•	•
BERLINGO (B9)	Display/Telematics	•	•	•	•
BERLINGO (B9)	Multifunction Display	•	•	•	•
BERLINGO (B9)	Battery Change Status Unit	•	•	•	•
BERLINGO (B9)	Multiplexed Additive Adding Pump	•	•	•	•
BERLINGO (B9)	Hands-free Control Unit	•	•	•	•
BERLINGO (B9)	High Frequency Receiver	•	•	•	•
BERLINGO (B9)	Deflation Detection	•	•	•	•
BERLINGO (B9)	Bodywork Conversion Unit	•	•	•	•
BERLINGO (B9)	Anti-slip Mode Selector	•	•	•	•
BERLINGO (B9)	Service Module	•	•	•	•
BERLINGO (B9)	Traction Battery	•	•	•	•
BERLINGO (B9)	Onboard Charger Of The Traction Battery	•	•	•	•
BERLINGO (B9)	Traction Battery Cells Management 1	<del>-</del>	•	•	•
	· · ·				
BERLINGO (B9)	Traction Battery Cells Management 2	•	•	•	•
BERLINGO (B9)	Traction Battery Cells Management 3	•	•	•	•
BERLINGO (B9)	Traction Battery Cells Management 4	•	•	•	•
BERLINGO (B9)	Traction Battery Cells Management 5	•	•	•	•
BERLINGO (B9)	Traction Battery Cells Management 7	•	•	•	•
BERLINGO (B9)	Traction Battery Cells Management 8	•	•	•	•
BERLINGO (B9)	Traction Battery Cells Management 9	•	•	•	•

DEDI INCO (DO)	T D C 11 M 10	I <b>a</b>	I_	1_	
	Traction Battery Cells Management 10	•	•	•	•
BERLINGO (B9)	CD Player	•	•	•	•
` ′	Radio	•	•	•	•
	Alarm	•	•	•	•
	Electric Machine Management	•	•	•	•
	Electric Vehicle Management	•	•	•	•
C-ZERO	ASC	•	•	•	•
C-ZERO	ORC	•	•	•	•
C-ZERO	Instrument Cluster	•	•	•	•
C-ZERO	Air Conditioning	•	•	•	•
C-ZERO	Electric Power Steering	•	•	•	•
C-ZERO	Steering Wheel Angle Sensor	•	•	•	•
C-ZERO	Gateway Wiring Housing	•	•	•	•
C-ZERO	Direct Voltage Transformer	•	•	•	•
C-ZERO	Onboard Charger Of The Traction Battery	•	•	•	•
C-ZERO	Traction Battery	•	•	•	•
C-ZERO	Traction Battery Cells Management 1	•	•	•	•
C-ZERO	Traction Battery Cells Management 2	•	•	•	•
C-ZERO	Traction Battery Cells Management 3	•	•	•	•
C-ZERO	Traction Battery Cells Management 4	•	•	•	•
C-ZERO	Traction Battery Cells Management 5	•	•	•	•
C-ZERO	Traction Battery Cells Management 7	•	•	•	•
C-ZERO	Traction Battery Cells Management 8	•	•	•	•
C-ZERO	Traction Battery Cells Management 9	•	•	•	•
C-ZERO	Traction Battery Cells Management 10	•	•	•	•
C-ZERO	Traction Battery Cells Management 11	•	•	•	•
C-ZERO	Service Module	•	•	•	•
C-ZERO	Radio	•	•	•	•
C1	Engine Control Moduel	•	•	•	•
	Manual Gearbox	•	•	•	•
C1	ABS/ESP	•	•	•	•
	Airbag	•	•	•	•
C1	Electric Power Steering	•	•	•	•
C1	Immobiliser	•	•	•	•
C1 (B4)	Engine Control Moduel	•	•	•	•
C1 (B4)		•	•	•	•
C1 (B4)	Auto Gearbox	•	•	•	•
	Anti-lock Brake System	_	_	_	_
C1 (B4)	Airbag	•	•	•	•
C1 (B4)	Instrument Cluster	•	•	•	•
	Air Conditioning	•	•	•	•
	Electric Power Steering	•	•	•	•
C1 (B4)	Engine immobiliser/hands free starting access electric module	•	•	•	•
C1 (B4)	Start/Stop Control	•	•	•	•
C1 (B4)	Multifunction Display	•	•	•	•
C2	Engine Control Moduel	•	•	•	•
C2	Manual Gearbox	•	•	•	•
C2	Anti-lock Brake System	•	•	•	•
C2	Airbag	•	•	•	•
C2	Control Panel	•	•	•	•
C2	Built-in System Interface (BSI)	•	•	•	•
C2	Air Conditioning	•	•	•	•
C2	Electric Power Steering	•	•	•	•
C2	Steering Wheel With Fixed Central Control	•	•	•	•
C2	Engine Relay Unit	•	•	•	•
	Trailer Relay Unit	•	•	•	•
C2	Parking Assistance Module	•	•	•	•
C2	Hands-free Control Unit	•	•	•	•
	Start/Stop Control	•	•	•	•
02	ovar v, ovop control	<u> </u>	<u> </u>	<u> </u>	<u> </u>

Co	Dain/Dwightness Canaan	•	•	•	
C2	Rain/Brightness Sensor	•	•	•	•
C2	High Frequency Receiver	_		_	•
C2	Multifunction Display C	•	•	•	•
C2	Telematic Unit	•	•	•	•
C2	CD Player	•	•	•	•
C2	Radio	•	•	•	•
C2	Alarm	•	•	•	•
C2 (CHINA)	Engine Control Moduel	•	•	•	•
C2 (CHINA)	Auto Gearbox	•	•	•	•
C2 (CHINA)	Anti-lock Brake System	•	•	•	•
C2 (CHINA)	Airbag	•	•	•	•
C2 (CHINA)	Instrument Cluster	•	•	•	•
C2 (CHINA)	Built-in System Interface	•	•	•	•
C2 (CHINA)	Air Conditioning	•	•	•	•
C2 (CHINA)	Steering Wheel With Fixed Central Control	•	•	•	•
C3	Engine Control Moduel	•	•	•	•
C3	Auto Gearbox	•	•	•	•
C3	Anti-lock Brake System	•	•	•	•
C3	Airbag	•	•	•	•
C3	Control Panel	•	•	•	•
C3	Built-in System Interface	•	•	•	•
C3	Air Conditioning	•	•	•	•
C3	Electric Power Steering	•	•	•	•
C3	Steering Wheel With Fixed Central Control	•	•	•	•
C3	Parking Assistance Module	•	•	•	•
C3	Diesel Additive Function	•	•	•	•
C3	Rain/Brightness Sensor	•	•	•	•
C3	Multifunction Display A	•	•	•	•
C3	CD Player	•	•	•	•
C3	Radio	•	•	•	•
C3	Alarm	•	•	•	•
C3 (A51)	Engine Control Moduel	•	•	•	•
C3 (A51)	Auto Gearbox	•	•	•	•
C3 (A51)	Anti-lock Brake System	•	•	•	•
C3 (A51)	Airbag	•	•	•	•
C3 (A51)	Control Panel	•	•	•	•
		•	•	•	•
C3 (A51)	Built-in System Interface	•	•		•
C3 (A51)	Air Conditioning	•	•	•	•
C3 (A51)	Engine Relay Unit	•	•	•	•
C3 (A51)	Trailer Relay Unit	•	•	•	•
C3 (A51)	Electric Power Steering	•	•	•	•
C3 (A51)	Steering Wheel With Fixed Central Control	•	•	•	•
C3 (A51)	Multiplexed Diesel Additive Pump	•	•	•	•
C3 (A51)	Driver Door Control Panel	•	•	•	•
C3 (A51)	Seat Belt Reminder LED	•	•	•	•
C3 (A51)	Battery Change Status Unit	•	•	•	•
C3 (A51)	Hands-free Control Unit	•	•	•	•
CO (AE1)	High Frequency Receiver	•	•	•	•
C3 (A51)					
C3 (A51)	Driver School Module	•	•	•	•
	Driver School Module Rain/Brightness Sensor	•	•	•	•
C3 (A51)					
C3 (A51)	Rain/Brightness Sensor	•	•	•	•
C3 (A51) C3 (A51) C3 (A51)	Rain/Brightness Sensor Parking Assistance Module	•	•	•	•
C3 (A51) C3 (A51) C3 (A51) C3 (A51)	Rain/Brightness Sensor Parking Assistance Module Display/Telematics	•	•	•	•
C3 (A51) C3 (A51) C3 (A51) C3 (A51) C3 (A51) C3 (A51)	Rain/Brightness Sensor Parking Assistance Module Display/Telematics Multifunction Display	•	•	•	•
C3 (A51)	Rain/Brightness Sensor Parking Assistance Module Display/Telematics Multifunction Display Service Module	•	•	•	•
C3 (A51)	Rain/Brightness Sensor Parking Assistance Module Display/Telematics Multifunction Display Service Module Radio	•	•	•	•
C3 (A51)	Rain/Brightness Sensor Parking Assistance Module Display/Telematics Multifunction Display Service Module Radio Alarm	• • • • • • • • • • • • • • • • • • •	•	•	•

		1	1	1	
	Anti-lock Brake System	•	•	•	•
C3 (AIRCROSS)	Airbag	•	•	•	•
C3 (AIRCROSS)	Control Panel	•	•	•	•
C3 (AIRCROSS)	Built-in System Interface	•	•	•	•
C3 (AIRCROSS)	Air Conditioning	•	•	•	•
C3 (AIRCROSS)	Electric Power Steering	•	•	•	•
C3 (AIRCROSS)	Steering Wheel With Fixed Central Control	•	•	•	•
C3 (AIRCROSS)	Parking Assistance Module	•	•	•	•
C3 (AIRCROSS)	Rain/Brightness Sensor	•	•	•	•
C3 (AIRCROSS)	Trailer Relay Unit	•	•	•	•
	Stolen Vehicle Location Control Unit	•	•	•	•
C3 (AIRCROSS)	Telematic Unit	•	•	•	•
C3 (AIRCROSS)	Service Module	•	•	•	•
C3 (AIRCROSS)	Radio	•	•	•	•
C3 (AIRCROSS)		•	•	•	•
	Alarm	_	_	_	_
C3 (NEW LOOK)	Engine Control Moduel	•	•	•	•
C3 (NEW LOOK)	Auto Gearbox	•	•	•	•
C3 (NEW LOOK)	Anti-lock Brake System	•	•	•	•
	Airbag	•	•	•	•
C3 (NEW LOOK)	Control Panel	•	•	•	•
C3 (NEW LOOK)	Built-in System Interface	•	•	•	•
C3 (NEW LOOK)	Air Conditioning	•	•	•	•
C3 (NEW LOOK)	Electric Power Steering	•	•	•	•
C3 (NEW LOOK)	Steering Wheel With Fixed Central Control	•	•	•	•
C3 (NEW LOOK)	Parking Assistance Module	•	•	•	•
C3 (NEW LOOK)	Engine Relay Unit	•	•	•	•
C3 (NEW LOOK)	Hands-free Control Unit	•	•	•	•
C3 (NEW LOOK)	Rain/Brightness Sensor	•	•	•	•
C3 (NEW LOOK)	Multifunction Display C	•	•	•	•
C3 (NEW LOOK)	Telematic RT3	•	•	•	•
C3 (NEW LOOK)	CD Player	•	•	•	•
	Radio	•	•	•	•
	Alarm	•	•	•	•
C3 (PLURIEL)		•	•	•	•
	Engine Control Moduel			_	_
C3 (PLURIEL)	Manual Gearbox	•	•	•	•
	Anti-lock Brake System	•	•	•	•
C3 (PLURIEL)	Airbag	•	•	•	•
C3 (PLURIEL)	Control Panel	•	•	•	•
C3 (PLURIEL)	Built-in System Interface	•	•	•	•
C3 (PLURIEL)	Air Conditioning	•	•	•	•
C3 (PLURIEL)	Electric Power Steering	•	•	•	•
C3 (PLURIEL)	Steering Wheel With Fixed Central Control	•	•	•	•
C3 (PLURIEL)	Parking Assistance Module	•	•	•	•
C3 (PLURIEL)	Engine Relay Unit	•	•	•	•
C3 (PLURIEL)	Hands-free Control Unit	•	•	•	•
C3 (PLURIEL)	Rain/Brightness Sensor	•	•	•	•
	Multifunction Display C	•	•	•	•
	Telematic RT3	•	•	•	•
C3 (PLURIEL)	CD Player	•	•	•	•
C3 (PLURIEL)	Radio	•	•	•	•
C3 (PICASSO)	Engine Control Moduel	•	•	•	•
	Auto Gearbox	•	•	•	•
C3 (DICYGGO)		•			
C3 (PICASSO)			•	•	•
C3 (PICASSO)	Anti-lock Brake System		_		
C3 (PICASSO) C3 (PICASSO)	Airbag	•	•	•	•
C3 (PICASSO) C3 (PICASSO) C3 (PICASSO)	Airbag Control Panel	•	•	•	•
C3 (PICASSO) C3 (PICASSO) C3 (PICASSO) C3 (PICASSO)	Airbag	•	_	_	_
C3 (PICASSO) C3 (PICASSO) C3 (PICASSO) C3 (PICASSO)	Airbag Control Panel	•	•	•	•

C3 (DICAGO)	Stooring Whool With Fired Control Control				
	Steering Wheel With Fixed Central Control	•	•	•	•
	Parking Assistance Module	•	•	_	•
	Engine Relay Unit	•	•	•	•
	Trailer Relay Unit	•	•	•	•
	Driver Door Control Panel	•	•	•	•
	Multiplexed Diesel Additive Pump	•	•	•	•
	High Frequency Receiver	•	•	•	•
	Rain/Brightness Sensor	•	•	•	•
	Hands-free Control Unit	•	•	•	•
	Battery Change Status Unit	•	•	•	•
	Seat Belt Reminder LED	•	•	•	•
	Service Module	•	•	•	•
	Multifunction Display	•	•	•	•
C3 (PICASSO)	Display/Telematics	•	•	•	•
C3 (PICASSO)	Alarm	•	•	•	•
	Radio	•	•	•	•
	Engine Control Moduel	•	•	•	•
C3 (XR)	Auto Gearbox	•	•	•	•
C3 (XR)	Anti-lock Brake System	•	•	•	•
C3 (XR)	Airbag	•	•	•	•
C3 (XR)	Control Panel	•	•	•	•
C3 (XR)	Built-in System Interface (BSI)	•	•	•	•
C3 (XR)	Electric Steering Lock	•	•	•	•
C3 (XR)	Electric Power Steering	•	•	•	•
C3 (XR)	Steering Wheel With Fixed Central Control	•	•	•	•
C3 (XR)	Parking Assistance Module	•	•	•	•
C3 (XR)	Hands-free Control Unit	•	•	•	•
C3 (XR)	Electric Key Reader	•	•	•	•
C3 (XR)	Battery Charge Status Unit	•	•	•	•
C3 (XR)	Anti-slip Mode Selector	•	•	•	•
C3 (XR)	Multiplexed Control Panel	•	•	•	•
C3 (XR)	Voltage Retaining Device	•	•	•	•
C3 (XR)	Multifunction Display	•	•	•	•
C3 (XR)	Telematic Unit	•	•	•	•
C3 (XR)	Service Module	•	•	•	•
C3 (XR)	Radio	•	•	•	•
	Engine Control Moduel	•	•	•	•
	Auto Gearbox	•	•	•	•
	Anti-lock Brake System	•	•	•	•
	Electric Secondary Brake	•	•	•	•
	Airbag	•	•	•	•
	Control Panel	•	•	•	•
	Built-in System Interface	•	•	•	•
	Air Conditioning	•	•	•	•
	Electric Power Steering	•	•	•	•
	Steering Wheel With Fixed Central Control	•	•	•	•
	Engine Relay Unit	•	•	•	•
	Diesel Additive Function	•	•	•	•
	Unit Rev Counter	•	•	•	•
	Driver Door Control Panel	•	•	•	•
	Passenger Door Module	•	•	•	•
	Driver Seat Memorizing Unit	•	•	•	•
		•	•	•	•
	Parking Assistance Module	•	•		•
	Hands-free Control Unit		_	•	
	Rain/Brightness Sensor	•	•	•	•
	Directional Headlamps	•	•	•	•
	High Frequency Receiver	•	•	•	•
C4	Lane Departure Warning System	•	•	•	•

04	I. 1' D 1 II .'		I_	-	
C4	Light Pack Unit	•	•	•	•
C4	Pneumatic Suspension	•	•	•	•
C4	Trailer Relay Unit	•	•	•	•
C4	Windscreen Wiper	•	•	•	•
	Multifunction Display	•	•	•	•
C4	Display/Telematics	•	•	•	•
	Battery Change Status Unit	•	•	•	•
	Multiplexed Additive Adding Pump	•	•	•	•
C4	Service Module	•	•	•	•
C4	Deflation Detection	•	•	•	•
C4	Audio Amplifier	•	•	•	•
C4	Driver School Module	•	•	•	•
C4	CD Player	•	•	•	•
C4	Radio	•	•	•	•
C4	Alarm	•	•	•	•
C4 (AIRCROSS)	Engine Control Moduel	•	•	•	•
C4 (AIRCROSS)	Auto Gearbox	•	•	•	•
C4 (AIRCROSS)	Anti-lock Brake System	•	•	•	•
C4 (AIRCROSS)	Airbag	•	•	•	•
C4 (AIRCROSS)	Control Panel	•	•	•	•
C4 (AIRCROSS)	Air Conditioning	•	•	•	•
C4 (AIRCROSS)	Electric Power Steering	•	•	•	•
C4 (AIRCROSS)	Steering Wheel Angle Sensor	•	•	•	•
C4 (AIRCROSS)	Parking Assistance Module	•	•	•	•
C4 (AIRCROSS)	Start/Stop Control	•	•	•	•
C4 (AIRCROSS)	Starting Authorisation	•	•	•	•
C4 (AIRCROSS)	Locking And Immobiliser Control Module	•	•	•	•
C4 (AIRCROSS)	Rear Final Drive Piloted Clutch	•	•	•	•
C4 (AIRCROSS)	Navigation	•	•	•	•
C4 (AIRCROSS)	Radio	•	•	•	•
C4 (CACTUS)	Engine Control Moduel	•	•	•	•
C4 (CACTUS)	Auto Gearbox	•	•	•	•
C4 (CACTUS)	Anti-lock Brake System	•	•	•	•
C4 (CACTUS)	Airbag	•	•	•	•
C4 (CACTUS)	Control Panel	•	•	•	•
C4 (CACTUS)	Built-in System Interface (BSI)	•	•	•	•
C4 (CACTUS)	Air Conditioning	•	•	•	•
C4 (CACTUS)	Diesel Additive Function	•	•	•	•
C4 (CACTUS)	Electric Power Steering	•	•	•	•
C4 (CACTUS)	Steering Wheel With Fixed Central Control	•	•	•	•
C4 (CACTUS)	Parking Assistance Module	•	•	•	•
C4 (CACTUS)	Seat Belts Not Fastened LED Unit	•	•	•	•
C4 (CACTUS)	Trailer Relay Unit	•	•	•	•
	Rain/Brightness Sensor	•	•	•	•
	Battery Charge Status Unit	•	•	•	•
	Voltage Retaining Device	•	•	•	•
	Multiplexed Control Panel	•	•	•	•
	Service Module	•	•	•	•
C4 (CACTUS)	External CD Player	•	•	•	•
C4 (CACTUS)	Telematic Unit	•	•	•	•
C4 (CACTUS)	Touch Screen	•	•	•	•
C4 (PICASSO)	Engine Control Moduel	•	•	•	•
C4 (PICASSO)	Auto Gearbox	•	•	•	•
					•
C4 (PICASSO)	Anti-lock Brake System	•	•	•	
C4 (PICASSO)	Electric Secondary Brake	•	•	•	•
	Airbag	•	•	•	•
C4 (PICASSO)	Control Panel	•	•	•	•
C4 (PICASSO)	Built-in System Interface	•	•	•	•

a. (p. a.		_	1_	_	_
	Air Conditioning	•	•	•	•
C4 (PICASSO)	Engine Relay Unit	•	•	•	•
C4 (PICASSO)	Trailer Relay Unit	•	•	•	•
C4 (PICASSO)	Diesel Additive Function	•	•	•	•
C4 (PICASSO)	Electric Power Steering	•	•	•	•
C4 (PICASSO)	Electric Steering Lock	•	•	•	•
C4 (PICASSO)	Steering Wheel With Fixed Central Control	•	•	•	•
C4 (PICASSO)	Parking Assistance Module	•	•	•	•
C4 (PICASSO)	Driver Door Control Panel	•	•	•	•
C4 (PICASSO)	Passenger Door Module	•	•	•	•
C4 (PICASSO)	Driver Seat Memorizing Unit	•	•	•	•
C4 (PICASSO)	Right Reversible Seat Belt Reel	•	•	•	•
C4 (PICASSO)	Left Reversible Seat Belt Reel	•	•	•	•
C4 (PICASSO)	Body Control Module	•	•	•	•
	·				
C4 (PICASSO)	Hands-free Control Unit	•	•	•	•
C4 (PICASSO)	Multiplexed Additive Adding Pump	•	•	•	•
	Electric Key Reader	•	•	•	•
C4 (PICASSO)	Battery Change Status Unit	•	•	•	•
C4 (PICASSO)	Rain/Brightness Sensor	•	•	•	•
C4 (PICASSO)	Directional Headlamps	•	•	•	•
C4 (PICASSO)	Unit Rev Counter	•	•	•	•
C4 (PICASSO)	Deflation Detection	•	•	•	•
C4 (PICASSO)	Pneumatic Suspension	•	•	•	•
C4 (PICASSO)	Driver School Module	•	•	•	•
C4 (PICASSO)	High Frequency Receiver	•	•	•	•
C4 (PICASSO)	Lane Departure Warning System	•	•	•	•
C4 (PICASSO)	Light Pack Unit	•	•	•	•
C4 (PICASSO)	Multifunction Camera	•	•	•	•
		_			_
C4 (PICASSO)	Vehicle Distance Assistance	•	•	•	•
C4 (PICASSO)	Multiplexed Control Panel	•	•	•	•
	Signalling Fuse Box	•	•	•	•
C4 (PICASSO)	Supply Protection And Management Unit	•	•	•	•
C4 (PICASSO)	Windscreen Wiper	•	•	•	•
C4 (PICASSO)	Display/Telematics	•	•	•	•
C4 (PICASSO)	Multifunction Display	•	•	•	•
C4 (PICASSO)	Service Module	•	•	•	•
C4 (PICASSO)	Audio Amplifier	•	•	•	•
C4 (PICASSO)	CD Player	•	•	•	•
C4 (PICASSO)	Radio	•	•	•	•
C4 (PICASSO)	Alarm	•	•	•	•
C4 (PICASSO)	Siren	•	•	•	•
C4 (SEDAN)	Engine Control Moduel	•	•	•	•
C4 (SEDAN)	Auto Gearbox	•	•	•	•
C4 (SEDAN)					
	Anti-lock Brake System	•	•	•	•
	Electric Secondary Brake	•	•	•	•
	Airbag	•	•	•	•
C4 (SEDAN)	Control Panel	•	•	•	•
C4 (SEDAN)	Built-in System Interface	•	•	•	•
C4 (SEDAN)	Air Conditioning	•	•	•	•
C4 (SEDAN)	Engine Relay Unit	•	•	•	•
C4 (SEDAN)	Trailer Relay Unit	•	•	•	•
C4 (SEDAN)	Diesel Additive Function	•	•	•	•
C4 (SEDAN)	Electric Power Steering	•	•	•	•
C4 (SEDAN)	Steering Wheel With Fixed Central Control	•	•	•	•
C4 (SEDAN)	Parking Assistance Module	•	•	•	•
C4 (SEDAN)	mostocamo mondio	_	-	-	
OT ODDAM	Driver Door Control Panel	•			
	Driver Door Control Panel	•	•	•	•
C4 (SEDAN)	Driver Door Control Panel Passenger Door Module Driver Seat Memorizing Unit	•	•	•	•

C4 (SEDAN)	Hands-free Control Unit	•	•	•	•
	Rain/Brightness Sensor	•	•	•	•
	Multiplexed Additive Adding Pump	•	•	•	•
	Directional Headlamps	•	•	•	•
C4 (SEDAN)	Driver School Module	•	•	•	•
C4 (SEDAN)	High Frequency Receiver	•	•	•	•
C4 (SEDAN)	Lane Departure Warning System	•	•	•	•
C4 (SEDAN)	Light Pack Unit	•	•	•	•
	Pneumatic Suspension	•	•	•	•
C4 (SEDAN)	*		•	•	•
C4 (SEDAN) C4 (SEDAN)	Deflation Detection Unit Rev Counter	•			•
		•	•	•	
C4 (SEDAN)	Display/Telematics	•	•	•	•
C4 (SEDAN)	Multifunction Display	•	•	•	•
C4 (SEDAN)	Service Module	•	•	•	•
C4 (SEDAN)	Battery Change Status Unit	•	•	•	•
	Audio Amplifier	•	•	•	•
	Windscreen Wiper	•	•	•	•
C4 (SEDAN)	CD Player	•	•	•	•
	Radio	•	•	•	•
	Alarm	•	•	•	•
C4L	Engine Control Moduel	•	•	•	•
C4L	Auto Gearbox	•	•	•	•
C4L	Anti-lock Brake System	•	•	•	•
C4L	Electric Secondary Brake	•	•	•	•
C4L	Airbag	•	•	•	•
C4L	Control Panel	•	•	•	•
C4L	Air Conditioning	•	•	•	•
C4L	Engine Relay Unit	•	•	•	•
C4L	Trailer Relay Unit	•	•	•	•
C4L	Electric Power Steering	•	•	•	•
C4L	Electric Steering Lock	•	•	•	•
C4L	Steering Wheel With Fixed Central Control	•	•	•	•
C4L	Driver Door Control Panel	•	•	•	•
C4L	Driver Seat Memorizing Unit	•	•	•	•
C4L	Seat Belts Not Fastened LED Unit	•	•	•	•
C4L	Parking Assistance Module	•	•	•	•
C4L	Directional Headlamps	•	•	•	•
C4L	Matrix Screen Integral To The Instrument Panel	•	•	•	•
C4L	Multiplexed Control Panel	•	•	•	•
C4L	Battery Change Status Unit	•	•	•	•
C4L	Electric Key Reader	•	•	•	•
	Service Module	•	•	•	•
C4L	Supply Protection And Management Unit	•	•	•	•
C4L	Monitoring Of The Blind Spot	•	•	•	•
C4L	Driver School Module	•	•	•	•
C4L	Rain/Brightness Sensor	•	•	•	•
C4L	Lane Departure Warning System	•	•	•	•
C4L	Deflation Detection	•	•	•	•
C4L	Multiplexed Additive Adding Pump	•	•	•	•
C4L	Display/Telematics	•	•	•	•
C4L	Multifunction Display	•	•	•	•
C4L	Audio Amplifier	•	•	•	•
C4L C4L	Radio	•	•	•	•
			•	•	•
	Alarm Engine Control Medical	•	_		
	Engine Control Moduel	•	•	•	•
C5	Auto Gearbox	•	•	•	•
C5 C5	Airbag	•	•	•	•
III la	Control Panel	•	•	•	•

C5	Built-in System Interface	•	•	•	•
C5	Air Conditioning	•	•	•	•
C5	Steering Wheel With Fixed Central Control	•	•	•	•
C5	Parking Assistance Module	•	•	•	•
C5	Rain/Brightness Sensor	•	•	•	•
C5		•	•	•	•
	Multifunction Display A	•	•	•	•
C5 C5	ADDGO 2	_			_
	ADDITIF FAP	•	•	•	•
C5	MDP PASSAG	•	•	•	•
C5	MDP CONDUCT	•	•	•	•
C5	CD Player	•	•	•	•
C5	Radio	•	•	•	•
C5	Alarm	•	•	•	•
C5 (NEW)	Engine Control Moduel	•	•	•	•
C5 (NEW)	Auto Gearbox	•	•	•	•
C5 (NEW)	Anti-lock Brake System	•	•	•	•
C5 (NEW)	Airbag	•	•	•	•
C5 (NEW)	Built-in System Interface	•	•	•	•
C5 (NEW)	Air Conditioning	•	•	•	•
C5 (NEW)	Engine Relay Unit	•	•	•	•
C5 (NEW)	Electric Power Steering	•	•	•	•
C5 (NEW)	Steering Wheel With Fixed Central Control	•	•	•	•
C5 (NEW)	Parking Assistance Module	•	•	•	•
C5 (NEW)	Hands-free Control Unit	•	•	•	•
C5 (NEW)	Rain/Brightness Sensor	•	•	•	•
C5 (NEW)	Directional Headlamps	•	•	•	•
C5 (NEW)	Deflation Detection	•	•	•	•
C5 (NEW)	Ecotech Suspension	•	•	•	•
C5 (NEW)	Multifunction Display C	•	•	•	•
C5 (NEW)	Telematic RT3	•	•	•	•
C5 (NEW)	ADDGO 3	•	•	•	•
C5 (NEW)	MDP CONDUCT	•	•	•	•
C5 (NEW)	MDP PASSAG	•	•	•	•
C5 (NEW)	CD Player	•	•	•	•
C5 (NEW)	Radio	•	•	•	•
C5 (NEW)	Alarm	•	•	•	•
C5 (X7)	Engine Control Moduel	•	•	•	•
C5 (X7)	Auto Gearbox	•	•	•	•
C5 (X7)	Anti-lock Brake System	•	•	•	•
C5 (X7)	Electric Secondary Brake	•	•	•	•
C5 (X7)	Airbag	•	•	•	•
C5 (X7)	Control Panel	•	•	•	•
C5 (X7)	Built-in System Interface	•	•	•	•
C5 (X7)	·	•	•	•	•
	Air Conditioning	•		•	
C5 (X7)	Electric Power Steering		•		•
C5 (X7)	Steering Wheel With Fixed Central Control	•	•	•	•
C5 (X7)	Engine Relay Unit	•	•	•	•
C5 (X7)	Trailer Relay Unit	•	•	•	•
C5 (X7)	Body Control Module	•	•	•	•
C5 (X7)	Driver Door Control Panel	•	•	•	•
C5 (X7)	Driver Seat Memorizing Unit	•	•	•	•
C5 (X7)	Seat Belt Reminder LED	•	•	•	•
C5 (X7)	Battery Change Status Unit	•	•	•	•
C5 (X7)	Hands-free Control Unit	•	•	•	•
C5 (X7)	Rain/Brightness Sensor	•	•	•	•
C5 (X7)	Parking Assistance Module	•	•	•	•
C5 (X7)	Suspension System Control	•	•	•	•
C5 (X7)	Active Damper Electronic Unit	•	•	•	•
L	l	ı			

C5 (X7)	High Frequency Receiver	•	•	•	•
C5 (X7)	Lane Departure Warning System	•	•	•	•
C5 (X7)	Display/Telematics	•	•	•	•
C5 (X7)	Service Module	•	•	•	•
C5 (X7)	Multifunction Display	•	•	•	•
C5 (X7)	Directional Headlamps	•	•	•	•
C5 (X7)	Deflation Detection	•	•	•	•
C5 (X7)	Additional Heating	•	•	•	•
C5 (X7)	Audio Amplifier	•	•	•	•
C5 (X7)	BASHE5	•	•	•	•
C5 (X7)	Windscreen Wiper	•	•	•	•
C5 (X7)	CD Player	•	•	•	•
C5 (X7)	Radio	•	•	•	•
C5 (X7)	Alarm	•	•	•	•
		_			_
C6 C6	Engine Control Moduel	•	•	•	•
C6	Auto Gearbox	•	•	•	_
	Anti-lock Brake System	•	•	•	•
C6	Electric Secondary Brake	•	•	•	•
C6	Airbag	•	•	•	•
C6	Control Panel	•	•	•	•
C6	Built-in System Interface (BSI)	•	•	•	•
C6	Engine Relay Unit	•	•	•	•
C6	Trailer Relay Unit	•	•	•	•
C6	Boot Relay Unit	•	•	•	•
C6	Suspension	•	•	•	•
C6	Air Conditioning	•	•	•	•
C6	Rear Air Conditioning Panel	•	•	•	•
C6	Parking Assistance Module	•	•	•	•
C6	Steering Wheel With Fixed Central Control	•	•	•	•
C6	Driver Door Control Panel	•	•	•	•
C6	Passenger Door Module	•	•	•	•
C6	Driver Seat Memorizing Unit	•	•	•	•
C6	Passenger Seat Memorisation Unit	•	•	•	•
C6	Left Seat Switch Panel	•	•	•	•
C6	Right Seat Switch Panel	•	•	•	•
C6	Rear Seat Memorising Unit	•	•	•	•
C6	Battery Change Status Unit	•	•	•	•
C6	Rain/Brightness Sensor	•	•	•	•
C6	Directional Headlamps	•	•	•	•
C6	Deflation Detection	•	•	•	•
C6	Additional Heating	•	•	•	•
C6	Hands-free Control Unit	•	•	•	•
C6	High Frequency Receiver	•	•	•	•
C6	High Head Vision	•	•	•	•
C6	Lane Departure Warning System	•	•	•	•
C6	Headlamp (Left)	•	•	•	•
C6	Headlamp (Right)	•	•	•	•
C6	Moving Panel Deflector	•	•	•	•
C6	Pedestrian Impact Detection	•	•	•	•
C6	Windscreen Wiper	•	•	•	•
C6	Boitier Telematique	•	•	•	•
C6	Multifunction Display	•	•	•	•
C6	CD Player	•	•	•	•
C6	Radio	•	•	•	•
C6	Alarm	•	•	•	•
C8	Engine Control Moduel	•	•	•	•
C8	Auto Gearbox	•	•	•	•
C8	Anti-lock Brake System	•	•	•	•
00	mict fook brake oyocoll	<u> </u>	<u> </u>	<u> </u>	

C8	Airbag	•	•	•	•
C8	Control Panel	•	•	•	•
C8	Built-in System Interface (BSI)	•	•	•	•
C8	Air Conditioning	•	•	•	•
C8	Engine Relay Unit	•	•	•	•
C8	Trailer Relay Unit	•	•	•	•
C8	Diesel Additive Function	•	•	•	•
C8	Electric Power Steering	•	•	•	•
C8	Steering Wheel With Fixed Central Control	•	•	•	•
C8	Parking Assistance Module	•	•	•	•
C8	Driver Door Control Panel	•	•	•	•
C8	Passenger Door Module	•	•	•	•
C8	Sliding Side Door Module	•	•	•	•
C8	Driver Seat Memorizing Unit	•	•	•	•
C8	Hands-free Control Unit	•	•	•	•
C8	Additional Heating	•	•	•	•
C8	Rain/Brightness Sensor	•	•	•	•
C8	Multifunction Display	•	•	•	•
C8	Headlamp (Left)	•	•	•	•
C8	Headlamp (Right)	•	•	•	•
	Display/Telematics	•	_		_
C8		_	•	•	•
C8	Telematic Unit	•	•	•	•
C8	LEDs And Odometer	•	•	•	•
C8	Deflation Detection	•	•	•	•
C8	Front Sunsroof	•	•	•	•
C8	Middle Sunroof	•	•	•	•
C8	Rear Sunroof	•	•	•	•
C8	CD Player	•	•	•	•
C8	Radio	•	•	•	•
C8	Alarm	•	•	•	•
C-CROSSER	Engine Control Moduel	•	•	•	•
C-CROSSER	Auto Gearbox	•	•	•	•
C-CROSSER	Anti-lock Brake System	•	•	•	•
C-CROSSER	Electronic Stability Program	•	•	•	•
C-CROSSER	Airbag	•	•	•	•
C-CROSSER	Control Panel	•	•	•	•
C-CROSSER	Air Conditioning	•	•	•	•
C-CROSSER	Steering Wheel Angle Sensor	•	•	•	•
C-CROSSER	Parking Assistance Module	•	•	•	•
C-CROSSER	Driver Door Control Panel	•	•	•	•
C-CROSSER	Passenger Door Switch Panel	•	•	•	•
C-CROSSER	Rear Left Door Switch Panel	•	•	•	•
C-CROSSER	Rear Right Door Switch Panel	•	•	•	•
C-CROSSER	Rear Final Drive Piloted Clutch	•	•	•	•
C-CROSSER	Locking And Immobiliser Control Module	•	•	•	•
C-CROSSER	Headlamp Beam Corrector	•	•	•	•
C-CROSSER	Rain/Brightness Sensor	•	•	•	•
C-CROSSER	Hands-free Control Unit	•	•	•	•
C-CROSSER	Gear Lever (DCT)	•	•	•	•
C-CROSSER			ı -	l <sup>*</sup>	
I SHOUSEN		•	•	•	
C-CROSSER	Sunroof	•	•	•	•
C-CROSSER	Sunroof Navigation	•	•	•	•
C-CROSSER	Sunroof Navigation Radio	•	•	•	•
C-CROSSER C-ELYSEE	Sunroof Navigation Radio Engine Control Moduel	•	•	•	•
C-CROSSER C-ELYSEE C-ELYSEE	Sunroof Navigation Radio Engine Control Moduel Auto Gearbox	•	•	•	•
C-CROSSER C-ELYSEE C-ELYSEE C-ELYSEE	Sunroof Navigation Radio Engine Control Moduel Auto Gearbox Anti-lock Brake System	•	•	•	•
C-CROSSER C-ELYSEE C-ELYSEE C-ELYSEE C-ELYSEE	Sunroof Navigation Radio Engine Control Moduel Auto Gearbox Anti-lock Brake System SAC (SIEMENS)	•	• • • • • • • • • • • • • • • • • • •	•	•
C-CROSSER C-ELYSEE C-ELYSEE C-ELYSEE	Sunroof Navigation Radio Engine Control Moduel Auto Gearbox Anti-lock Brake System	•	•	•	•

a privapp (va (vi)		_	I =	_	_
	Anti-lock Brake System	•	•	•	•
	Airbag	•	•	•	•
C-ELYSEE (M3/M4)	Control Panel	•	•	•	•
C-ELYSEE (M3/M4)	Built-in System Interface (BSI)	•	•	•	•
C-ELYSEE (M3/M4)	Electric Power Steering	•	•	•	•
C-ELYSEE (M3/M4)	Steering Wheel With Fixed Central Control	•	•	•	•
C-ELYSEE (M3/M4)	Parking Assistance Module	•	•	•	•
C-ELYSEE (M3/M4)	Trailer Relay Unit	•	•	•	•
C-ELYSEE (M3/M4)	Multiplexed Addition Pump	•	•	•	•
C-ELYSEE (M3/M4)	Multifunction Display	•	•	•	•
C-ELYSEE (M3/M4)	Radio	•	•	•	•
, , ,	Siren	•	•	•	•
	Engine Control Moduel	•	•	•	•
	Auto Gearbox	•	•	•	•
C-QUATRE	Anti-lock Brake System	•	•	•	•
C-QUATRE	Airbag (AUTOLIV)	•	•	•	•
C-QUATRE	Control Panel	•	•	•	•
C-QUATRE	Built-in System Interface (BSI)	•	•	•	•
C-QUATRE	Air Conditioning	•	•	•	•
C-QUATRE	Engine Relay Unit	•	•	•	•
C-QUATRE	Electric Power Steering	•	•	•	•
C-QUATRE	Steering Wheel With Fixed Central Control	•	•	•	•
C-QUATRE	Parking Assistance Module	•	•	•	•
C-QUATRE	Rain/Brightness Sensor	•	•	•	•
C-QUATRE	Hands-free Control Unit	•	•	•	•
	Multifunction Display	•	•	•	•
·	MDP CONDUCT	•	•	•	•
C-QUATRE	MDP PASSAG	•	•	•	•
				_	_
C-QUATRE	Telematic RT3	•	•	•	•
C-QUATRE	CD Player	•	•	•	•
	Radio	•	•	•	•
C-TRIOMPHE	Engine Control Moduel	•	•	•	•
C-TRIOMPHE	Auto Gearbox	•	•	•	•
C-TRIOMPHE	Anti-lock Brake System	•	•	•	•
C-TRIOMPHE	Airbag	•	•	•	•
C-TRIOMPHE	Built-in System Interface	•	•	•	•
C-TRIOMPHE	Air Conditioning	•	•	•	•
C-TRIOMPHE	Engine Relay Unit	•	•	•	•
C-TRIOMPHE	Engine Service Box	•	•	•	•
	Tachometer Control Box	•	•	•	•
	Electric Power Steering	•	•	•	•
	Steering Wheel With Fixed Central Control	•	•	•	•
	Passenger Door Module	•	•	•	•
	Adjustable Headlight	•	•	•	•
	Parking Assistance Module	•	•	•	•
C-TRIOMPHE	Hands-free Control Unit	•	•	•	•
C-TRIOMPHE	Rain/Brightness Sensor	•	•	•	•
C-TRIOMPHE	Multifunction Display C	•	•	•	•
C-TRIOMPHE	MDP CONDUCT	•	•	•	•
C-TRIOMPHE	Telematic RT3	•	•	•	•
C-TRIOMPHE	CD Player	•	•	•	•
C-TRIOMPHE	Radio	•	•	•	•
	Alarm	•	•	•	•
DS3	Engine Control Moduel	•	•	•	•
		•		•	•
	Auto Gearbox		•		
	Anti-lock Brake System	•	•	•	•
	Airbag	•	•	•	•
DS3	Control Panel	•	•	•	•

DG0	D 11	_	_	_	1
DS3	Built-in System Interface	•	•	•	•
DS3	Air Conditioning	•	•	•	•
DS3	Engine Relay Unit	•	•	•	•
DS3	Trailer Relay Unit	•	•	•	•
DS3	Electric Power Steering	•	•	•	•
DS3	Steering Wheel With Fixed Central Control	•	•	•	•
DS3	Multiplexed Diesel Additive Pump	•	•	•	•
DS3	Parking Assistance Module	•	•	•	•
DS3	Battery Change Status Unit	•	•	•	•
DS3	Hands-free Control Unit	•	•	•	•
DS3	High Frequency Receiver	•	•	•	•
DS3	Rain/Brightness Sensor	•	•	•	•
DS3	Seat Belt Reminder LED	•	•	•	•
DS3	Service Module	•	•	•	•
DS3	Multifunction Display	•	•	•	•
DS3	Display/Telematics	•	•	•	•
DS3	Radio	•	•	•	•
DS3	Alarm	•	•	•	•
DS4	Engine Control Moduel	•	•	•	•
DS4	Auto Gearbox	•	•	•	•
DS4	Anti-lock Brake System	•	•	•	•
DS4	Electric Secondary Brake	•	•	•	•
DS4	Airbag	•	•	•	•
DS4	Control Panel	•	•	•	•
		•	•	•	•
DS4	Built-in System Interface (BSI)				_
DS4	Air Conditioning	•	•	•	•
DS4	Trailer Relay Unit	•	•	•	•
DS4	Engine Relay Unit	•	•	•	•
DS4	Electric Power Steering	•	•	•	•
DS4	Steering Wheel With Fixed Central Control	•	•	•	•
DS4	Battery Charge Status Unit	•	•	•	•
DS4	Matrix Screen Integral To The Instrument Panel	•	•	•	•
DS4	Multiplexed Additive Adding Pump	•	•	•	•
DS4	Lane Departure Warning System	•	•	•	•
DS4	Parking Assistance Module	•	•	•	•
DS4	Driver Door Control Panel	•	•	•	•
DS4	Driver Seat Memorizing Unit	•	•	•	•
DS4	Seat Belts Not Fastened LED Unit	•	•	•	•
DS4	Rain/Brightness Sensor	•	•	•	•
DS4	Driver School Module	•	•	•	•
DS4	Monitoring Of The Blind Spot	•	•	•	•
DS4	Supply Protection And Management Unit	•	•	•	•
DS4	Directional Headlamps	•	•	•	•
DS4	Multifunction Display	•	•	•	•
DS4	Display/Telematics	•	•	•	•
DS4	Multiplexed Control Panel	•	•	•	•
DS4	Deflation Detection	•	•	•	•
DS4	Audio Amplifier	•	•	•	•
DS4	Service Module	•	•	•	•
DS4	Alarm	•	•	•	•
DS4	Radio	•	•	•	•
DS5	Engine Control Moduel	•	•	•	•
DS5	Auto Gearbox	•	•	•	•
DS5	Anti-lock Brake System	•	•	•	•
DS5	Airbag	•	•	•	•
DS5	Control Panel	•	•	•	•
DS5		•	•	•	•
	Air Conditioning				_
DS5	Engine Relay Unit	•	•	•	•

nce	Trailar Palay Unit				
DS5	Trailer Relay Unit	•	•	•	•
DS5	Electric Steering Lock Electric Power Steering	_	•	_	_
	v v	•	•	•	•
DS5	Steering Wheel With Fixed Central Control	•	•	•	•
DS5	Parking Assistance Module	•	•	•	•
DS5	Hands-free Control Unit	•	•	•	•
DS5	Electric Key Reader	•	•	•	•
DS5	Rain/Brightness Sensor	•	•	•	•
DS5	Driver Seat Memorizing Unit	•	•	•	•
DS5	Seat Belts Not Fastened LED Unit	•	•	•	•
DS5	Battery Charge Status Unit	•	•	•	•
DS5	Directional Headlamps	•	•	•	•
DS5	Traction Battery	•	•	•	•
DS5	Matrix Screen Integral To The Instrument Panel	•	•	•	•
DS5	Multiplexed Additive Adding Pump	•	•	•	•
DS5	Supply Protection And Management Unit	•	•	•	•
DS5	Service Module	•	•	•	•
DS5	Multifunction Display	•	•	•	•
DS5	Display/Telematics	•	•	•	•
DS5	Windscreen Wiper	•	•	•	•
DS5	Telematic Navigator	•	•	•	•
DS5	Vibrators Control	•	•	•	•
DS5	Multifunction Camera	•	•	•	•
DS5	Deflation Detection	•	•	•	•
DS5	High Head Vision	•	•	•	•
DS5	Audio Amplifier	•	•	•	•
DS5	Multiplexed Control Panel	•	•	•	•
DS5	Hybrid Mode Selector	•	•	•	•
DS5	Hybrid Control 1	•	•	•	•
DS5	Clock	•	•	•	•
DS5	Radio	•	•	•	•
DS5	Alarm	•	•	•	•
DS5 (Hybird 4)	Engine Control Moduel	•	•	•	•
DS5 (Hybird 4)	Auto Gearbox	•	•	•	•
DS5 (Hybird 4)	Anti-lock Brake System	•	•	•	•
DS5 (Hybird 4)	Airbag	•	•	•	•
DS5 (Hybird 4)	Control Panel	•	•	•	•
DS5 (Hybird 4)	Air Conditioning	•	•	•	•
DS5 (Hybird 4)	Engine Relay Unit	•	•	•	•
DS5 (Hybird 4)	Trailer Relay Unit	•	•	•	•
DS5 (Hybird 4)	Electric Steering Lock	•	•	•	•
DS5 (Hybird 4)	Electric Power Steering	•	•	•	•
DS5 (Hybird 4)	Steering Wheel With Fixed Central Control	•	•	•	•
DS5 (Hybird 4)	Parking Assistance Module	•	•	•	•
DS5 (Hybird 4)	Hands-free Control Unit	•	•	•	•
DS5 (Hybird 4)	Electric Key Reader	•	•	•	•
DS5 (Hybird 4)	Driver Seat Memorizing Unit	•	•	•	•
				_	
DS5 (Hybird 4)	Seat Belts Not Fastened LED Unit	•	•	•	•
DS5 (Hybird 4)	Directional Headlamps	•	•	•	•
DS5 (Hybird 4)	Matrix Screen Integral To The Instrument Panel	•	•	•	•
DS5 (Hybird 4)	Battery Charge Status Unit	•	•	•	•
DS5 (Hybird 4)	Multiplexed Additive Adding Pump	•	•	•	•
DS5 (Hybird 4)	Supply Protection And Management Unit	•	•	•	•
DS5 (Hybird 4)	Rain/Brightness Sensor	•	•	•	•
DS5 (Hybird 4)	Service Module	•	•	•	•
DS5 (Hybird 4)	Multifunction Display	•	•	•	•
DS5 (Hybird 4)	Display/Telematics	•	•	•	•
DS5 (Hybird 4)	Windscreen Wiper	•	•	•	•

DS5 (Hybird 4) Hybrid Mode Selector  DS5 (Hybird 4) Traction Battery  DS5 (Hybird 4) Hybrid Control 1  DS5 (Hybird 4) Hybrid Control 2  DS5 (Hybird 4) Telematic Navigator  DS5 (Hybird 4) Vibrators Control  DS5 (Hybird 4) Wibrid Control	•
DS5 (Hybird 4) Hybrid Control 1  DS5 (Hybird 4) Hybrid Control 2  DS5 (Hybird 4) Telematic Navigator  DS5 (Hybird 4) Vibrators Control	•
DS5 (Hybird 4) Hybrid Control 2	•
DS5 (Hybird 4) Telematic Navigator  DS5 (Hybird 4) Vibrators Control	_
DS5 (Hybird 4) Vibrators Control	
	•
DCE (Hykind 4) Multifunction Common	•
DS5 (Hybird 4) Multifunction Camera • •	•
DS5 (Hybird 4) Multiplexed Control Panel • •	•
DS5 (Hybird 4) Deflation Detection • •	•
DS5 (Hybird 4) High Head Vision • •	•
DS5 (Hybird 4) Audio Amplifier $lacktriangle$	•
DS5 (Hybird 4) Clock $lacktriangle$	•
DS5 (Hybird 4) Radio $lacktriangle$	•
DS5 (Hybird 4) Alarm $lacktriangle$	•
DS 5LS Engine Control Moduel • •	•
DS 5LS Auto Gearbox • •	•
DS 5LS Anti-lock Brake System • •	•
DS 5LS Electric Secondary Brake	•
DS 5LS Airbag • • •	•
DS 5LS Control Panel • •	•
DS 5LS Air Conditioning	•
DS 5LS Engine Relay Unit	•
l · · ·	
DS 5LS Electric Power Steering • •	•
DS 5LS Electric Steering Lock	•
DS 5LS Steering Wheel With Fixed Central Control	•
DS 5LS Parking Assistance Module	•
DS 5LS Battery Charge Status Unit	•
DS 5LS Rain/Brightness Sensor • •	•
DS 5LS Matrix Screen Integral To The Instrument Panel	•
DS 5LS Supply Protection And Management Unit	•
DS 5LS Hands-free Control Unit	•
DS 5LS Electric Key Reader • • •	•
DS 5LS Audio Amplifier • • • •	•
DS 5LS Directional Headlamps • • •	•
DS 5LS Services Module • •	•
DS 5LS Under Inflation Detection • • •	•
DS 5LS Multifunction Display $lacktriangle$	•
DS 5LS Audio/Navigation/Air Conditioning   • • •	•
DS 5LS Telematic Unit	•
DS 5LS Radio • •	•
DS 5LS Alarm • •	•
DS6 Engine Control Moduel • •	•
DS6 Auto Gearbox • • •	•
DS6 Anti-lock Brake System • •	•
DS6 Electric Secondary Brake	•
DS6 Airbag • • •	•
DS6 Control Panel • •	•
DS6 Air Conditioning	•
	•
DS6 Electric Steering Lock	•
DS6 Electric Power Steering • • •	•
DS6 Steering Wheel With Fixed Central Control	•
DS6 Parking Assistance Module	•
DS6 Body Control Module	•
DS6 Rain/Brightness Sensor ● ●	•
DS6 Directional Headlamps • • •	•
DS6 Hands-free Control Unit	•
DS6 Electric Key Reader • •	•

DS6	Under Inflation Detection	•	•	•	•
	Voltage Retaining Device	•	•	•	•
	Matrix Screen Integral To The Instrument Panel	•	•	•	•
	Supply Protection And Management Unit	•	•	•	•
	Battery Charge Status Unit	•	•	•	•
	Signalling Fuse Box	•	•	•	•
	Anti-slip Mode Selector	•	•	•	•
DS6		•	•	•	•
	Audio Amplifier				
DS6	Services Module	•	•	•	•
	Multifunction Display	•	•	•	•
DS6	Audio/Navigation/Air Conditioning	•	•	•	•
DS6	Telematic Unit	•	•	•	•
DS6	Alarm	•	•	•	•
	Engine Control Moduel	•	•	•	•
	Auto Gearbox	•	•	•	•
	Anti-lock Brake System	•	•	•	•
	Airbag (SIEMENS)	•	•	•	•
	Airbag (AUTOLIV)	•	•	•	•
	Electric Key Reader	•	•	•	•
EVASION (SYNERGIE)	Engine Control Moduel	•	•	•	•
EVASION (SYNERGIE)	Auto Gearbox	•	•	•	•
EVASION (SYNERGIE)	ABS (5.3)	•	•	•	•
EVASION (SYNERGIE)	Airbag (AUTOLIV)	•	•	•	•
FUKANG	Engine Control Moduel	•	•	•	•
FUKANG	Auto Gearbox	•	•	•	•
FUKANG	Anti-lock Brake System	•	•	•	•
JUMPY (DISPATCH)	Engine Control Moduel	•	•	•	•
JUMPY (DISPATCH)	Auto Gearbox	•	•	•	•
JUMPY (DISPATCH)	Anti-lock Brake System	•	•	•	•
JUMPY (DISPATCH)	Airbag	•	•	•	•
JUMPY (DISPATCH)	Control Panel	•	•	•	•
JUMPY (DISPATCH)	Built-in System Interface	•	•	•	•
JUMPY (DISPATCH)	Air Conditioning	•	•	•	•
JUMPY (DISPATCH)	Rear Air Conditioning Panel	•	•	•	•
JUMPY (DISPATCH)	Engine Relay Unit	•	•	•	•
JUMPY (DISPATCH)	Trailer Relay Unit	•	•	•	•
	Electric Power Steering	•	•	•	•
JUMPY (DISPATCH)	Steering Wheel With Fixed Central Control	•	•	•	•
	Parking Assistance Module	•	•	•	•
	Hands-free Control Unit	•	•	•	•
	Additional Heating	•	•	•	•
	Multifunction Display	•	•	•	•
	Rain/Brightness Sensor	•	•	•	•
	Bodywork Conversion Unit	•	•	•	•
	Pneumatic Suspension	•	•	•	•
	Anti-slip Mode Selector	•	•	•	•
	Battery Change Status Unit	•	•	•	•
	High Frequency Receiver	•	•	•	•
	Deflation Detection	•	•	•	•
	Display/Telematics	•	•	•	•
	CD Player	•	•	•	•
	· ·	_			•
	Radio	•	•	•	
	Alarm	•	•	•	•
	Engine Control Moduel	•	•	•	•
THWDED (DELVA)	1 . 1 1 D 1 0	_			
	Anti-lock Brake System	•	•	•	•
JUMPER (RELAY)	Control Panel	•	•	•	•
JUMPER (RELAY) JUMPER (RELAY)	·				

()	T	1_	T_	1_	T-
JUMPER (RELAY)	Parking Assistance Module	•	•	•	•
JUMPER (RELAY)	Additional Heating	•	•	•	•
NEMO	Auto Gearbox	•	•	•	•
NEMO	Anti-lock Brake System	•	•	•	•
NEMO	Airbag	•	•	•	•
NEMO	Control Panel	•	•	•	•
NEMO	Parking Assistance Module	•	•	•	•
SAXO	Engine Control Moduel	•	•	•	•
SAXO	Auto Gearbox	•	•	•	•
SAXO	Anti-lock Brake System	•	•	•	•
SAXO	Airbag	•	•	•	•
SAXO	Electric Key Reader	•	•	•	•
	· ·				
XSARA	Engine Control Moduel	•	•	•	•
XSARA	Auto Gearbox	•	•	•	•
XSARA	Anti-lock Brake System	•	•	•	•
XSARA	Airbag	•	•	•	•
XSARA	Control Panel	•	•	•	•
XSARA	Built-in System Interface	•	•	•	•
XSARA	Air Conditioning	•	•	•	•
XSARA	Parking Assistance Module	•	•	•	•
XSARA	Steering Wheel With Fixed Central Control	•	•	•	•
XSARA	Rain/Brightness Sensor	•	•	•	•
XSARA	Multifunction Display B	•	•	•	•
XSARA	Radio	•	•	•	•
					_
XSARA	CD Player	•	•	•	•
XSARA	Alarm	•	•	•	•
XSARA (PICASSO)	Engine Control Moduel	•	•	•	•
XSARA (PICASSO)	Auto Gearbox	•	•	•	•
XSARA (PICASSO)	Anti-lock Brake System	•	•	•	•
XSARA (PICASSO)	Airbag	•	•	•	•
XSARA (PICASSO)	Instrument Cluster	•	•	•	•
XSARA (PICASSO)	Built-in System Interface	•	•	•	•
XSARA (PICASSO)	Air Conditioning	•	•	•	•
XSARA (PICASSO)	Parking Assistance Module	•	•	•	•
XSARA (PICASSO)	Steering Wheel With Fixed Central Control	•	•	•	•
XSARA (PICASSO)	Rain/Brightness Sensor	-	•	•	•
		<del> </del>	•		1
XSARA (PICASSO)	Multifunction Display B	•	•	•	•
XSARA (PICASSO)	ADDGO 2	•	•	•	•
XSARA (PICASSO)	CD Player	•	•	•	•
XSARA (PICASSO)	Radio	•	•	•	•
XSARA (PICASSO)	Alarm	•	•	•	•
XSARA (PICASSO)	Engine Control Moduel	•	•	•	•
(CHINA) XSARA (PICASSO)	Auto Gearbox	•	•	•	•
(CHINA)	nuto dearbox				
XSARA (PICASSO)	Anti-lock Brake System	•	•	•	•
(CHINA) XSARA (PICASSO)	Airbag (AUTOLIV)	•	•	•	•
(CHINA)	hiibag (holobiv)				
XSARA (PICASSO)	Control Panel	•	•	•	•
(CHINA) XSARA (PICASSO)	Air Conditioning	•	•	•	•
(CHINA)	All Collectioning				
XSARA (PICASSO)	Parking Assistance Module	•	•	•	•
(CHINA) XSARA (PICASSO)	Steering Wheel With Fixed Central Control	•	•	•	•
(CHINA)	eccelling anger aren tiven central confitor				
XSARA (PICASSO)	Rain/Brightness Sensor	•	•	•	•
(CHINA) XSARA (PICASSO)	Multifunction Display B	•	•	•	•
(CHINA)	materiunceron propray D				
XSARA (PICASSO)	ADDGO 2	•	•	•	•
				•	•
(CHINA) XSARA (PICASSO)	CD Player	•	•	•	•

XSARA (PICASSO) (CHINA)	Radio	•	•	•	•
XANTIA	Engine Control Moduel	•	•	•	•
XANTIA	Airbag	•	•	•	•
XANTIA	Airbag (Left)	•	•	•	•
XANTIA	CPH_TEXTON	•	•	•	•
XANTIA	TEVES_MK20E	•	•	•	•
XM	Engine Control Moduel	•	•	•	•
XM	Anti-lock Brake System	•	•	•	•
ZX	Engine Control Moduel	•	•	•	•
ZX	Auto Gearbox	•	•	•	•

#### Compatibilité Citroën - Système EPB

• : Compatible

\* : Peut être compatible en fonction de l'état du véhicule

o: N'est pas compatible

Vehicle	EPB
C4	•
C4 (PICASSO)	•
C4 (SEDAN)	•
C4L	•
C5 (X7)	•
C6	•
DS4	•
DS 5LS	•
DS6	•

#### Compatibilité Citroën - Système ETC

• : Compatible

\* : Peut être compatible en fonction de l'état du véhicule

o: N'est pas compatible

Vehicle	ETC
BERLINGO	•
C1	•
C2	•
C3	•
C4	•
C5	•
C6	•
C8	•
C-ELYSEE	•
C-QUATRE	•
C-TRIOMPHE	•
DS3	•
DS4	•
DS5	•
DS 5LS	•
DS6	•
ELYSEE	•
EVASION (SYNERGIE)	•
FUKANG	•
JUMPY (DISPATCH)	•
JUMPER (RELAY)	•
SAXO	•
XSARA	•
ZX	•

#### Compatibilité Citroën - Système FAP

• : Compatible

\* : Peut être compatible en fonction de l'état du véhicule

o: N'est pas compatible

Vehicle	Chassis	DPF
BERLINGO B9	HDI_SID807	•
BERLINGO B9	HDI_SID807_BR2	•
C3 A51	EDC17C10	•
C3 A51	EDC17C10_BR2	•
C3 A51	HDI_SID807	•
C3 A51	HDI_SID807_BR2	•
C3	EDC16C34_DV6	•
C3 R	EDC16C34_DV6	•
C3 PICASSO (A58)	EDC17C10	•
C3 PICASSO (A58)	HDI_SID807	•
C3 PICASSO (A58)	HDI_SID807_BR2	•
C4	HDI_SID803	•
C4	EDC16C3	•
C4	HDI_SID803A	•
C4	DCM34	•
C4	DCM35	•
C4	HDI SID807 BR2	•
C4 (B7)	DCM35_BR2	•
C4 (B7)	HDI_SID807_BR2	•
C4 (B7)	EDC17C10_BR2	•
C4 SEDAN	HDI_SID803	•
C4 SEDAN	EDC16C3	•
C4 SEDAN	HDI_SID803A	•
C4 SEDAN	DCM34	•
C4 SEDAN	DCM35	•
C4 SEDAN	HDI_SID807_BR2	•
C4 PICASSO	EDC16C3	•
C4 PICASSO	HDI_SID803A	•
C4 PICASSO	DCM34	•
C4 PICASSO	DCM35	•
C4 PICASSO	DCM35_BR2	•
C4 PICASSO	HDI_SID807	•
C4 PICASSO	HDI SID807 BR2	•
C4 PICASSO (B78)	DCM62	•
C4 PICASSO (B78)	HDI_SID807_BR2	•
C4 AIRCROSS	HDI_SID807_J3J4	•
C5 (X7)	HDI_SID201	•
C5 (X7)	EDC16CP39	•
C5 (X7)	DCM34	•
C5 (X7)	DCM34_P	•
C5 (X7)	DCM35	•
C5 (X7)	DCM35 BR2	•
C5 (X7)	EDC16C3	•
C5 (X7)	EDC17CP11	•
C5 (X7)	EDC17CP11	•
		•
C5 (X7)	HDI_SID807	

C5 (X7)	HDI_SID807_BR2	•
	EDC15C2	•
C5 R	EDC16CP39	•
C5 R	HDI_SID803A	•
	HDI_SID803	•
C6	EDC16CP39	•
C6	EDC17CP11	•
C6	HDI_SID201	•
C8 CAN	EDC15C2	•
C8 CAN	HDI_SID803A	•
C8 CAN	EDC16CP39	•
	DCM35	•
C8 CAN	DCM35_BR2	•
C8	EDC15C2	•
	EDC16CP39	•
C-CROSSER	EDC16CP39_E5	•
DS3	EDC17C10	•
DS3	EDC17C10_BR2	•
DS3	HDI_SID807	•
DS3	HDI_SID807_BR2	•
DS4	DCM35_BR2	•
DS4	EDC17C10_BR2	•
DS4	HDI_SID807_BR2	•
DS5	DCM35_BR2	•
DS5	HDI_SID807_BR2	•
DS5 Hybird 4	DCM35_HY	•
JUMPY 3	HDI_SID803A	•
JUMPY 3	DCM35	•
JUMPY 3	DCM35_BR2	•
JUMPER 3	EDC17CP52	•
JUMPER 3 MINIBUS	EDC17CP52	•
NEMO	HDI_8DF2	•

#### Compatibilité Citroën - Injections

• : Compatible

\* : Peut être compatible en fonction de l'état du véhicule

o : N'est pas compatible

Vehicle	Chassis	INJ
BERLINGO	EDC16C3	•
BERLINGO (B9)	EDC16C3	•
BERLINGO (B9)	EDC17C10_BR2	•
BERLINGO (B9)	HDI_SID807	•
C2	EDC16C3	•
C2 (CHINA)	EDC16C3	•
C3	EDC16C3	•
C3 (A51)	EDC17C10	•
C3 (A51)	EDC17C10_BR2	•
C3 (A51)	EDC16C3_DV4	•
C3 (A51)	HDI_SID807	•
C3 (A51)	HDI_SID807_BR2	•
C3 (NEW LOOK)	EDC16C3	•
C3 (PICASSO) (A58)	EDC17C10	•
C3 (PICASSO) (A58)	EDC17C10 BR2	•
C3 (PICASSO) (A58)	EDC16C3	•
C3 (PICASSO) (A58)	HDI_SID807	•
C3 (PICASSO) (A58)	HDI_SID807_BR2	•
C3 (PLURIEL)	EDC16C3	•
C4	DCM35	•
C4	DCM34	•
C4	EDC16C3	•
C4	HDI_SID807_BR2	•
C4 (B7)	DCM35_BR2	•
C4 (B7)	HDI_SID807_BR2	•
C4 (B7)	EDC17C10_BR2	•
C4 (PICASSO)	DCM35	•
C4 (PICASSO)	DCM35_BR2	•
C4 (PICASSO)	EDC16C3	•
C4 (PICASSO)	HDI_SID807	•
C4 (PICASSO)	DCM34	•
C4 (PICASSO)	HDI_SID807_BR2	•
C4 (PICASSO) (B78)	EDC17C10 BR2	•
C4 (SEDAN)	DCM35	•
C4 (SEDAN)	EDC16C3	•
C4 (SEDAN)	HDI_SID807_BR2	•
C4 (SEDAN)	DCM34	•
C5	EDC16C3	•
C5 (X7)	DCM34_P	•
C5 (X7)	DCM35	•
C5 (X7)	EDC16CP39	•
C5 (X7)	DCM34	•
C5 (X7)	DCM35_BR2	•
C5 (X7)	EDC16C3	•
C5 (X7)	EDC17CP11	•
C5 (X7)	HDI_SID807	•
CO (AI)	ומסמונ"בומוו	1

C5 (X7)	HDI_SID807_BR2	•
C6	EDC16CP39	•
C6	EDC17CP11	•
C6	EDC16C3	•
C8	EDC16C3	•
C8 (CAN)	EDC16CP39	•
C8 (CAN)	DCM35	•
C_ELYSEE	EDC16C3	•
C_ELYSEE	EDC17C10_BR2	•
DS3	EDC16C3	•
DS3	EDC17C10	•
DS3	EDC17C10_BR2	•
DS3	HDI_SID807	•
DS3	HDI_SID807_BR2	•
DS4	DCM35_BR2	•
DS4	EDC17C10_BR2	•
DS4	HDI_SID807_BR2	•
DS5	DCM35_BR2	•
DS5	HDI_SID807_BR2	•
ELYSEE	EDC16C3	•
FUKANG	EDC16C3	•
EVASION (SYNERGIE)	EDC16C3	•
JUMPER (RELAY)	EDC16C3	•
JUMPY 3	DCM35	•
JUMPY 3	DCM35_BR2	•
JUMPY 3	EDC16C3	•
JUMPY 3	EDC17C10_BR2	•
JUMPY (DISPATCH)	EDC16C3	•
SAX0	EDC16C3	•
XANTIA	EDC16C3	•
XSARA	EDC16C3	•
XSARA (PICASSO)	EDC16C3	•
XSARA (PICASSO) (CHINA)	EDC16C3	•
ZX	EDC16C3	•

#### Compatibilité Citroën - Entretiens / Vidanges

• : Compatible \* : Peut être compatible en fonction de l'état du véhicule

o : N'est pas compatible

Vehicle	OIL
BERLINGO	•
C2	•
C3	•
C4	•
C5	•
C6	•
C8	•
C-CROSSER	•
C-ELYSEE	•
C-QUATRE	•
C-TRIOMPHE	•
DS3	•
DS4	•
DS5	•
DS 5LS	•
DS6	•
EVASION (SYNERGIE)	•
JUMPY (DISPATCH)	•
JUMPER (RELAY)	•
NEMO	•
SAX0	•
XSARA	•
XANTIA	•

#### Compatibilité Citroën - Système SAS

• : Compatible

\* : Peut être compatible en fonction de l'état du véhicule

o: N'est pas compatible

Vehicle	SAS
BERLINGO	•
C-ZERO	•
C1	•
C2	•
C3	•
C4	•
C5	•
C6	•
C8	•
C-CROSSER	•
C-ELYSEE	•
C-QUATRE	•
C-TRIOMPHE	•
DS3	•
DS4	•
DS5	•
DS 5LS	•
DS6	•
ELYSEE	•
FUKANG	•
JUMPY (DISPATCH)	•
JUMPER (RELAY)	•
NEMO	•
SAXO	•
XSARA	•