COMPATIBILITE

CR PRO

POUR PEUGEOT

iCarsoft France

Compatibilité Peugeot - Batterie

● : Compatible
 * : Peut être compatible en fonction de l'état du véhicule
 ○ : N'est pas compatible
 ▲: Nouvelle compatibilité sur ce modèle

Vehicle	BMS
207	
208	•
308	•
308 (T9)	•
308 (S)	•
407	•
408 (T73)	•
408 (T93)	•
508	•
2008	•
3008	•
5008	•
RCZ	•
EXPERT	•
PARTNER	•

Compatibilité Peugeot - Système BLD

• : Compatible

* : Peut être compatible en fonction de l'état du véhicule

• : N'est pas compatible

Vehicle	System Type	BLD
1007 (CAN)	ABSMK70_1	
1007 (CAN)	ESPMK60_0	
206 (+)	ABSMK70_1	
206 (+)	ESPMK60_0	
207 (CAN)	ABSMK70_1	
207 (CAN)	ESPMK60_0	•
207 (VAN)	ABSMK70_1	
207 (VAN)	ESPMK60_0	
207 (i)	ABSMK70_1	
207 (i)	ESPMK60_0	
207_ADD	ABSMK70_1	•
207_ADD	ESPMK60_0	•
2008	ABSMK100	
2008	ESPMK100	
208	ABSMK100	
208	ESPMK100	
3008	ESP8. 1	•
3008 (Hybrid 4)	ESP8. 1	•
3008 (CHINA)	ESP8. 1	
301	ABSMK100	
301	ESPMK100	
307 (CAN)	ABS81	
307 (CAN)	ABS8_BOSCH	
307 (CAN)	ESP8_BOSCH	
307 (CAN)	ESP8. 1	
308	ABS81	
308	ESP8. 1	
308 (4 Portes)	ABS81	
308 (4 Portes)	ESP8. 1	•
407	ESP8. 1	
407	ESP_EBC_44	
408	ABS81	•
408	ESP8. 1	•
5008	ESP8. 1	•
508	ABS81	•
508	ESP8. 1	•
508 (Hybrid 4)	ABS81	•
508 (Hybrid 4)	ESP8. 1	•
508 (RHX)	ABS81	•
508 (RHX)	ESP8. 1	•
807 (CAN)	ESP8_BOSCH	•
807_CAN	ESP8_BOSCH	•
807_CAN	ESP8. 1	•
EXPERT 2	ABS81	•
EXPERT 2	ABS8_BOSCH	•
EXPERT 2	ESP8. 1	•

EXPERT 3	ABS81	•
EXPERT 3	ABS8_BOSCH	•
EXPERT 3	ESP8. 1	•
EXPERT 3	ESP8_BOSCH	•
HOGGAR	ABSMK70_1	•
HOGGAR	ESPMK60_0	•
PARTNER (B9)	ABS81	•
PARTNER (B9)	ESP8. 1	•
RCZ	ABS81	•
RCZ	ESP8. 1	•

Compatibilité Peugeot - Diagnostic

● : Compatible * : Peut être compatible en fonction de l'état du véhicule ○ : N'est pas compatible ▲: Nouvelle compatibilité sur ce modèle

Vehicle	System Name	EcuInfo.	Read	Erase	LiveData
106	Engine Control Moduel	•	Codes	Codes	•
106	Additional Heating	•	•	•	•
107	Engine Control Moduel	•	•	•	•
107	Manual Gearbox (MMT)	•	•	•	•
107	ESP (BOSCH 8.0 C1)	•	•	•	•
107	Airbag	•	•	•	•
107	Electric Power Steering	•	•	•	•
107	Coded Anti Start	•	•	•	•
107		•	•	•	•
108	Engine Control Moduel		-	•	_
	Gearbox	•	•	-	•
108	ABS/ESP	•	•	•	•
108	Airbag	•	•	•	•
108	Instrument Panel	•	•	•	•
108	Air Conditioning	•	•	•	•
108	Electric Power Steering	•	•	•	•
108	Start/Stop Control	•	•	•	•
108	Engine Immobiliser\Hands Free Starting Access Electric Module	•	•	•	•
108	Multifunction Display	•	•	•	•
206	Engine Control Moduel	•	•	•	•
206	Auto Gearbox	•	•	•	•
206	Active Safety (ABS)	•	•	•	•
206	Airbag	•	•	•	•
206	Instrument Panel	•	•	•	•
206	Built-in System Interface (BSI)	•	•	•	•
206	Air Conditioning	•	•	•	•
206	Diesel Additive Function	•	•	•	•
206	Electric Power Steering	•	•	•	•
206	Steering Wheel Switching Module	•	•	•	•
206	Rain/Brightness Sensor	•	•	•	•
206	Driver School Module	•	•	•	•
206	Display/Telematics	•	•	•	•
206	Service Module	•	•	•	•
206	Multifunction Display	•	•	•	•
206	CD Player		•	-	
206	Alarm	•	•	•	•
206	Radio	•	•	•	•
200	Engine Control Moduel	•	•	•	•
207	Auto Gearbox	•	•	•	•
207	Active Safety (ABS)	•	•	•	•
207	• • •	•	•	•	•
207	Airbag			•	
	Instrument Panel	•	•		•
207	Built-in System Interface (BSI)	•	•	•	•
207	Air Conditioning	•	•	•	•
207	Engine Relay Unit	•	•	•	•
207	Trailer Relay Unit	•	•	•	•
207	Electric Power Steering	•	•	•	•
207	Steering Wheel Switching Module	•	•	•	•
207	Parking Assistance Module	•	•	•	•
207	Rain/Brightness Sensor	•	•	•	\bullet

207	Battery Charge Status Unit	•	•	•	•
207	Service Module	•	•	•	•
207	Hands Free Control Unit	•	•	•	•
207	Display/Telematics	•	•	•	•
207	Not Fastened Warning Light (TNB)	•	•	•	•
207	Multiplexed Additive Adding Pump	•	•	•	•
207	High Frequency Receiver	•	•	•	•
207	Under Inflation Detection	•	•	•	•
207	Driver School Module	•	•	•	•
207	Directional Headlamps	•	•	•	•
207	Stolen Vehicle Location Control Unit	•	•	•	•
207	Folding Roof	•	•	•	•
207	Multifunction Display	•	•	•	•
207	CD Player	•	•	•	•
	;	•	•	•	•
207 207	Alarm	•	-	-	-
	Radio	-	•	•	•
208	Engine Control Moduel	•	•	•	•
208	Auto Gearbox	•	•	•	•
208	Active Safety (ABS)	•	•	•	•
208	Airbag	•	•	•	•
208	Instrument Panel	•	•	•	•
208	Built-in System Interface (BSI)	•	•	•	•
208	Air Conditioning	•	•	•	•
208	Trailer Relay Unit	•	•	•	•
208	Lighting Relay Unit	•	•	•	•
208	Electric Power Steering	•	•	•	•
208	Steering Wheel Switching Module	•	•	•	•
208	Steering Wheel With Fixed Central Control	•	•	•	•
208	Parking Assistance Module	•	•	•	•
208	Multiplexed Additive Adding Pump	•	•	•	•
208	Rain/Brightness Sensor	•	•	•	•
208	Battery Charge Status Unit	•	•	•	•
208	Multiplexed Control Panel	•	•	•	•
208	Driver School Module	•	•	•	•
208	Independent Telematic Unit (BTA)	•	•	•	•
208	Matrix Screen Integral To The Instrument Panel	•	•	•	•
208	Telematic Unit	•	•	•	•
208	Siren	•	•	•	•
208	CD Player	•	•	•	•
208	Alarm	•	•	•	•
208	Audio Amplifier	•	•	•	•
208	Radio	•	•	•	•
208 (Ai91)	Engine Control Moduel	•	•	•	•
208 (Ai91)	Auto Gearbox	•	•	•	•
208 (Ai91)	Active Safety (ABS)	•	•	•	•
208 (Ai91)	Airbag	•	•	•	•
208 (Ai91)	Instrument Panel	•	•	•	•
208 (Ai91)	Built-in System Interface (BSI)	•	•	•	•
208 (Ai91)	Air Conditioning	•	•	•	•
208 (Ai91)	Electric Power Steering	•	•	•	•
208 (Ai91)	Steering Wheel Switching Module	•	•	•	•
208 (Ai91)	Steering Wheel With Fixed Central Control	•	•	•	•
208 (Ai91)	Parking Assistance Module	•	•	•	•
208 (Ai91)	Rain/Brightness Sensor	•	•	•	•
208 (Ai91)	Independent Telematic Unit	•	•	•	•
208 (A191) 208 (A191)	Multiplexed Control Panel	•	•	•	•
208 (A191) 208 (A191)	External CD Player	•	•	•	•
208 (A191) 208 (A191)	Telematic Unit	•	•	•	•
(III / I/	TOLOMOUTO ONTO	1 -	1-	17	-

208 (Ai91)	Siren			•	•
208 (Ai91)	Alarm	•	•	•	•
208 (Ai91)	Radio	•	•	•	•
301	Engine Control Moduel	•	•	•	•
301	Auto Gearbox	•	•	•	•
301	Active Safety (ABS)	•	•	•	•
301	Airbag	•	•	•	•
301	Instrument Panel	•	•	•	•
301	Trailer Relay Unit	•	•	•	•
301	Electric Power Steering	•	•	•	•
301		•	•	•	•
	Multiplexed Additive Adding Pump	•	•	•	•
301	Steering Wheel Switching Module		•	•	-
301	Parking Assistance Module	•			•
301	Multifunction Display	•	•	•	•
301	Siren	•	•	•	•
301	Radio	•	•	•	•
306	Engine Control Moduel	•	•	•	•
306	Auto Gearbox	•	•	•	•
306	ABS (BOSCH 5.3)	•	•	•	•
306	Airbag	•	•	•	•
307	Engine Control Moduel	•	•	•	•
307	Auto Gearbox	•	•	•	•
307	Active Safety (ABS)	•	•	•	•
307	Airbag	•	•	•	•
307	Instrument Panel	•	•	•	•
307	Built-in System Interface (BSI)	•	•	•	•
307	Air Conditioning	•	•	•	•
307	Engine Relay Unit	•	•	•	•
307	Trailer Relay Unit	•	•	•	•
307	Diesel Additive Function	•	•	•	•
307	Electric Power Steering	•	•	•	•
307	Steering Wheel Switching Module	•	•	•	•
307	Parking Assistance Module	•	•	•	•
307	Driver Door module	•	•	•	•
307	Passenger Door Module	•	•	•	•
307	Right Headlamp Beam Level Corrector	•	•	•	•
307	Left Headlamp Beam Level Corrector	•	•	•	•
307	Rain/Brightness Sensor	•	•	•	•
307	Driver School Module	•	•	•	•
307	Hands Free Control Unit	•	•	•	•
307	Multifunction Display	•	•	•	•
307	High Frequency Receiver	•	•	•	•
307	Service Module"	•	•	•	•
307	Under Inflation Detection	•	•	•	•
307	Telematic Unit	•	•	•	•
307	Sunroof	•	•	•	•
307	Folding Roof	•	•	•	•
307	CD Player	•	•	•	•
307	Alarm	•	•	•	•
307	Radio	•	•	•	•
307	Engine Control Moduel	•	•	•	•
	-	•	•	•	•
308	Auto Gearbox				
308	Active Safety (ABS)	•	•	•	•
308	Airbag	•	•	•	•
308	Instrument Panel	•	•	•	•
308	Built-in System Interface (BSI)	•	•	•	•
308	Air Conditioning	•	•	•	•
308	Engine Relay Unit	•	•	•	•

308	Trailer Relay Unit	•	•	•	•
308	Electric Power Steering	•	•	•	•
308	Steering Wheel Switching Module	•	•	•	•
308	Parking Assistance Module	•	•	•	•
308	Multiplexed Additive Adding Pump	•	•	•	•
308	Driver Door Module	•	•	•	•
308	Driver Seat Memory Unit	•	•	•	•
308	Passenger Seat Memory Unit	•	•	•	•
308	Directional Headlamps	•	•	•	•
308	Hands Free Control Unit	•	•	•	•
308	Battery Charge Status Unit	•	•	•	•
308	Not Fastened Warning Light (TNB)	•	•	•	•
308	Rain/Brightness Sensor	•	•	•	•
308	Display/Telematics	•	•	•	•
308	Service Module"	•	•	•	•
		•	•	•	•
308	Multifunction Display	-	-	-	-
308	High Frequency Receiver	•	•	•	•
308	Lane Departure Warning System	•	•	•	•
308	Windscreen Wiper	•	•	•	•
308	Matrix Screen Integral To The Instrument Panel	•	•	•	•
308	Moving Panel Deflector	•	•	•	•
308	Under Inflation Detection	•	•	•	•
308	Driver School Module	•	•	•	•
308	Audio Amplifier	•	•	•	•
308	Electropump Assembly	•	•	•	•
308	Sunroof	•	•	•	•
308	Folding Roof	•	•	•	•
308	CD Player	•	•	•	•
308	Radio	•	•	•	•
308	Alarm	•	•	•	•
308 (T9)	Engine Control Moduel	•	•	•	•
308 (T9)	Auto Gearbox	•	•	•	•
308 (T9)	Active Safety (ABS)	•	•	•	•
308 (T9)	Vehicle Distance Assistance	•	•	•	•
308 (T9)	Airbag	•	•	•	•
308 (T9)	Instrument Panel	•	•	•	•
308 (T9)	Air Conditioning	•	•	•	•
308 (T9)	Engine Relay Unit	•	•	•	•
308 (T9)	Trailer Relay Unit	•	•	•	•
308 (T9)	Electric Power Steering	•	•	•	•
308 (T9)	Electric Steering Lock	•	•	•	•
308 (T9)	Steering Wheel Switching Module	•	•	•	•
308 (T9)	Parking Assistance Module	•	•	•	•
308 (T9)	Additional Heating	•	•	•	•
308 (T9)	Driver Door control panel	•	•	•	•
308 (T9)	Driver Seat Memory Unit	•	•	•	•
308 (T9) 308 (T9)	Seat Belts Not Fastened LED Unit	•	•	•	•
308 (T9) 308 (T9)	Directional Headlamps	•	•	•	•
	-	•	•	•	•
308 (T9)	Rain/Brightness Sensor				
308 (T9)	Hands Free Starting Access Electric Module	•	•	•	•
308 (T9)	Electric Key Reader	•	•	•	•
308 (T9)	Battery Charge Status Unit	•	•	•	•
308 (T9)	Voltage Retaining Device	•	•	•	•
308 (T9)	Matrix Screen Integral To The Instrument Panel	•	•	•	•
308 (T9)	Supply Protection And Management Unit	•	•	•	•
	Independent Telematic Unit (BTA)	•	•	•	•
308 (T9)					
308 (T9) 308 (T9) 308 (T9)	PADDGO INERGY Multifunction Display	•	•	•	•

308 (T9) Multiplexed Control Panel 308 (T9) External CD Player 308 (T9) Telematic Unit/Radio Navigation 308 (T9) Audio Amplifier	•	•	•	•
308 (T9) Telematic Unit/Radio Navigation	-	-		•
		•	•	•
	•	•	•	•
308 (T9) Touch Screen	•	•	•	•
308 (T9) Radio/Telephone	•	•	•	•
308 (T9) Alarm	•	•	•	•
308 (T9) Siren	•	•	•	•
308 (T9) Radio	•	•	•	•
308 (19) Raulo 308 (S) Engine Control Moduel	•	•	•	•
308 (S) Auto Gearbox	•	•	•	•
308 (S) Active Safety (ABS)	•	•	•	•
308 (S) Airbag	•	•	•	•
308 (S) Instrument Panel	•	•	•	•
308 (S) Built-in System Interface (BSI)	•	•	•	•
308 (S) Air Conditioning	•	•	•	•
308 (S) Engine Relay Unit	•	•	•	•
308 (S) Electric Power Steering	•	•	•	•
308 (S) Electric Steering Lock	•	•	•	•
308 (S) Steering Wheel Switching Module	•	•	•	•
308 (S) Parking Assistance Module	•	•	•	•
308 (S) Driver Seat Memory Unit	•	•	•	•
308 (S) Directional Headlamps	•	•	•	•
308 (S) Battery Charge Status Unit	•	•	•	•
308 (S) Voltage Retaining Device	•	•	•	•
308 (S) Hands Free Starting Access Electric Module	•	•	•	•
308 (S) Electric Key Reader	•	•	•	•
308 (S) Supply Protection And Management Unit	•	•	•	•
308 (S) Rain/Brightness Sensor	•	•	•	•
308 (S) Matrix Screen Integral To The Instrument Panel	•	•	•	•
308 (S) Multiplexed Control Panel	•	•	•	•
308 (S) Multifunction Display	•	•	•	•
308 (S) Touch Screen	•	•	•	•
308 (S) Telematic Unit	•	•	•	•
308 (S) Radio/Telephone	•	•	•	•
308 (S) Service Module	•	•	•	•
308 (S) Alarm	•	•	•	•
308 (S) Radio	•	•	•	•
405 Engine Control Moduel	•	•	•	•
406 Engine Control Moduel	•	•	•	•
406 Auto Gearbox	•	•	•	•
406 Active Safety (ABS)	•	•	•	•
406 Airbag	•	•	•	•
406 Instrument Panel	•	•	•	•
406 Built-in System Interface (BSI)	•	•	•	•
406 Air Conditioning	•	•	•	•
406 Diesel Additive Function	•	•	•	•
406 Steering Wheel Switching Module	•	•	•	•
406 Steering wheel Switching Module 406 Rain/Brightness Sensor	•	•	•	•
406 Multifunction Display	•	•	•	•
406 CD Player	•	•	•	•
406 Alarm	•	•	•	•
406 Radio	•	•	•	•
407 Engine Control Moduel	•	•	•	•
407 Auto Gearbox	•	•	•	•
407 Active Safety (ABS)	•	•	•	•
407 Airbag	•	•	•	•
407 Instrument Panel	•	•	•	•

407 407 407	Built-in System Interface (BSI) Air Conditioning	•	•	•	•
	Air Conditioning				
407		-	•	•	•
	Engine Relay Unit	•	•	•	•
407	Trailer Relay Unit	•	•	•	•
407	Diesel Additive Function	•	•	•	•
407	Electronically Managed Suspension	•	•	•	•
407	Electric Power Steering	•	•	•	•
407	Steering Wheel Switching Module	•	•	•	•
407	Parking Assistance Module	•	•	•	•
407	Driver Door module	•	•	•	•
407	Passenger Door Module	•	•	•	•
407	Driver Seat Memory Unit	•	•	•	•
407	Passenger Seat Memory Unit	•	•	•	•
407	Right Headlamp Beam Level Corrector	•	•	•	•
407	Left Headlamp Beam Level Corrector	•	•	•	•
	Directional Headlamps	•		•	•
407	*	-	-	-	-
407	Rain/Brightness Sensor	•	•	•	•
407	Hands Free Control Unit	•	•	•	•
407	Battery Charge Status Unit	•	•	•	•
407	High Frequency Receiver	•	•	•	•
407	Under Inflation Detection	•	•	•	•
407	Multifunction Display	•	•	•	•
407	Display/Telematics	•	•	•	•
407	Sunroof	•	•	•	•
407	Windscreen Wiper	•	•	•	•
407	Additional Heating	•	•	•	•
407	Boot Wiring	•	•	•	•
407	CD Player	•	•	•	•
407	Alarm	•	•	•	•
407	Radio	•	•	•	•
408 (T73)	Engine Control Moduel	•	•	•	•
408 (T73)	Auto Gearbox	•	•	•	•
408 (T73)	Active Safety (ABS)	•	•	•	•
408 (173) 408 (T73)		•		•	•
	Airbag	_	-	-	_
408 (T73)	Instrument Panel	•	•	•	•
408 (T73)	Built-in System Interface (BSI)	•	•	•	•
408 (T73)	Air Conditioning	•	•	•	•
408 (T73)	Engine Relay Unit	•	•	•	•
408 (T73)	Trailer Relay Unit	•	•	•	•
408 (T73)	Electric Power Steering	•	•	•	•
408 (T73)	Steering Wheel Switching Module	•	•	•	•
408 (T73)	Parking Assistance Module	•	•	•	•
408 (T73)	Driver Door Module	•	•	•	•
408 (T73)	Driver Seat Memory Unit	•	•	•	•
408 (T73)	Passenger Seat Memory Unit	•	•	•	•
408 (T73)	Rain/Brightness Sensor	•	•	•	•
408 (T73)	Display/Telematics	•	•	•	•
408 (T73)	Multiplexed Additive Adding Pump	•	•	•	•
408 (T73)	Hands Free Control Unit	•	•	•	•
408 (T73)	Service Module"	•	•	•	•
408 (173) 408 (173)	Battery Charge Status Unit	•	•	•	•
408 (T73) 408 (T73)					•
	Multifunction Display	•	•	•	
408 (T73)	Not Fastened Warning Light (TNB)	•	•	•	•
408 (T73)	High Frequency Receiver	•	•	•	•
408 (T73)	Lane Departure Warning System	•	•	•	•
408 (T73)	Matrix Screen Integral To The Instrument Panel	•	•	•	•
408 (T73)	Moving Panel Deflector	•	•	•	•

408 (T73)	Driver School Module	•	•	•	•
408 (T73)	Directional Headlamps	•	•	•	•
408 (T73)	Windscreen Wiper	•	•	•	•
408 (T73)	Sunroof	•	•	•	•
408 (T73) 408 (T73)	Folding Roof	•	•	•	•
408 (T73) 408 (T73)	CD Player	•	•	•	•
408 (173) 408 (T73)	Radio	•	•	•	•
			•	•	•
408 (T73)	Audio Amplifier	•	-	-	-
408 (T73)	Alarm	•	•	•	•
408 (T73)	Alarm	•	•	•	•
408 (T93)	Engine Control Moduel	•	•	•	•
408 (T93)	Auto Gearbox	•	•	•	•
408 (T93)	Active Safety (ABS)	•	•	•	•
408 (T93)	Airbag	•	•	•	•
408 (T93)	Instrument Panel	•	•	•	•
408 (T93)	Air Conditioning	•	•	•	•
408 (T93)	Engine Relay Unit	•	•	•	•
408 (T93)	Electric Power Steering	•	•	•	•
408 (T93)	Electric Steering Lock	•	•	•	•
408 (T93)	Steering Wheel Switching Module	•	•	•	•
408 (T93)	Parking Assistance Module	•	•	•	•
408 (T93)	Hands Free Starting Access Electric Module	•	•	•	•
408 (T93)	Electric Key Reader	•	•	•	•
408 (T93)	Battery Charge Status Unit	•	•	•	•
408 (T93)	Voltage Retaining Device	•	•	•	•
408 (T93)	Driver Seat Memory Unit	•	•	•	•
408 (T93)	Directional Headlamps	•	•	•	•
408 (T93)	Rain/Brightness Sensor	•	•	•	•
408 (T93)	Independent Telematic Unit (BTA)	•	•	•	•
408 (T93)	Matrix Screen Integral To The Instrument Panel	•	•	•	•
408 (T93)	Multifunction Display	•	•	•	•
408 (T93)	Supply Protection And Management Unit	•	•	•	•
408 (T93)	Telematic Unit/Radio Navigation	•	•	•	•
408 (T93)	Multiplexed Control Panel	•	•	•	•
408 (T93)	Touch Screen	•	•	•	•
408 (T93)	Radio/Telephone	•	•	•	•
408 (T93)	Alarm	•	•	•	•
408 (T93)	Radio	•	•	•	•
508	Engine Control Moduel	•	•	•	•
508	Auto Gearbox	•	•	•	•
508	Active Safety (ABS)	•	•	•	•
508	Electric Secondary Brake	•	•	•	•
508	Airbag	•	•	•	•
508	Instrument Panel	•	•	•	•
508	Built-in System Interface (BSI)	•	•	•	•
508	Air Conditioning	•	•	•	•
508	Rear Air Conditioning	•	•	•	•
508	Engine Relay Unit	•	•	•	•
508	Trailer Relay Unit	•	•	•	•
508	Electric Power Steering	•	•	•	•
508	Steering Wheel Switching Module	•	•	•	•
508	Steering Wheel With Fixed Central Control	•	•	•	•
508	Electric Steering Lock	•	•	•	•
508	Parking Assistance Module	•	•	•	•
508	Driver Door control panel	•	•	•	•
	Driver Seat Memory Unit	•	•	•	•
508	Main Beams Assistant	•	•	•	•
508	Seat Belts Not Fastened LED Unit	•	•	•	•
	Sear Derts NUT Fastened LED UNIT	-	- -	-	

508	Active Damper Electronic Unit	•	•	•	•
508	Traction Battery	•	•	•	•
508	Battery Charge Status Unit	•	•	•	•
508	Rain/Brightness Sensor (CDPL)	•	•	•	•
508	Hands Free Control Unit	•	•	•	•
508	Electric Key Reader	•	•	•	•
508	Matrix Screen Integral To The Instrument Panel	•	•	•	•
508	Multifunction Display	•	•	•	•
508	High Head Vision	•	•	•	•
508	Multiplexed Control Panel	•	•	•	•
508	Hybrid Control 1	•	•	•	•
508	Hybrid Control 2	•	•	•	•
508	Hybrid Mode Selector	•	•	•	•
508	Independent Telematic Unit (BTA)	•	•	•	•
508	Under Inflation Detection	•	•	•	•
508	Discharge Bulbs Vertical And Horizontal Adjustment	•	•	•	•
508	Additional Heating	•	•	•	•
508	Supply Protection And Management Unit	•	•	•	•
508	Windscreen Wiper (Right)	•	•	•	•
508	Windscreen Wiper (Left)	•	•	•	•
508	Telematic Navigator	•	•	•	•
508	Display/Telematics	•	•	•	•
508	Alarm	•	•	•	•
508	Audio Amplifier	•	•	•	•
508	Radio (RD5)	•	•	•	•
508	Motorised Boot	•	•	•	•
605	Engine Control Moduel	•	•	•	•
607	Engine Control Moduel	•	•	•	•
607	Auto Gearbox	•	•	•	•
607	Active Safety (ABS)	•	•	•	•
607	Airbag	•	•	•	•
607	Instrument Panel	•	•	•	•
607	Built-in System Interface (BSI)	•	•	•	•
607	Air Conditioning	•	•	•	•
607	Engine Relay Unit	•	•	•	•
607	Trailer Relay Unit	•	•	•	•
607	Diesel Additive Function	•	•	•	•
607	Electronically Managed Suspension	•	•	•	•
607	Electric Power Steering	•	•	•	•
607	Steering Wheel Switching Module	•	•	•	•
607	Parking Assistance Module	•	•	•	•
607	Driver Door control panel	•	•	•	•
607	Passenger Door Control Panel	•	•	•	•
607	Driver Seat Memory Unit	•	•	•	•
607	Driver Seat Memory Unit Headlamp Height Corrector	•	•	•	•
				•	
607	Hands Free Control Unit	•	•		•
607	Under Inflation Detection	•	•	•	•
607	Rain/Brightness Sensor	•	•	•	•
607	Storing Of The Driving Position	•	•	•	•
607	Multifunction Display	•	•	•	•
607	Telematic Unit	•	•	•	•
607	CD Player	•	•	•	•
607	Alarm	•	•	•	•
607	Radio	•	•	•	•
806	Engine Control Moduel	•	•	•	•
806	Auto Gearbox	•	•	•	•
806	Airbag	•	•	•	•
807	Engine Control Moduel	•	•	•	•
L	1	1	1	1	

AUTCriter Marter (ABS)OOOOBITArringInstrumet TanalIIIIBITInstrumet TanalIIIIIBITInstrumet TanalIIIIIBITInstrumet TanalIIIIIBITInstruction TanalIIIIIBITInstruction TananIIIIIBITInstruction TananIIIIIBITInstruction TananIIIIIBITStating MohlaIIIIIIBITStating Stating MohlaIIIIIIBITStating Stating MohlaII<	7 Au	uto Gearbox	•	•	•	•
207 Linkag 0 0 0 0 267 Latricent Fuel 0 0 0 0 267 Mill-16 System Interface (SN) 0 0 0 0 267 Hirel-Mattree Fuels 0 0 0 0 0 267 Hestric-Foor Storage (GD) 0 0 0 0 0 267 Electric-Foor Storage (GD) 0 0 0 0 0 267 Electric Toor Mohle 0 0 0 0 0 267 Reiner Mohle 0 0 0 0 0 267 Reiner Mohle 0 0 0 0 0 267 Reiner Mohle 0 0 0 0 0 267 Erding State Mohle 0 0 0 0 0 267 Erding State Mohle 0 0 0 0 0 267 Erding State Mohle 0 0 0 0 0 267 Erding Mohle 0 0 0 0 0 0 267 Erding Mohle 0 0 0 0 0 0						
807 Istrument Panel Image: Section of the section of			•	•	•	•
997 bilitis System Interface (0S1) • </td <td></td> <td></td> <td>•</td> <td>•</td> <td>•</td> <td>•</td>			•	•	•	•
807 Mr conditioning Image: Section of the section of			-		-	
Bran Additive Function Image: Secting OVER Image: Secting Research Rese			-	-	-	-
897 Rectric Power Steering (GEP) ● ● ● ● 897 Steering World Switching Model ● ● ● ● 897 Parking Assistance Model ● ● ● ● 897 Parking Assistance Model ● ● ● ● 897 Silding Sidonews Model ● ● ● ● 897 Silding Sidonews Model ● ● ● ● 897 Isht Bodiap Bean Level Corrector ● ● ● ● 897 Isht Bodiap Bean Level Corrector ● ● ● ● 897 Isht Bodiap Bean Level Corrector ● ● ● ● 897 Isht Bodian Bean Level Corrector ● ● ● ● 897 Isht Bodian Bean Level Corrector ● ● ● ● 897 Isht Bodian Bean Level Corrector ● ● ● ● 897 Ishter Facing Deviston ● ● ● ● 897 Ishter Facing Deviston ● ● ● ● 897 Ishter Facing Deviston ● ● ● ● 897 Ishter Facing<		-	-	-	-	-
977Steering Wheel Switching Wodale•••* <t< td=""><td></td><td></td><td></td><td></td><td>-</td><td></td></t<>					-	
977Parking Assistance Module●●● <td></td> <td></td> <td>-</td> <td>-</td> <td>-</td> <td>-</td>			-	-	-	-
807Priver Door Module••				-		-
B07Passenger Door ModuleImage: Constraint of the section of th		-	-	-	-	-
811 frig Side Boors Module807Driver Soat Memory Unit <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td></t<>						
807Briver Seat Memory Unit●●●●●●807807Kight Bedauge Bean Level Corrector●●●●●●807807Kight Bedauge Bean Level Corrector●●●●●●807807Kight Bedauge Control Unit●●●●●●●●●807●●● <td></td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td></td>		-	-	-	-	
807Laft Headlang Beam Level Corrector </td <td></td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>_</td>		-	-	-	-	_
807 Right Headlamp Beam Level Corrector ● ● ● 807 Warning Lights/Mometer unit ● ● ● 807 Telematic Receiver Control ● ● ● ● 807 Maditional Hearing ●					-	
807 Karning Lights/0dometer unit ● ● ● 807 Telematic Receiver Control ● ● ● 807 Madi tional Reating ● ● ● 807 Bands Free Control Duit ● ● ● ● 807 Binds Free Control Duit ●		-	-	-	-	-
807Telematic Receiver Control●●●●807Maltional Insting●●●●●807Bands Free Control Unit●● </td <td></td> <td></td> <td>-</td> <td>-</td> <td>-</td> <td>_</td>			-	-	-	_
807hditional leating••<			-		-	
807Inde Sree Control Unit•••<			-	-	-	_
807Storing Of The Driving Position•• <t< td=""><td></td><td>-</td><td>-</td><td>-</td><td></td><td></td></t<>		-	-	-		
807Inder Inflation Detection●●● <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
807Rain/Brightness Sensor<	7 S1	toring Of The Driving Position	•	•	•	•
807Rear Suncof </td <td>7 Ur</td> <td>nder Inflation Detection</td> <td>•</td> <td>•</td> <td>•</td> <td>•</td>	7 Ur	nder Inflation Detection	•	•	•	•
807Front Sunroof••	7 Ra	ain/Brightness Sensor	•	•	•	•
807Middle Sunroof●●●●807Multifunction Display●●● <td>7 Re</td> <td>ear Sunroof</td> <td>•</td> <td>•</td> <td>•</td> <td>•</td>	7 Re	ear Sunroof	•	•	•	•
807Multifunction Display••• <t< td=""><td>7 F1</td><td>ront Sunroof</td><td>•</td><td>•</td><td>•</td><td>•</td></t<>	7 F1	ront Sunroof	•	•	•	•
807Display/TelematicsImage: CD PlayerImage: CD Player	7 Mi	liddle Sunroof	•	•	•	•
807CD PlayerImage: CD Player	7 Mu	ultifunction Display	•	•	•	•
807Alarm••• <td>7 Di</td> <td>visplay/Telematics</td> <td>•</td> <td>•</td> <td>•</td> <td>•</td>	7 Di	visplay/Telematics	•	•	•	•
807RadioImage: Control ModuelImage: Control ModuelImage: Control Moduel1007Manual Gearbox (BVMP)Image: Control ModuelImage: Control ModuelImage: Control Moduel1007Active Safety (ABS)Image: Control ModuelImage: Control ModuelImage: Control Moduel1007Active Safety (ABS)Image: Control ModuelImage: Control ModuelImage: Control Moduel1007AirbagImage: Control ModuelImage: Control ModuelImage: Control ModuelImage: Control Moduel1007Electric Power SteeringImage: Control ModuelImage: Control ModuelImage: Control ModuelImage: Control Moduel1007Steering Wheel Switching ModuleImage: Control ModuelImage: Control ModuelImage: Control ModuelImage: Control Moduel1007Rain/Brightness SensorImage: Control UnitImage: Control ModuelImage: Control ModuelImage: Control Moduel1007Maltifuex Additive Adding PumpImage: Control ModuelImage: Control ModuelImage: Control ModuelImage: Control Moduel1007Maltifunction DisplayImage: Control ModuelImage: Control ModuelImage: Control ModuelImage: Control Moduel1007RadioImage: Control ModuelImage: Control ModuelImage: Control ModuelImage: Control Moduel1007RadioImage: Control ModuelImage: Control ModuelImage: Control ModuelImage: Control Moduel1007RadioImage: Control ModuelImage: Control ModuelImage: Control ModuelImage: Control Mo	7 CI	D Player	•	•	•	•
1007Engine Control Moduel•••<	7 A1	larm	•	•	•	•
1007Manual Gearbox (BVMP)•••<	7 Ra	adio	•	•	•	•
1007Active Safety (ABS)••• <th< td=""><td>D7 Er</td><td>ngine Control Moduel</td><td>•</td><td>•</td><td>•</td><td>•</td></th<>	D7 Er	ngine Control Moduel	•	•	•	•
1007Airbag•••<)7 Ma	anual Gearbox (BVMP)	•	•	•	•
1007Instrument Panel••<)7 Ac	ctive Safety (ABS)	•	•	•	•
1007Instrument Panel••<	07 Ai	irbag	•	•	•	•
1007Built-in System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)1007Air ConditioningImage: System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)1007Electric Power SteeringImage: System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)1007Steering Wheel Switching ModuleImage: System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)1007Sliding Side Doors ModuleImage: System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)Image: System Interface (BSI)1007Rain/Brightness SensorImage: System Interface (BSI)Image: System Interface (BSI) <td></td> <td></td> <td>•</td> <td>•</td> <td>•</td> <td>•</td>			•	•	•	•
1007Air Conditioning••<			•	•	•	•
1007Electric Power Steering••• <td></td> <td></td> <td>•</td> <td>•</td> <td>•</td> <td>•</td>			•	•	•	•
1007Steering Wheel Switching Module••<		-				
1007Parking Assistance Module••• </td <td></td> <td>-</td> <td></td> <td></td> <td></td> <td></td>		-				
1007Sliding Side Doors Module••• </td <td></td> <td></td> <td></td> <td></td> <td></td> <td>-</td>						-
1007Rain/Brightness Sensor•••		-			-	
1007Hands Free Control UnitImage: Second control UnitImage: Second control UnitImage: Second control Unit1007Multiplexed Additive Adding PumpImage: Second control UnitImage: Second control Unit<		-				
1007Multiplexed Additive Adding Pump●●●●●1007Under Inflation Detection●●●						
InterpretationInterp						
1007Multifunction Display•••<						
1007RadioImage: state of the state o						
1007CD PlayerImage: Second seco						
1007Telematic Unit•• <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
1007Alarm••• </td <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
2008Engine Control Moduel•••<						
2008Auto Gearbox••				•	•	•
2008Active Safety (ABS)•••••2008Airbag••••••	D8 Er	ngine Control Moduel	•	•	•	•
2008 Airbag • • • •			•	•	•	•
	Ac	ctive Safety (ABS)	•	•	•	•
2008 Instrument Panel	08 Ai	irbag	•	•	•	•
	II 80	nstrument Panel	•	•	•	•
2008 Air Conditioning • • • •	08 Ai	ir Conditioning	•	•	•	•
2008 Trailer Relay Unit • • • •)8 Tı	railer Relay Unit	•	•	•	•

0000					
2008	Electric Power Steering	•	•	•	•
2008	Steering Wheel Switching Module	•	•	•	•
2008	Steering Wheel With Fixed Central Control	•	•	•	•
2008	Parking Assistance Module	•	•	•	•
2008	Rain/Brightness Sensor	•	•	•	•
2008	Multiplexed Control Panel	•	•	•	•
2008	Battery Charge Status Unit	•	•	•	•
2008	Independent Telematic Unit (BTA)	•	•	•	•
2008	Matrix Screen Integral To The Instrument Panel	•	•	•	•
2008	Multiplexed Additive Adding Pump	•	•	•	•
2008	Siren	•	•	•	•
2008	Telematic Unit	•	•	•	•
2008	External CD Player	•	•	•	•
2008	Alarm	•	•	•	•
2008	Audio Amplifier	•	•	•	•
2008	Radio	•	•	•	•
3008	Engine Control Moduel	•	•	•	•
3008	Auto Gearbox	•	•	•	•
3008	Active Safety (ABS)	•	•	•	•
3008	Electric Secondary Brake	•	•	•	•
3008	Airbag	•	•	•	•
3008	Instrument Panel	•	•	•	•
3008	Built-in System Interface (BSI)	•	•	•	•
3008	Air Conditioning	•	•	•	•
3008	Engine Relay Unit	•	•	•	•
3008	Trailer Relay Unit	•	•	•	•
3008	Electric Power Steering	•	•	•	•
3008	Steering Wheel Switching Module	•	•	•	•
3008	Parking Assistance Module	•	•	•	•
3008	Driver Door control panel	•	•	•	•
3008	Not Fastened Warning Light (TNB)	•	•	•	•
3008	Headlamp Height Corrector	•	•	•	•
3008	Traction Battery	•	•	•	•
3008	Battery Charge Status Unit	•	•	•	•
3008	Hands Free Control Unit	•	•	•	•
3008	Rain/Brightness Sensor	•	•	•	•
3008	Display/Telematics	•	•	•	•
3008	Multiplexed Additive Adding Pump	•	•	•	•
		•	•		
3008 3008	Service Module	•	•	•	•
	Multifunction Display				
3008	High Head Vision	•	•	•	•
3008	Network Isolation Unit	•	•	•	•
3008	High Frequency Receiver	•	•	•	•
3008	Matrix Screen Integral To The Instrument Panel	•	•	•	•
3008	Under Inflation Detection	•	•	•	•
3008	Assistance In Complying With The Inter Vehicle Time	•	•	•	•
3008	Anti-slip Mode Selector	•	•	•	•
3008	Hybrid Control 1	•	•	•	•
3008	Hybrid Control 2	•	•	•	•
3008	Hybrid Mode Selector	•	•	•	•
3008	Windscreen Wiper	•	•	•	•
3008	CD Player	•	•	•	•
3008	Audio Amplifier	•	•	•	•
3008	Radio	•	•	•	•
3008	Alarm	•	•	•	•
4007	Engine Control Moduel	•	•	•	•
4007	Auto Gearbox	•	•	•	•
4007	ABS/ESP	•	•	•	•
	1	1	l	1	

4007	Airbag	•	•	•	
4007	Instrument Panel	•	•	•	•
4007	Built-in System Interface (BSI)	•	•	•	•
4007	Air Conditioning	•	•	•	•
4007	Steering Wheel Angle Sensor	•	•	•	•
4007	Gear Lever (DCT)	•	•	•	•
4007	4x4 Transmission	•	•	•	•
4007	Parking Assistance Module	•	•	•	•
4007	Coded Anti Start	•	•	•	•
4007	Rear Final Drive Piloted Clutch	•	•	•	•
4007	Hands Free Control Unit	•	•	•	•
4007	Static AFS	•	•	•	•
4007	Navigation	•	•	•	•
4007	Radio	•	•	•	•
4008	Auto Gearbox	•	•	•	•
4008	Airbag	•	•	•	•
4008	Instrument Panel	•	•	•	•
	Air Conditioning	•	•	•	•
4008	*	-	-	-	-
4008	Electric Power Steering	•	•	•	•
4008	Steering Wheel Angle Sensor	•	•	•	•
4008	Parking Assistance Module	•	•	•	•
4008	Hands Free Control Unit	•	•	•	•
4008	Rear Final Drive Piloted Clutch	•	•	•	•
4008	Starting Authorisation	•	•	•	•
4008	Start/Stop Control	•	•	•	•
4008	Radio/Telephone	•	•	•	•
4008	Navigation	•	•	•	•
5008	Engine Control Moduel	•	•	•	•
5008	Auto Gearbox	•	•	•	•
5008	Active Safety (ABS)	•	•	•	•
5008	Electric Parking Brake	•	•	•	•
5008	Electric Secondary Brake	•	•	•	•
5008	Airbag	•	•	•	•
5008	Instrument Panel	•	•	•	•
5008	Built-in System Interface (BSI)	•	•	•	•
5008	Air Conditioning	•	•	•	•
5008	Engine Relay Unit	•	•	•	•
5008	Trailer Relay Unit	•	•	•	•
5008	Electric Power Steering	•	•	•	•
5008	Steering Wheel Switching Module	•	•	•	•
5008	Parking Assistance Module	•	•	•	•
5008	Driver Door control panel	•	•	•	•
5008	Not Fastened Warning Light (TNB)	•	•	•	•
5008	Headlamp Height Corrector	•	•	•	•
5008	Battery Charge Status Unit	•	•	•	•
5008	Rain/Brightness Sensor	•	•	•	•
5008	Hands Free Control Unit	•	•	•	•
5008	Multiplexed Additive Adding Pump	•	•	•	•
5008	Service Module	•	•	•	•
5008	High Head Vision	•	•	•	•
5008	Network Isolation Unit	•	•	•	•
5008	High Frequency Receiver	•	•	•	•
5008	Control Panel Dot Matrix Display	•	•	•	•
5008	Under Inflation Detection	•	•	•	•
		-		-	
5008	Assistance In Complying With The Inter Vehicle Time	•	•	•	•
5008	Anti-slip Mode Selector	•	•	•	•
5008	Lane Departure Warning System	•	•	•	•
5008	Windscreen Wiper	•	•	•	•

5008	Portable Unit			•	
5008	Multifunction Display	•	•	•	•
5008	Display/Telematics	•	•	•	•
5008	CD Player	•	•	•	•
5008	Audio Amplifier	•	•	•	•
5008	Radio	•	•	•	•
5008	Alarm	•	•	•	•
5008	Steering Wheel With Fixed Central Control	•	•	•	•
5008	Multiplexed Control Panel	•	•	•	•
5008	Hybrid Mode Selector	•	•	•	•
5008	Independent Telematic Unit (BTA)	•	•	•	•
5008	Discharge Bulbs Vertical And Horizontal Adjustment	•	•	•	•
10N	Electric Vehicle Management	•	•	•	•
iON		•	•	•	•
	Electric Machine Management	-		-	-
iON	Active Safety (ABS)	•	•	•	•
iON	Airbag	•	•	•	•
iON	Instrument Panel	•	•	•	•
iON	Electric Power Steering	•	•	•	•
iON	Steering Wheel Angle Sensor	•	•	•	•
iON	Passenger Compartment Air Heanting Resistor	•	•	•	•
iON	Gateway Wiring Housing	•	•	•	•
iON	Onboard Charger Of The Traction Battery	•	•	•	•
iON	Independent Telematic Unit (BTA)	•	•	•	•
iON	Direct Voltage Transformer	•	•	•	•
iON	Traction Battery	•	•	•	•
iON	Traction Battery Cells Management 01	•	•	•	•
iON	Traction Battery Cells Management 02	•	•	•	•
iON	Traction Battery Cells Management 03	•	•	•	•
iON	Traction Battery Cells Management 04	•	•	•	•
iON	Traction Battery Cells Management 05	•	•	•	•
iON	Traction Battery Cells Management 07	•	•	•	•
iON	Traction Battery Cells Management 08	•	•	•	•
iON	Traction Battery Cells Management 09	•	•	•	•
iON	Traction Battery Cells Management 10	•	•	•	•
iON	Traction Battery Cells Management 11	•	•	•	•
iON	Radio	•	•	•	•
HOGGAR	Engine Control Moduel	•	•	•	•
HOGGAR	Auto Gearbox	•	•	•	•
HOGGAR	Active Safety (ABS)	•	•	•	•
HOGGAR	Airbag	•	•	•	•
HOGGAR	Instrument Panel	•	•	•	•
HOGGAR	Built-in System Interface (BSI)	•	•	•	•
HOGGAR	Air Conditioning	•	•	•	•
HOGGAR	Electric Power Steering	•	•	•	•
HOGGAR	Steering Wheel Switching Module	•	•	•	•
HOGGAR	Rain/Brightness Sensor	•	•	•	•
HOGGAR	Stolen Vehicle Location Control Unit	•	•	•	•
HOGGAR	Multifunction Display	•	•	•	•
HOGGAR	Service Module	•	•	•	•
HOGGAR	CD Player	•	•	•	•
HOGGAR	Radio	•	•	•	•
HOGGAR	Alarm	•	•	•	•
RCZ	Engine Control Moduel	•	•	•	•
RCZ	Auto Gearbox	•	•	•	•
RCZ	Active Safety (ABS)	•	•	•	•
RCZ	Airbag	•	•	•	•
RCZ	Instrument Panel		•	•	•
RCZ	Built-in System Interface (BSI)	•	•	•	•

RCZ	Air Conditioning	•	•	•	•
RCZ	Engine Relay Unit	•	•	•	•
RCZ	Trailer Relay Unit	•	•	•	•
RCZ	Electric Power Steering	•	•	•	•
RCZ	Steering Wheel Switching Module	•	•	•	•
RCZ	Parking Assistance Module	•	•	•	•
RCZ	Driver Door Module	•	•	•	•
RCZ	Driver Seat Memory Unit	•	•	•	•
RCZ	Passenger Seat Memory Unit	•	•	•	•
RCZ	Not Fastened Warning Light (TNB)	•	•	•	•
RCZ	Directional Headlamps	•	•	•	•
RCZ	Hands Free Control Unit	•	•	•	•
RCZ	Battery Charge Status Unit	•	•	•	•
RCZ	High Frequency Receiver	•	•	•	•
RCZ	Lane Departure Warning System	•	•	•	•
RCZ	Rain/Brightness Sensor	•	•	•	•
RCZ	Display/Telematics	•	•	•	•
RCZ	Multiplexed Additive Adding Pump	•	•	•	•
RCZ	· • ·	-		•	•
	Matrix Screen Integral To The Instrument Panel	•	•	-	-
RCZ	Service Module"	•	•	•	•
RCZ	Multifunction Display	•	•	•	•
RCZ	Moving Panel Deflector	•	•	•	•
RCZ	Under Inflation Detection	•	•	•	•
RCZ	Driver School Module	•	•	•	•
RCZ	Sunroof	•	•	•	•
RCZ	Folding Roof	•	•	•	•
RCZ	Windscreen Wiper	•	•	•	•
RCZ	CD Player	•	•	•	•
RCZ	Radio	•	•	•	•
RCZ	Alarm	•	•	•	•
RCZ	Alarm	•	•	•	•
RCZ	Audio Amplifier	•	•	•	•
BIPPER	Auto Gearbox	•	•	•	•
BIPPER	Active Safety (ABS)	•	•	•	•
BIPPER	Airbag	•	•	•	•
BIPPER	Instrument Panel	•	•	•	•
BIPPER	Parking Assistance Module	•	•	•	•
BOXER	Engine Control Moduel	•	•	•	•
BOXER	Auto Gearbox (4HP20)	•	•	•	•
BOXER	Active Safety (ABS)	•	•	•	•
		•	•	•	•
BOXER BOXER	Electric Power Steering Additional Heating	•	•	•	•
	-				-
BOXER	Tachograph	•	•	•	•
EXPERT	Engine Control Moduel	•	•	•	•
EXPERT	Auto Gearbox	•	•	•	•
EXPERT	Active Safety (ABS)	•	•	•	•
EXPERT	Airbag	•	•	•	•
EXPERT	Instrument Panel	•	•	•	•
EXPERT	Built-in System Interface (BSI)	•	•	•	•
EXPERT	Air Conditioning	•	•	•	•
EXPERT	Rear Air Conditioning	•	•	•	•
EXPERT	Engine Relay Unit	•	•	•	•
EXPERT	Trailer Relay Unit	•	•	•	•
EXPERT	Electric Power Steering	•	•	•	•
EXPERT	Steering Wheel Switching Module	•	•	•	•
EXPERT	Parking Assistance Module	•	•	•	•
EXPERT	Battery Charge Status Unit	•	•	•	•
EXPERT	Rain/Brightness Sensor	•	•	•	•
	1	1	1	1	

EXPERT	Additional Heating	•	•	•	•
	Additional Heating	•	-	•	-
EXPERT	Anti-slip Mode Selector Hands Free Control Unit	-	•	-	•
EXPERT		•	•	•	•
EXPERT	High Frequency Receiver	•	•	•	•
EXPERT	Pneumatic Suspension	•	•	•	•
EXPERT	Deflation Detection (DSG)	•	•	•	•
EXPERT	Bodywork Conversion Unit	•	•	•	•
EXPERT	Display/Telematics	•	•	•	•
EXPERT	Multifunction Display	•	•	•	•
EXPERT	CD Player	•	•	•	•
EXPERT	Radio	•	•	•	•
EXPERT	Alarm	•	•	•	•
PARTNER	Engine Control Moduel	•	•	•	•
PARTNER	Auto Gearbox	•	•	•	•
PARTNER	Active Safety (ABS)	•	•	•	•
PARTNER	Airbag	•	•	•	•
PARTNER	Instrument Panel	•	•	•	•
PARTNER	Built-in System Interface (BSI)	•	•	•	•
PARTNER	Air Conditioning	•	•	•	•
PARTNER	Air Conditioning	•	•	•	•
PARTNER	Engine Relay Unit	•	•	•	•
PARTNER	Trailer Relay Unit	•	•	•	•
PARTNER	Electric Power Steering	•	•	•	•
PARTNER	Steering Wheel Switching Module	•	•	•	•
PARTNER	Parking Assistance Module	•	•	•	•
PARTNER	Passenger Compartment Air Heanting Resistor	•	•	•	•
PARTNER	Hands Free Control Unit	•	•	•	•
PARTNER	Rain/Brightness Sensor	•	•	•	•
PARTNER	Onboard Charger Of The Traction Battery	•	•	•	•
PARTNER	Bodywork Conversion Unit	•	•	•	•
PARTNER	Electric Machine Management	•	•	•	•
PARTNER	High Frequency Receiver	•	•	•	•
PARTNER	Under Inflation Detection	•	•	•	•
PARTNER	Anti-slip Mode Selector	•	•	•	•
PARTNER	Additional Heating	•	•	•	•
PARTNER	Battery Charge Status Unit	•	•	•	•
PARTNER	Traction Battery Cells Management 01	•	•	•	•
PARTNER	Traction Battery Cells Management 02	•	•	•	•
PARTNER	Traction Battery Cells Management 03	•	•	•	•
PARTNER	Traction Battery Cells Management 04	•	•	•	•
PARTNER	Traction Battery Cells Management 05	•	•	•	•
PARTNER	Traction Battery Cells Management 07	•	•	•	•
PARTNER	Traction Battery Cells Management 08	•	•	•	•
PARTNER	Traction Battery Cells Management 09	•	•	•	•
PARTNER	Traction Battery Cells Management 10	•	•	•	•
PARTNER	Multifunction Display	•	•	•	•
PARTNER	Display/Telematics	•	•	•	•
PARTNER	Multiplexed Additive Adding Pump	•	•	•	•
PARTNER	Service Module"	•	•	•	•
	CD Player	•	•		•
PARTNER				•	
PARTNER	Alarm	•	•	•	•
PARTNER	Radio	•	•	•	•

Compatibilité Peugeot - Système EPB

 \bullet : Compatible

* : Peut être compatible en fonction de l'état du véhicule

• : N'est pas compatible

Vehicle	EPB
508	
3008	•
5008	•

Compatibilité Peugeot - Système ETC

• : Compatible

* : Peut être compatible en fonction de l'état du véhicule

• : N'est pas compatible

Vehicle	ETC
106	
107	
206	
207	
208	
301	•
306	•
307	•
308	•
405	•
406	•
407	•
408	•
508	•
607	•
806	•
807	•
1007	•
2008	•
3008	
5008	
HOGGAR	•
RCZ	
BOXER	•
EXPERT	•
PARTNER	•
1	

Compatibilité Peugeot - Système FAP

• : Compatible

* : Peut être compatible en fonction de l'état du véhicule

• : N'est pas compatible

Vehicle	Chassis	DPF
207 CAN	EDC16C3	•
207 CAN	HDI_SID807	•
207 CAN	EDC17C10	•
207 CAN	HDI_SID807_BR2	•
207 CAN	EDC17C10_BR2	•
207+	EDC16C3	•
207+	HDI_SID807	•
207+	EDC17C10	•
207+	HDI_SID807_BR2	•
207+	EDC17C10_BR2	•
208	EDC17C10_BR2	•
208	HDI_SID807_BR2	•
301	EDC17C10_BR2	•
306 R	EDC15C2	•
307 CAN	DCM34	•
307 CAN	EDC16C3	•
307 CAN	HDI_SID803	•
307 CAN	HDI_SID803A	•
307 VAN	EDC16C3	•
307 VAN	HDI_SID803	•
308 (T9)	HDI_SID807_BR2	•
308 (T9)	EDC17C10_BR2	•
308	DCM34	•
308	DCM35	•
308	DCM35_BR2	•
308	EDC16C3	•
308	HDI_SID807	•
308	EDC17C10_BR2	•
308	EDC17C10	•
308	HDI_SID807_BR2	•
308 (4 portes)	DCM34	•
308 (4 portes)	DCM35	•
308 (4 portes)	DCM35_BR2	•
308 (4 portes)	EDC16C3	•
308 (4 portes)	HDI_SID807	•
308 (4 portes)	EDC17C10_BR2	•
308 (4 portes)	EDC17C10	•
308 (4 portes)	HDI_SID807_BR2	•
406 R	EDC15C2	•
406 R Coupe	EDC15C2	•
407	HDI_SID803	•
407	EDC16C3	•
407	HDI_SID803A	•
407	DCM34	•
407	DCM35	•
407	DCM35_BR2	•

407	EDC16CP39	•
407 407	EDC17CP11	•
407	HDI_SID201	•
408	DCM34	•
408	DCM35	•
408	EDC16C3	•
408	HDI_SID807	•
408	EDC17C10	•
408	EDC17C10_BR2	•
408	HDI_SID807_BR2	•
408	DCM35_BR2	•
508	DCM62	•
508	DCM34_P	•
508	DCM35_BR2	•
508	HDI_SID807_BR2	•
508	EDC17CP42	•
508 HYbrid4	DCM35_HY	•
508 RHX HYbrid4	DCM35_HY	•
607 R	HDI_SID201	•
607 R	EDC16CP39	•
607 R	HDI_SID803A	•
807 CAN	EDC15C2	•
807 CAN	HDI_SID803A	•
807 CAN	EDC16CP39	•
807 CAN	DCM35	•
807 CAN	DCM35_BR2	•
1007 CAN	EDC16C3	•
2008	EDC17C10_BR2	•
2008	HDI_SID807_BR2	•
3008	DCM62	•
3008	EDC16C3	•
3008	DCM35	•
3008	DCM35_BR2	•
3008	HDI_SID807	•
3008	HDI_SID807_BR2	•
3008	DCM35_HY	•
3008 China	EDC16C3	•
3008 China	DCM35	•
3008 China	HDI_SID807	•
3008 China	HDI_SID807_BR2	
3008 China	DCM35_BR2	
3008 China	DCM35_HY	•
3008 HYbrid4	DCM35_HY	•
3008 HYbrid4	HDI_SID807_BR2	•
4007	EDC16CP39	•
4007	EDC16CP39_E5	•
4008 5008	HDI_SID807_J3J4	•
5008	DCM62	•
5008	EDC16C3 DCM35	•
5008	DCM35 DCM35_BR2	•
5008	HDI_SID807	•
		•
		•
5008 5008	HDI_SID807_BR2 DCM35_HY	•

RCZ	DCM34	•
RCZ	DCM35	•
RCZ	DCM35_BR2	•
RCZ	EDC16C3	•
RCZ	HDI_SID807	•
RCZ	EDC17C10	•
RCZ	HDI_SID807_BR2	•
RCZ	EDC17C10_BR2	•
BOXER 3	EDC17CP52	•
BOXER 3 MiniBus	EDC17CP52	•
EXPERT 3	EDC16C3	•
EXPERT 3	EDC17C10_BR2	•
EXPERT 3	HDI_SID803A	•
EXPERT 3	DCM35	•
EXPERT 3	DCM35_BR2	•
EXPERT 2	HDI_SID803A	•
EXPERT 2	DCM35	•
EXPERT 2	DCM35_BR2	•
PARTNER B9	EDC16C3	•
PARTNER B9	EDC17C10_BR2	•
PARTNER B9	HDI_SID807	•
PARTNER B9	HDI_SID807_BR2	•

Compatibilité Peugeot - Injections

• : Compatible

* : Peut être compatible en fonction de l'état du véhicule

N'est pas compatible

Vehicle	Chassis	INJ
1007 (CAN)	EDC16C3	•
1007 (VAN)	EDC16C3	•
2008	EDC17C10_BR2	•
2008	HDI_SID807_BR2	•
206	EDC16C3	•
206 (MUX)	EDC16C3	•
207 (+)	EDC16C3_DV4	•
207 (+)	HDI_SID807_BR2	•
207 (CAN)	EDC16C3	•
207 (CAN)	EDC16C3_DV4	•
207 (CAN)	EDC17C10	•
207 (CAN)	EDC17C10_BR2	•
207 (CAN)	HDI_SID807	•
207 (CAN)	HDI_SID807_BR2	•
208	EDC17C10_BR2	•
208	HDI_SID807_BR2	•
3008	DCM35	•
3008	DCM35_BR2	•
3008	DCM35_HY	•
3008	EDC16C3	•
3008	HDI_SID807	•
3008	HDI_SID807_BR2	•
3008 (CHINA)	DCM35_BR2	•
3008 (CHINA)	DCM35_HY	•
3008 (CHINA)	HDI_SID807_BR2	•
3008 (Hybrid 4)	DCM35_HY	•
3008 (Hybrid 4)	HDI_SID807_BR2	•
301	EDC17C10_BR2	•
307 (CAN)	DCM34	•
307 (CAN)	EDC16C3	•
307 (VAN)	EDC16C3	•
308	DCM34	•
308	DCM35	•
308	DCM35_BR2	•
308	EDC16C3	•
308	EDC17C10	•
308	EDC17C10_BR2	•
308	HDI_SID807	•
308	HDI_SID807_BR2	•
4007	EDC16CP39	•
407	DCM34	•
407	EDC16C3	•
407 (CAN)	DCM35	•
407 (CAN)	DCM35_BR2	•
407 (CAN)	EDC16CP39	•
407 (CAN)	EDC17CP11	•

408	DCM34	•
408	DCM35	•
408	DCM35_BR2	•
408	EDC17C10_BR2	•
408	HDI_SID807	•
408	HDI_SID807_BR2	•
5008	DCM35	•
5008	DCM35_BR2	•
5008	DCM35_HY	•
5008	EDC16C3	•
5008	HDI_SID807	•
5008	HDI_SID807_BR2	•
508	DCM34_P	•
508	DCM35_BR2	•
508	DCM35_HY	•
508	 EDC17CP42	•
508	HDI_SID807_BR2	•
508 (Hybrid 4)	 DCM34_P	•
508 (Hybrid 4)	DCM35_HY	•
508 (RHX)	DCM34_P	•
508 (RHX)	DCM35_HY	•
607 (CAN)	EDC16CP39	•
807 (CAN)	DCM35	•
807 (CAN)	DCM35_BR2	•
807 (CAN)	EDC16CP39	•
EXPERT 2	DCM35	•
EXPERT 2	DCM35_BR2	•
EXPERT 2	EDC16C3	•
EXPERT 3	DCM35_BR2	•
EXPERT 3	EDC17C10_BR2	•
PARTNER	EDC16C3	•
PARTNER B9	EDC16C3	•
PARTNER B9	EDC17C10_BR2	•
PARTNER B9	HDI_SID807	•
PARTNER B9	HDI_SID807_BR2	•
RCZ	DCM34	•
RCZ	DCM35	•
RCZ	DCM35_BR2	•
RCZ	EDC17C10_BR2	•
RCZ	HDI_SID807	•
RCZ	HDI_SID807_BR2	•

Compatibilité Peugeot - Entretiens / Vidanges

• : Compatible
 * : Peut être compatible en fonction de l'état du véhicule
 ○ : N'est pas compatible
 ▲ : Nouvelle compatibilité sur ce modèle

106 ● 107 ● 206 ● 207 ● 208 ● 301 ● 306 ● 307 ● 308 ● 406 ● 407 ● 508 ● 607 ● 806 ● 607 ● 806 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 809 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ●	Vehicle	OIL
206 ● 207 ● 208 ● 301 ● 306 ● 307 ● 308 ● 406 ● 407 ● 408 ● 508 ● 607 ● 608 ● 607 ● 806 ● 607 ● 808 ● 607 ● 806 ● 807 ● 806 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 809 ● 8007 ● 8008 ● 8009 ● 8009 ● 8009 ● 8008 ● 8008	106	
207 ● 208 ● 301 ● 306 ● 307 ● 308 ● 406 ● 407 ● 408 ● 508 ● 607 ● 806 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 809 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008	107	•
208 ● 301 ● 306 ● 307 ● 308 ● 406 ● 407 ● 408 ● 508 ● 607 ● 806 ● 807 ● 808 ● 807 ● 806 ● 807 ● 808 ● 807 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 807 ● 808 ● 9008 ● 9008 ● 9008 ● 9008 ● 9008 ● 9008 ● 9008 ● 9008 ● 9008	206	•
301 ● 306 ● 307 ● 308 ● 308 ● 406 ● 407 ● 408 ● 508 ● 607 ● 806 ● 807 ● 806 ● 807 ● 808 ● 807 ● 808 ● 807 ● 807 ● 807 ● 807 ● 807 ● 807 ● 807 ● 807 ● 807 ● 807 ● 908 ● 908 ● 908 ● 908 ● 908 ● 908 ● 908 ● 908 ● 908 ● 908 ●	207	•
306 ● 307 ● 308 ● 406 ● 407 ● 408 ● 508 ● 607 ● 806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 607 ● 806 ● 807 ● 808 ● 809 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ● 8008 ● 8007 ● 8008 ● 8007 ● 8007 ● 8007 ● 8007 ● 8007 ● 80028 ● 80028	208	•
307 ● 308 ● 406 ● 407 ● 408 ● 508 ● 607 ● 806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 607 ● 806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 10N ● 4006 ● 6008 ● 607 ● 808 ● 807 ● 807 ● 807 ● 807 ● 807 ● 800	301	•
308 ● 406 ● 407 ● 408 ● 508 ● 607 ● 806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 10N ● HOGGAR ● RCZ ● BIPPER ● BOXER ● EXPERT ●	306	•
406 ● 407 ● 408 ● 508 ● 607 ● 806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 10N ● HOGGAR ● RCZ ● BIPPER ● BOXER ● EXPERT ●	307	•
407 ● 408 ● 508 ● 607 ● 806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 100 ● 1003 ● 5008 ● 606 ● 5008 ● 100 ● BIPPER ● BOXER ● EXPERT ●	308	•
408 ● 508 ● 607 ● 806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 10N ● H0GGAR ● RCZ ● BIPPER ● BOXER ● EXPERT ●	406	•
508 ● 607 ● 806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 10N ● HOGGAR ● RCZ ● BIPPER ● BOXER ● EXPERT ●	407	•
607 ● 806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 10N ● HOGGAR ● RCZ ● BIPPER ● EXPERT ●	408	•
806 ● 807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 10N ● HOGGAR ● RCZ ● BIPPER ● EXPERT ●	508	•
807 ● 1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 10N ● HOGGAR ● RCZ ● BIPPER ● BOXER ● EXPERT ●	607	•
1007 ● 2008 ● 3008 ● 4007 ● 4008 ● 5008 ● 10N ● HOGGAR ● RCZ ● BIPPER ● BOXER ● EXPERT ●	806	•
2008 • 3008 • 4007 • 4008 • 5008 • i0N • HOGGAR • RCZ • BIPPER • BOXER • EXPERT •	807	•
3008 ● 4007 ● 4008 ● 5008 ● i0N ● HOGGAR ● RCZ ● BIPPER ● BOXER ● EXPERT ●	1007	•
4007 ● 4008 ● 5008 ● i0N ● HOGGAR ● RCZ ● BIPPER ● BOXER ● EXPERT ●	2008	•
4008•5008•i0N•HOGGAR•RCZ•BIPPER•BOXER•EXPERT•	3008	•
5008•iON•HOGGAR•RCZ•BIPPER•BOXER•EXPERT•	4007	•
iON•HOGGAR•RCZ•BIPPER•BOXER•EXPERT•	4008	•
HOGGAR•RCZ•BIPPER•BOXER•EXPERT•	5008	•
RCZ•BIPPER•BOXER•EXPERT•	iON	•
BIPPER BIPPER	HOGGAR	•
BOXER EXPERT	RCZ	•
EXPERT	BIPPER	•
	BOXER	•
PARTNER •	EXPERT	•
	PARTNER	•

Compatibilité Peugeot - Système SAS

• : Compatible

* : Peut être compatible en fonction de l'état du véhicule

• : N'est pas compatible

Vehicle	SAS
107	
206	
207	
208	•
301	•
307	•
308	•
407	•
408	•
508	•
607	•
807	•
1007	•
2008	•
3008	•
4007	•
4008	•
5008	•
iON	•
HOGGAR	•
RCZ	•
BIPPER	•
BOXER	•
EXPERT	•
PARTNER	•