

Renault_V01.25 Diag Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData
ALASKAN	ECM (Injection)	●	●	●	●
ALASKAN	TCM (Transmission Control Module)	●	●	●	●
ALASKAN	ABS (Antilock Brake System)	●	●	●	●
ALASKAN	SRS (Airbag/Pretensioners)	●	●	●	●
ALASKAN	IP (Instrument Panel)	●	●	●	●
ALASKAN	UCH	●	●	●	●
ALASKAN	4WD (4 Wheels Drive)	●	●	●	●
ALASKAN	UPC	●	●	●	●
ALASKAN	Parking Prox CAN	●	●	●	●
ALASKAN	AC (Air Conditioning)	●	●	●	●
ALASKAN	Distance Regulator	●	●	●	●
AVANTIME	ECM (Injection)	●	●	●	●
AVANTIME	TCM (Transmission Control Module)	●	●	●	●
AVANTIME	ABS (Antilock Brake System)	●	●	●	●
AVANTIME	SRS (Airbag/Pretensioners)	●	●	●	●
AVANTIME	Interconnection Unit	●	●	●	●
AVANTIME	Engine Immobiliser	●	●	●	●
CAPTUR	ECM (Injection)	●	●	●	●
CAPTUR	TCM (Transmission Control Module)	●	●	●	●
CAPTUR	ABS (Antilock Brake System)	●	●	●	●
CAPTUR	SRS (Airbag/Pretensioners)	●	●	●	●
CAPTUR	IP (Instrument Panel)	●	●	●	●
CAPTUR	UCH	●	●	●	●
CAPTUR	Communications Unit	●	●	●	●
CAPTUR	Variable P.A.S	●	●	●	●
CAPTUR	Parking Prox CAN	●	●	●	●
CAPTUR	UPC	●	●	●	●
CAPTUR	AC (Air Conditioning)	●	●	●	○
CAPTUR	Telematic Control Unit	●	●	●	●
CAPTUR	Radio	●	●	●	●
CAPTUR	Multimedia Interface	●	●	●	●
CAPTUR	Hands Free Kit	●	●	●	●
CLIO 2	ECM (Injection)	●	●	●	●
CLIO 2	TCM (Transmission Control Module)	●	●	●	●
CLIO 2	ABS (Antilock Brake System)	●	●	●	●
CLIO 2	SRS (Airbag/Pretensioners)	●	●	●	●
CLIO 2	Gasoline ECM (Injection)	●	●	●	●
CLIO 2	Interconnection Unit	●	●	●	●
CLIO 2	Engine Immobiliser	●	●	●	●
CLIO 2	AC (Air Conditioning)	●	●	●	●
CLIO II PH2/3/4	ECM (Injection)	●	●	●	●
CLIO II PH2/3/4	TCM (Transmission Control Module)	●	●	●	●
CLIO II PH2/3/4	ABS (Antilock Brake System)	●	●	●	●
CLIO II PH2/3/4	SRS (Airbag/Pretensioners)	●	●	●	●

CLIO II PH2/3/4	Gasoline ECM (Injection)	●	●	●	●
CLIO II PH2/3/4	Interconnection Unit	●	●	●	●
CLIO II PH2/3/4	Variable P.A.S	●	●	●	●
CLIO II PH2/3/4	Engine Immobiliser	●	●	●	●
CLIO II PH2/3/4	AC (Air Conditioning)	●	●	●	●
CLIO II PH2/3/4	Discharge Lamp	●	●	●	●
CLIO II PH6	ECM (Injection)	●	●	●	●
CLIO II PH6	SRS (Airbag/Pretensioners)	●	●	●	●
CLIO II PH6	UCH	●	●	●	●
CLIO II PH6	Tracker	●	●	●	●
CLIO III	ECM (Injection)	●	●	●	●
CLIO III	TCM (Transmission Control Module)	●	●	●	●
CLIO III	ABS (Antilock Brake System)	●	●	●	●
CLIO III	SRS (Airbag/Pretensioners)	●	●	●	●
CLIO III	IP (Instrument Panel)	●	●	●	●
CLIO III	UCH	●	●	●	●
CLIO III	Communications Unit	●	●	●	●
CLIO III	Variable P.A.S	●	●	●	●
CLIO III	UPC	●	●	●	●
CLIO III	TPMS (Tire Pressure Monitoring System)	●	●	●	●
CLIO III	AC (Air Conditioning)	●	●	●	●
CLIO III	Lighting	●	●	●	●
CLIO III	Radio	●	●	●	●
CLIO III	Multimedia Connection	●	●	●	●
CLIO III	Multimedia Interface	●	●	●	●
CLIO III	PAM (Parking Assistance)	●	●	●	●
CLIO IV	ECM (Injection)	●	●	●	●
CLIO IV	TCM (Transmission Control Module)	●	●	●	●
CLIO IV	ABS (Antilock Brake System)	●	●	●	●
CLIO IV	SRS (Airbag/Pretensioners)	●	●	●	●
CLIO IV	IP (Instrument Panel)	●	●	●	●
CLIO IV	UCH	●	●	●	●
CLIO IV	Communications Unit	●	●	●	●
CLIO IV	Variable P.A.S	●	●	●	●
CLIO IV	Parking Prox CAN	●	●	●	●
CLIO IV	UPC	●	●	●	●
CLIO IV	AC (Air Conditioning)	●	●	●	●
CLIO IV	Telematic Control Unit	●	●	●	●
CLIO IV	Radio	●	●	●	●
CLIO IV	Multimedia Interface	●	●	●	●
CLIO IV	Hands Free Kit	●	●	●	●
CLIO IV	Amplifier	●	●	●	●
CLIO V6	ECM (Injection)	●	●	●	●
CLIO V6 PH 2	ECM (Injection)	●	●	●	●
DOKKER	ECM (Injection)	●	●	●	●
DOKKER	ABS (Antilock Brake System)	●	●	●	●
DOKKER	SRS (Airbag/Pretensioners)	●	●	●	●
DOKKER	IP (Instrument Panel)	●	●	●	●
DOKKER	UCH	●	●	●	●
DOKKER	Variable P.A.S	●	●	●	●
DOKKER	Radio	●	●	●	●
DUSTER	ECM (Injection)	●	●	●	●
DUSTER	TCM (Transmission Control Module)	●	●	●	●
DUSTER	ABS (Antilock Brake System)	●	●	●	●
DUSTER	SRS (Airbag/Pretensioners)	●	○	●	●

DUSTER	UCH	●	●	●	●
DUSTER	4WD (4 Wheels Drive)	●	●	●	●
DUSTER	Variable P. A. S	●	●	●	●
DUSTER	Radio	●	●	●	●
DUSTER	Tracker	●	●	●	●
DUSTER PH2	ECM (Injection)	●	●	●	●
DUSTER PH2	ABS (Antilock Brake System)	●	●	●	●
DUSTER PH2	SRS (Airbag/Pretensioners)	●	●	●	●
DUSTER PH2	IP (Instrument Panel)	●	●	●	●
DUSTER PH2	UCH	●	●	●	●
DUSTER PH2	Variable P. A. S	●	●	●	●
DUSTER PH2	4WD (4 Wheels Drive)	●	●	●	●
DUSTER PH2	Radio	●	●	●	●
ESPACE	ECM (Injection)	●	●	●	●
ESPACE	TCM (Transmission Control Module)	●	●	●	●
ESPACE	ABS (Antilock Brake System)	●	●	●	●
ESPACE	SRS (Airbag/Pretensioners)	●	●	●	●
ESPACE	IP (Instrument Panel)	●	※	※	●
ESPACE	Interconnection Unit	●	●	●	●
ESPACE	Engine Immobiliser	●	●	●	●
ESPACE	AC (Air Conditioning)	●	●	●	●
ESPACE	Heater	●	●	●	●
ESPACE	Lighting	●	●	●	●
ESPACE IV	ECM (Injection)	●	●	●	●
ESPACE IV	TCM (Transmission Control Module)	●	●	●	●
ESPACE IV	ABS (Antilock Brake System)	●	●	●	●
ESPACE IV	SRS (Airbag/Pretensioners)	●	●	●	●
ESPACE IV	IP (Instrument Panel)	●	●	●	●
ESPACE IV	UCH	●	●	●	●
ESPACE IV	AC (Air Conditioning)	●	●	●	●
ESPACE IV	EPB (Parking Brake)	●	●	●	●
ESPACE IV	PAM (Parking Assistance)	●	●	●	●
ESPACE IV	Heater	●	●	●	●
ESPACE IV	Discharge Lamp	●	●	●	●
ESPACE IV	Radio	●	●	●	●
ESPACE IV	Hands Free Kit	●	●	●	●
ESPACE IV PH2	ECM (Injection)	●	●	●	●
ESPACE IV PH2	TCM (Transmission Control Module)	●	●	●	●
ESPACE IV PH2	ABS (Antilock Brake System)	●	●	●	●
ESPACE IV PH2	SRS (Airbag/Pretensioners)	●	●	●	●
ESPACE IV PH2	IP (Instrument Panel)	●	●	●	●
ESPACE IV PH2	UCH	●	●	●	●
ESPACE IV PH2	Communications Unit	●	●	●	●
ESPACE IV PH2	Variable P. A. S	●	●	●	●
ESPACE IV PH2	EPB (Parking Brake)	●	●	●	●
ESPACE IV PH2	Parking Prox CAN	●	●	●	●
ESPACE IV PH2	AC (Air Conditioning)	●	●	●	●
ESPACE IV PH2	PAM (Parking Assistance)	●	●	●	●
ESPACE IV PH2	Heater	●	●	●	●
ESPACE IV PH2	Lighting	●	●	●	●
ESPACE IV PH2	Radio	●	●	●	●
ESPACE IV PH2	Multimedia Interface	●	●	●	●
ESPACE IV PH2	Multimedia Connection	●	●	●	●
ESPACE V	ECM (Injection)	●	●	●	●
ESPACE V	TCM (Transmission Control Module)	●	●	●	●

ESPACE V	ABS (Antilock Brake System)	●	●	●	●
ESPACE V	SRS (Airbag/Pretensioners)	●	●	●	●
ESPACE V	IP (Instrument Panel)	●	●	●	●
ESPACE V	UCH	●	●	●	●
ESPACE V	4 Wheels Steering	●	●	●	●
ESPACE V	Variable P.A.S	●	●	●	●
ESPACE V	EPB (Parking Brake)	●	●	●	●
ESPACE V	Parking Prox CAN	●	●	●	●
ESPACE V	UPC	●	●	●	●
ESPACE V	AC (Air Conditioning)	●	●	●	●
ESPACE V	Seat Management	●	●	●	●
ESPACE V	Front Camera	●	●	●	●
ESPACE V	Radio	●	●	●	●
ESPACE V	Multimedia Interface	●	●	●	○
ESPACE V	Amplifier	●	●	●	●
ESPACE V	Telematic Control Unit	●	●	●	●
ESPACE V	Left-Hand Door	●	●	●	●
ESPACE V	Right-Hand Door	●	●	●	●
ESPACE V	Distance Regulator	●	●	●	●
ESPACE V	Power Back Door	●	●	●	●
ESPACE V	Piloted Suspension	●	●	●	●
KADJAR	ECM (Injection)	●	●	●	●
KADJAR	TCM (Transmission Control Module)	●	●	●	●
KADJAR	ABS (Antilock Brake System)	●	●	●	●
KADJAR	SRS (Airbag/Pretensioners)	●	●	●	●
KADJAR	IP (Instrument Panel)	●	●	●	●
KADJAR	UCH	●	●	●	●
KADJAR	4WD (4 Wheels Drive)	●	●	●	●
KADJAR	Variable P.A.S	●	●	●	●
KADJAR	EPB (Parking Brake)	●	●	●	●
KADJAR	Parking Prox CAN	●	●	●	●
KADJAR	UPC	●	●	●	●
KADJAR	AC (Air Conditioning)	●	●	●	●
KADJAR	Front Camera	●	●	●	●
KADJAR	Radio	●	●	●	●
KADJAR	Multimedia Interface	●	●	●	○
KADJAR	Amplifier	●	●	●	●
KADJAR	Telematic Control Unit	●	●	●	●
KADJAR	Distance Regulator	●	●	●	○
KADJAR CN	ECM (Injection)	●	●	●	●
KADJAR CN	TCM (Transmission Control Module)	●	●	●	●
KADJAR CN	ABS (Antilock Brake System)	●	●	●	●
KADJAR CN	SRS (Airbag/Pretensioners)	●	●	●	●
KADJAR CN	IP (Instrument Panel)	●	●	●	●
KADJAR CN	UCH	●	●	●	●
KADJAR CN	4WD (4 Wheels Drive)	●	●	●	●
KADJAR CN	Variable P.A.S	●	●	●	●
KADJAR CN	EPB (Parking Brake)	●	●	●	●
KADJAR CN	Parking Prox CAN	●	●	●	●
KADJAR CN	UPC	●	●	●	●
KADJAR CN	AC (Air Conditioning)	●	●	●	●
KADJAR CN	Radio	●	●	●	●
KADJAR CN	Multimedia Interface	●	●	●	●
KADJAR CN	Amplifier	●	●	●	●
KADJAR CN	Telematic Control Unit	●	●	●	●

KANGOO	ECM (Injection)	●	●	●	●
KANGOO	TCM (Transmission Control Module)	●	●	●	●
KANGOO	ABS (Antilock Brake System)	●	●	●	●
KANGOO	SRS (Airbag/Pretensioners)	●	●	●	●
KANGOO	Interconnection Unit	●	●	●	●
KANGOO	AC (Air Conditioning)	●	●	●	●
KANGOO	Gasoline ECM (Injection)	●	●	●	●
KANGOO	Engine Immobiliser	●	●	●	●
KANGOO II	ECM (Injection)	●	●	●	●
KANGOO II	TCM (Transmission Control Module)	●	●	●	●
KANGOO II	ABS (Antilock Brake System)	●	●	●	●
KANGOO II	SRS (Airbag/Pretensioners)	●	●	●	●
KANGOO II	IP (Instrument Panel)	●	●	●	●
KANGOO II	UCH	●	●	●	●
KANGOO II	Communications Unit	●	●	●	●
KANGOO II	UPC	●	●	●	●
KANGOO II	Variable P.A.S	●	●	●	●
KANGOO II	AC (Air Conditioning)	●	●	●	●
KANGOO II	TPMS (Tire Pressure Monitoring System)	●	●	●	○
KANGOO II	PAM (Parking Assistance)	●	●	●	●
KANGOO II	Radio	●	●	●	●
KANGOO II	Multimedia Interface	●	●	●	●
KANGOO II	Multimedia Connection	●	●	●	●
KANGOO II	Telematic Control Unit	●	●	●	●
KANGOO II	Adaptation Unit	●	●	●	●
KANGOO MUX	Petrol ECM (Injection)	●	●	●	●
KANGOO MUX	Diesel ECM (Injection)	●	●	●	●
KANGOO MUX	TCM (Transmission Control Module)	●	●	●	●
KANGOO MUX	ABS (Antilock Brake System)	●	●	●	●
KANGOO MUX	SRS (Airbag/Pretensioners)	●	●	●	●
KANGOO MUX	Interconnection Unit	●	●	●	●
KANGOO MUX	Engine Immobiliser	●	●	●	●
KANGOO VLL	ECM (Injection)	●	●	●	●
KANGOO VLL	ABS (Antilock Brake System)	●	●	●	●
KANGOO VLL	SRS (Airbag/Pretensioners)	●	●	●	●
KANGOO VLL	UCH	●	●	●	●
KANGOO VLL	Variable P.A.S	●	●	●	●
KANGOO VLL	Tracker	●	●	●	●
KANGOO ZE/STOPSTART/PH2	ECM (Injection)	●	●	●	●
KANGOO ZE/STOPSTART/PH2	ABS (Antilock Brake System)	●	●	●	●
KANGOO ZE/STOPSTART/PH2	SRS (Airbag/Pretensioners)	●	●	●	●
KANGOO ZE/STOPSTART/PH2	IP (Instrument Panel)	●	●	●	●
KANGOO ZE/STOPSTART/PH2	UCH	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Variable P.A.S	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Communications Unit	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Parking Prox CAN	●	●	●	●
KANGOO ZE/STOPSTART/PH2	PAM (Parking Assistance)	●	●	●	●
KANGOO ZE/STOPSTART/PH2	UPC	●	●	●	●
KANGOO ZE/STOPSTART/PH2	AC (Air Conditioning)	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Adaptation Unit	●	●	●	●
KANGOO ZE/STOPSTART/PH2	LBC	●	●	●	●
KANGOO ZE/STOPSTART/PH2	EVC	●	●	●	●
KANGOO ZE/STOPSTART/PH2	PEB	●	●	●	●
KANGOO ZE/STOPSTART/PH2	LBC2	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Telematic Control Unit	●	●	●	●

KANGOO ZE/STOPSTART/PH2	Radio	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Multimedia Connection	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Multimedia Interface	●	●	●	●
KANGOO ZE/STOPSTART/PH2	Heater	●	●	●	○
KAPTUR	ECM (Injection)	●	●	●	●
KAPTUR	TCM (Transmission Control Module)	●	●	●	●
KAPTUR	ABS (Antilock Brake System)	●	●	●	●
KAPTUR	SRS (Airbag/Pretensioners)	●	●	●	●
KAPTUR	IP (Instrument Panel)	●	●	●	●
KAPTUR	UCH	●	●	●	●
KAPTUR	4WD (4 Wheels Drive)	●	●	●	●
KAPTUR	Variable P.A.S	●	●	●	●
KAPTUR	UPC	●	●	●	●
KAPTUR	AC (Air Conditioning)	●	●	●	●
KAPTUR	Radio	●	●	●	●
KAPTUR	Multimedia Interface	●	●	●	●
KAPTUR	Telematic Control Unit	●	●	●	●
KAPTUR	Hands Free Kit	●	●	●	●
KOLEOS	ECM (Injection)	●	●	●	●
KOLEOS	TCM (Transmission Control Module)	●	●	●	●
KOLEOS	ABS (Antilock Brake System)	●	●	●	●
KOLEOS	SRS (Airbag/Pretensioners)	●	●	●	●
KOLEOS	IP (Instrument Panel)	●	●	●	●
KOLEOS	UCH	●	●	●	●
KOLEOS	Communications Unit	●	●	●	※
KOLEOS	4WD (4 Wheels Drive)	●	●	●	●
KOLEOS	Variable P.A.S	●	●	●	●
KOLEOS	EPB (Parking Brake)	●	●	●	●
KOLEOS	Parking Prox CAN	●	●	●	●
KOLEOS	TPMS (Tire Pressure Monitoring System)	●	●	●	●
KOLEOS	UPC	●	●	●	●
KOLEOS	Multimedia Interface	●	●	●	●
KOLEOS	Multimedia Connection	●	●	●	●
KOLEOS	Radio	●	●	●	●
KOLEOS	Amplifier	●	●	●	●
KOLEOS	Telematic Control Unit	●	●	●	●
KOLEOS	Auto Front Lighting	●	●	●	●
KOLEOS	Discharge Lamp	●	○	○	●
KOLEOS II	ECM (Injection)	●	●	●	●
KOLEOS II	TCM (Transmission Control Module)	●	●	●	●
KOLEOS II	ABS (Antilock Brake System)	●	●	●	●
KOLEOS II	SRS (Airbag/Pretensioners)	●	●	●	●
KOLEOS II	IP (Instrument Panel)	●	●	●	●
KOLEOS II	UCH	●	●	●	●
KOLEOS II	4WD (4 Wheels Drive)	●	●	●	●
KOLEOS II	Variable P.A.S	●	●	●	●
KOLEOS II	EPB (Parking Brake)	●	●	●	●
KOLEOS II	Parking Prox CAN	●	●	●	●
KOLEOS II	UPC	●	●	●	●
KOLEOS II	AC (Air Conditioning)	●	●	●	●
KOLEOS II	Power Back Door	●	●	●	●
KOLEOS II	Seat Management	●	●	●	●
KOLEOS II	Front Camera	●	●	●	●
KOLEOS II	Radio	●	●	●	●
KOLEOS II	Multimedia Interface	●	●	●	●

KOLEOS II	Telematic Control Unit	●	●	●	●
KOLEOS II	Amplifier	●	●	●	●
KOLEOS II	Distance Regulator	●	●	●	●
KOLEOS II CN	ECM (Injection)	●	●	●	●
KOLEOS II CN	TCM (Transmission Control Module)	●	●	●	●
KOLEOS II CN	ABS (Antilock Brake System)	●	●	●	●
KOLEOS II CN	SRS (Airbag/Pretensioners)	●	●	●	●
KOLEOS II CN	IP (Instrument Panel)	●	●	●	●
KOLEOS II CN	UCH	●	●	●	●
KOLEOS II CN	4WD (4 Wheels Drive)	●	●	●	●
KOLEOS II CN	Variable P. A. S	●	●	●	●
KOLEOS II CN	EPB (Parking Brake)	●	●	●	●
KOLEOS II CN	Parking Prox CAN	●	●	●	●
KOLEOS II CN	UPC	●	●	●	●
KOLEOS II CN	AC (Air Conditioning)	●	●	●	●
KOLEOS II CN	Power Back Door	●	●	●	●
KOLEOS II CN	Seat Management	●	●	●	●
KOLEOS II CN	Front Camera	●	●	●	●
KOLEOS II CN	Radio	●	●	●	●
KOLEOS II CN	Multimedia Interface	●	●	●	●
KOLEOS II CN	Telematic Control Unit	●	●	●	●
KOLEOS II CN	Amplifier	●	●	●	●
KOLEOS II CN	Distance Regulator	●	●	●	●
KOLEOS II CN	Left-Hand Door	●	●	●	●
KWID	ECM (Injection)	●	●	●	●
KWID	SRS (Airbag/Pretensioners)	●	●	●	●
KWID	IP (Instrument Panel)	●	●	●	●
KWID	UCH	●	●	●	●
KWID	Variable P. A. S	●	●	●	●
KWID	Radio	●	●	●	●
LAGUNA	ECM (Injection)	●	●	●	●
LAGUNA	TCM (Transmission Control Module)	●	●	●	●
LAGUNA	ABS (Antilock Brake System)	●	●	●	●
LAGUNA	SRS (Airbag/Pretensioners)	●	●	●	●
LAGUNA	IP (Instrument Panel)	●	●	●	●
LAGUNA	Variable P. A. S	●	●	●	●
LAGUNA	Engine Immobiliser	●	●	●	●
LAGUNA	AC (Air Conditioning)	●	●	●	●
LAGUNA II	ECM (Injection)	●	●	●	●
LAGUNA II	TCM (Transmission Control Module)	●	●	●	●
LAGUNA II	ABS (Antilock Brake System)	●	●	●	●
LAGUNA II	SRS (Airbag/Pretensioners)	●	●	●	●
LAGUNA II	IP (Instrument Panel)	●	●	●	●
LAGUNA II	UCH	●	●	●	●
LAGUNA II	AC (Air Conditioning)	●	●	●	●
LAGUNA II	PAM (Parking Assistance)	●	●	●	●
LAGUNA II	Discharge Lamp	●	●	●	●
LAGUNA II	Heater	●	●	●	●
LAGUNA II	Lighting	●	●	●	●
LAGUNA II PH2	ECM (Injection)	●	●	●	●
LAGUNA II PH2	TCM (Transmission Control Module)	●	●	●	●
LAGUNA II PH2	ABS (Antilock Brake System)	●	●	●	●
LAGUNA II PH2	SRS (Airbag/Pretensioners)	●	●	●	●
LAGUNA II PH2	IP (Instrument Panel)	●	●	●	●
LAGUNA II PH2	Communications Unit	●	●	●	●

LAGUNA II PH2	UCH	●	●	●	●
LAGUNA II PH2	EPB (Parking Brake)	●	●	●	●
LAGUNA II PH2	AC (Air Conditioning)	●	●	●	●
LAGUNA II PH2	Lighting	●	●	●	●
LAGUNA II PH2	PAM (Parking Assistance)	●	●	●	●
LAGUNA II PH2	Heater	●	●	●	●
LAGUNA II PH2	Hands Free Kit	●	●	●	●
LAGUNA III	ECM (Injection)	●	●	●	●
LAGUNA III	TCM (Transmission Control Module)	●	●	●	●
LAGUNA III	ABS (Antilock Brake System)	●	●	●	●
LAGUNA III	SRS (Airbag/Pretensioners)	●	●	●	●
LAGUNA III	IP (Instrument Panel)	●	●	●	●
LAGUNA III	UCH	●	●	●	●
LAGUNA III	Communications Unit	●	●	●	●
LAGUNA III	UPC	●	●	●	●
LAGUNA III	Variable P.A.S	●	●	●	●
LAGUNA III	Parking Prox CAN	●	●	●	●
LAGUNA III	EPB (Parking Brake)	●	●	●	●
LAGUNA III	4 Wheels Steering	●	●	●	●
LAGUNA III	AC (Air Conditioning)	●	●	●	●
LAGUNA III	Amplifier	●	●	●	●
LAGUNA III	Lighting	●	●	●	●
LAGUNA III	Radio	●	※	※	※
LAGUNA III	Multimedia Interface	●	●	●	●
LAGUNA III	Multimedia Connection	●	●	●	●
LAGUNA III	Driver's Door	●	●	●	●
LAGUNA III	Passenger's Door	●	●	●	●
LAGUNA III	Seat Management	●	●	●	●
LAGUNA III	Telematic Control Unit	●	●	●	●
LAGUNA III	Left-Hand Door	●	○	●	○
LAGUNA III	Right-Hand Door	●	○	●	○
LAGUNA PHASE 2	ECM (Injection)	●	●	●	●
LAGUNA PHASE 2	TCM (Transmission Control Module)	●	●	●	●
LAGUNA PHASE 2	ABS (Antilock Brake System)	●	●	●	●
LAGUNA PHASE 2	SRS (Airbag/Pretensioners)	●	●	●	●
LAGUNA PHASE 2	IP (Instrument Panel)	●	●	●	●
LAGUNA PHASE 2	Variable P.A.S	●	●	●	●
LAGUNA PHASE 2	Gasoline ECM (Injection)	●	●	●	●
LAGUNA PHASE 2	AC (Air Conditioning)	●	●	●	●
LATITUDE/SM5	ECM (Injection)	●	●	●	●
LATITUDE/SM5	TCM (Transmission Control Module)	●	●	●	●
LATITUDE/SM5	ABS (Antilock Brake System)	●	●	●	●
LATITUDE/SM5	SRS (Airbag/Pretensioners)	●	●	●	●
LATITUDE/SM5	IP (Instrument Panel)	●	●	●	●
LATITUDE/SM5	UCH	●	●	●	●
LATITUDE/SM5	Communications Unit	●	●	●	●
LATITUDE/SM5	Variable P.A.S	●	●	●	●
LATITUDE/SM5	UPC	●	●	●	●
LATITUDE/SM5	EPB (Parking Brake)	●	●	●	●
LATITUDE/SM5	Parking Prox CAN	●	●	●	●
LATITUDE/SM5	AC (Air Conditioning)	●	●	●	●
LATITUDE/SM5	Lighting	●	●	●	●
LATITUDE/SM5	Seat Management	●	●	●	●
LATITUDE/SM5	Radio	●	●	●	●
LATITUDE/SM5	Multimedia Interface	●	●	●	●

LATITUDE/SM5	Multimedia Connection	●	●	●	●
LATITUDE/SM5	Amplifier	●	●	●	●
LATITUDE/SM5	Driver's Door	●	●	●	●
LATITUDE/SM5	Passenger's Door	●	●	●	●
LATITUDE/SM5	Left-Hand Door	●	○	○	●
LATITUDE/SM5	Right-Hand Door	●	○	○	●
LATITUDE/SM5	Telematic Control Unit	●	●	●	●
LODGY	ECM (Injection)	●	●	●	●
LODGY	TCM (Transmission Control Module)	●	●	●	●
LODGY	ABS (Antilock Brake System)	●	●	●	●
LODGY	SRS (Airbag/Pretensioners)	●	●	●	●
LODGY	IP (Instrument Panel)	●	●	●	●
LODGY	UCH	●	●	●	●
LODGY	Variable P. A. S	●	●	●	●
LODGY	Radio	●	●	●	●
LOGAN	ECM (Injection)	●	●	●	●
LOGAN	TCM (Transmission Control Module)	●	●	●	●
LOGAN	ABS (Antilock Brake System)	●	●	●	●
LOGAN	SRS (Airbag/Pretensioners)	●	●	●	●
LOGAN	UCH	●	●	●	●
LOGAN	Variable P. A. S	●	●	●	●
LOGAN	Gasoline ECM (Injection)	●	●	●	●
LOGAN	Tracker	●	●	●	●
LOGAN	Radio	●	●	●	●
LOGAN II/SANDERO II	ECM (Injection)	●	●	●	●
LOGAN II/SANDERO II	TCM (Transmission Control Module)	●	●	●	●
LOGAN II/SANDERO II	ABS (Antilock Brake System)	●	●	●	●
LOGAN II/SANDERO II	SRS (Airbag/Pretensioners)	●	●	●	●
LOGAN II/SANDERO II	IP (Instrument Panel)	●	●	●	●
LOGAN II/SANDERO II	UCH	●	●	●	●
LOGAN II/SANDERO II	Variable P. A. S	●	●	●	●
LOGAN II/SANDERO II	AC (Air Conditioning)	●	●	●	●
LOGAN II/SANDERO II	Radio	●	●	●	●
LOGAN II/SANDERO II	Multimedia Interface	●	●	●	●
LOGAN II/SANDERO II	Tracker	●	●	●	●
MASTER	ECM (Injection)	●	●	●	●
MASTER	ABS (Antilock Brake System)	●	●	●	●
MASTER	SRS (Airbag/Pretensioners)	●	●	●	●
MASTER	Engine Immobiliser	●	●	●	●
MASTER	Piloted Suspension	●	●	●	●
MASTER III	ECM (Injection)	●	●	●	●
MASTER III	TCM (Transmission Control Module)	●	●	●	●
MASTER III	ABS (Antilock Brake System)	●	●	●	●
MASTER III	SRS (Airbag/Pretensioners)	●	●	●	●
MASTER III	IP (Instrument Panel)	●	●	●	●
MASTER III	UCH	●	●	●	●
MASTER III	Communications Unit	●	●	●	●
MASTER III	Variable P. A. S	●	●	●	●
MASTER III	UPC	●	●	●	●
MASTER III	TPMS (Tire Pressure Monitoring System)	●	●	●	●
MASTER III	Adaptation Unit	●	●	●	※
MASTER III	PAM (Parking Assistance)	●	●	●	●
MASTER III	AC (Air Conditioning)	●	●	●	●
MASTER III	Radio	●	●	●	●
MASTER III	Multimedia Connection	●	●	●	●

MASTER III	Multimedia Interface	●	●	●	●
MASTER III	Lighting	●	○	○	●
MASTER III	Telematic Control Unit	●	●	●	●
MASTER III	Tracker	●	●	●	●
MASTER PH 2	Diesel ECM (Injection)	●	●	●	●
MASTER PH 2	ABS (Antilock Brake System)	●	●	●	●
MASTER PH 2	SRS (Airbag/Pretensioners)	●	●	●	●
MASTER PH 2	Interconnection Unit	●	●	●	●
MASTER PH 2	Engine Immobiliser	●	●	●	●
MASTER PH 2	EPB (Parking Brake)	●	●	●	●
MASTER PH 3	ECM (Injection)	●	●	●	●
MASTER PH 3	TCM (Transmission Control Module)	●	●	●	●
MASTER PH 3	ABS (Antilock Brake System)	●	●	●	●
MASTER PH 3	SRS (Airbag/Pretensioners)	●	●	●	●
MASTER PH 3	UCH	●	●	●	●
MASTER PH 3	Communications Unit	●	●	●	●
MASTER PH 3	PAM (Parking Assistance)	●	●	●	●
MASTER PH 3	Adaptation Unit	●	●	●	●
MASTER PH 3	Piloted Suspension	●	●	●	●
MASTER PH 3	Tracker	●	●	●	●
MASTER RWD PH2	ECM (Injection)	●	●	●	●
MASTER RWD PH2	SRS (Airbag/Pretensioners)	●	●	●	●
MASTER RWD PH2	Communications Unit	●	●	●	●
MASTER RWD PH2	Adaptation Unit	●	●	●	●
MASTER RWD PH2	Engine Immobiliser	●	●	●	●
MASTER RWD PH3	ECM (Injection)	●	●	●	●
MASTER RWD PH3	ABS (Antilock Brake System)	●	●	●	●
MASTER RWD PH3	SRS (Airbag/Pretensioners)	●	●	●	●
MASTER RWD PH3	UCH	●	●	●	●
MASTER RWD PH3	Communications Unit	●	●	●	●
MASTER RWD PH3	Adaptation Unit	●	●	●	●
MEGANE II	ECM (Injection)	●	●	●	●
MEGANE II	TCM (Transmission Control Module)	●	●	●	●
MEGANE II	ABS (Antilock Brake System)	●	●	●	●
MEGANE II	SRS (Airbag/Pretensioners)	●	●	●	●
MEGANE II	IP (Instrument Panel)	●	●	●	●
MEGANE II	UCH	●	●	●	●
MEGANE II	Communications Unit	●	●	●	●
MEGANE II	Variable P.A.S	●	●	●	●
MEGANE II	UPC	●	●	●	●
MEGANE II	AC (Air Conditioning)	●	●	●	●
MEGANE II	Lighting	●	●	●	●
MEGANE II	Sunroof	●	●	●	●
MEGANE II	EPB (Parking Brake)	●	●	●	●
MEGANE II	Discharge Lamp	●	●	●	●
MEGANE II	Left-Hand Door	●	●	●	●
MEGANE II	Right-Hand Door	●	●	●	●
MEGANE III	ECM (Injection)	●	●	●	●
MEGANE III	TCM (Transmission Control Module)	●	●	●	●
MEGANE III	ABS (Antilock Brake System)	●	●	●	●
MEGANE III	SRS (Airbag/Pretensioners)	●	●	●	●
MEGANE III	IP (Instrument Panel)	●	●	●	●
MEGANE III	UCH	●	●	●	●
MEGANE III	Communications Unit	●	●	●	●
MEGANE III	EPB (Parking Brake)	●	●	●	●

MEGANE III	Variable P.A.S	●	●	●	●
MEGANE III	UPC	●	●	●	●
MEGANE III	AC (Air Conditioning)	●	●	●	●
MEGANE III	Radio	●	●	●	●
MEGANE III	Sunroof	●	●	●	●
MEGANE III	Multimedia Connection	●	●	●	●
MEGANE III	Multimedia Interface	●	●	●	●
MEGANE III	Driver's Door	●	●	●	●
MEGANE III	Passenger's Door	●	●	●	○
MEGANE III	Seat Management	●	●	●	●
MEGANE III	Telematic Control Unit	●	●	●	○
MEGANE III	Front Camera	●	●	●	○
MEGANE IV	ECM (Injection)	●	●	●	●
MEGANE IV	TCM (Transmission Control Module)	●	●	●	●
MEGANE IV	ABS (Antilock Brake System)	●	●	●	●
MEGANE IV	SRS (Airbag/Pretensioners)	●	●	●	●
MEGANE IV	IP (Instrument Panel)	●	●	●	●
MEGANE IV	UCH	●	●	●	●
MEGANE IV	4 Wheels Steering	●	●	●	●
MEGANE IV	Variable P.A.S	●	●	●	●
MEGANE IV	EPB (Parking Brake)	●	●	●	●
MEGANE IV	Parking Prox CAN	●	●	●	●
MEGANE IV	UPC	●	●	●	●
MEGANE IV	AC (Air Conditioning)	●	●	●	●
MEGANE IV	Seat Management	●	●	●	●
MEGANE IV	Front Camera	●	●	●	●
MEGANE IV	Radio	●	●	●	●
MEGANE IV	Multimedia Interface	●	●	●	●
MEGANE IV	Amplifier	●	●	●	●
MEGANE IV	Telematic Control Unit	●	●	●	●
MEGANE IV	Left-Hand Door	●	●	●	●
MEGANE IV	LBC2	●	●	●	●
MEGANE IV	LBC	●	●	●	●
MEGANE IV	PEB	●	●	●	●
MEGANE IV	Distance Regulator	●	●	●	●
MEGANE IV	Supervisor	●	●	●	●
MEGANE IV SEDAN	ECM (Injection)	●	●	●	●
MEGANE IV SEDAN	TCM (Transmission Control Module)	●	●	●	●
MEGANE IV SEDAN	ABS (Antilock Brake System)	●	●	●	●
MEGANE IV SEDAN	SRS (Airbag/Pretensioners)	●	●	●	●
MEGANE IV SEDAN	IP (Instrument Panel)	●	●	●	●
MEGANE IV SEDAN	UCH	●	●	●	●
MEGANE IV SEDAN	Variable P.A.S	●	●	●	●
MEGANE IV SEDAN	EPB (Parking Brake)	●	●	●	●
MEGANE IV SEDAN	Parking Prox CAN	●	●	●	●
MEGANE IV SEDAN	UPC	●	●	●	●
MEGANE IV SEDAN	AC (Air Conditioning)	●	●	●	●
MEGANE IV SEDAN	Seat Management	●	●	●	●
MEGANE IV SEDAN	Front Camera	●	●	●	●
MEGANE IV SEDAN	Radio	●	●	●	●
MEGANE IV SEDAN	Multimedia Interface	●	●	●	●
MEGANE IV SEDAN	Amplifier	●	●	●	●
MEGANE IV SEDAN	Telematic Control Unit	●	●	●	●
MEGANE IV SEDAN	Left-Hand Door	●	●	●	●
MEGANE IV SEDAN	Distance Regulator	●	●	●	●

MEGANE/SCENIC	ECM (Injection)	●	●	●	●
MEGANE/SCENIC	TCM (Transmission Control Module)	●	●	●	●
MEGANE/SCENIC	ABS (Antilock Brake System)	●	●	●	●
MEGANE/SCENIC	SRS (Airbag/Pretensioners)	●	●	●	●
MEGANE/SCENIC	Gasoline ECM (Injection)	●	●	●	●
MEGANE/SCENIC	Engine Immobiliser	●	●	●	●
MEGANE/SCENIC	AC (Air Conditioning)	●	●	●	●
MEGANE/SCENIC	Hood Control	●	●	●	●
MODUS	ECM (Injection)	●	●	●	●
MODUS	TCM (Transmission Control Module)	●	●	●	●
MODUS	ABS (Antilock Brake System)	●	●	●	●
MODUS	SRS (Airbag/Pretensioners)	●	●	●	●
MODUS	IP (Instrument Panel)	●	●	●	●
MODUS	UCH	●	●	●	●
MODUS	Variable P. A. S	●	●	●	○
MODUS	UPC	●	●	●	●
MODUS	AC (Air Conditioning)	●	●	●	●
MODUS	TPMS (Tire Pressure Monitoring System)	●	●	●	●
MODUS	Lighting	●	●	●	●
MODUS	Hands Free Kit	●	●	●	●
MODUS	PAM (Parking Assistance)	●	●	●	●
NEW SM3/FLUENCE/MEGANE	ECM (Injection)	●	●	●	●
NEW SM3/FLUENCE/MEGANE	TCM (Transmission Control Module)	●	●	●	●
NEW SM3/FLUENCE/MEGANE	ABS (Antilock Brake System)	●	●	●	●
NEW SM3/FLUENCE/MEGANE	SRS (Airbag/Pretensioners)	●	●	●	●
NEW SM3/FLUENCE/MEGANE	IP (Instrument Panel)	●	●	●	●
NEW SM3/FLUENCE/MEGANE	UCH	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Communications Unit	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Variable P. A. S	●	●	●	●
NEW SM3/FLUENCE/MEGANE	UPC	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Parking Prox CAN	●	●	●	●
NEW SM3/FLUENCE/MEGANE	EPB (Parking Brake)	●	●	●	●
NEW SM3/FLUENCE/MEGANE	AC (Air Conditioning)	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Sunroof	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Lighting	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Radio	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Multimedia Interface	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Amplifier	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Multimedia Connection	●	●	●	●
NEW SM3/FLUENCE/MEGANE	LBC	●	●	●	●
NEW SM3/FLUENCE/MEGANE	LBC2	●	●	●	●
NEW SM3/FLUENCE/MEGANE	EVC	●	●	●	●
NEW SM3/FLUENCE/MEGANE	PEB	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Driver's Door	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Telematic Control Unit	●	●	●	●
NEW SM3/FLUENCE/MEGANE	Tracker	●	●	●	●
SANDERO	ECM (Injection)	●	●	●	●
SANDERO	TCM (Transmission Control Module)	●	●	●	●
SANDERO	ABS (Antilock Brake System)	●	●	●	●
SANDERO	SRS (Airbag/Pretensioners)	●	●	●	●
SANDERO	UCH	●	●	●	●
SANDERO	Variable P. A. S	●	●	●	●
SANDERO	Tracker	●	●	●	●
SANDERO	Radio	●	●	●	●
SCENIC II	ECM (Injection)	●	●	●	●

SCENIC II	TCM (Transmission Control Module)	●	●	●	●
SCENIC II	ABS (Antilock Brake System)	●	●	●	●
SCENIC II	SRS (Airbag/Pretensioners)	●	●	●	●
SCENIC II	IP (Instrument Panel)	●	●	●	●
SCENIC II	UCH	●	●	●	●
SCENIC II	Communications Unit	●	●	●	●
SCENIC II	EPB (Parking Brake)	●	●	●	●
SCENIC II	Parking Prox CAN	●	●	●	●
SCENIC II	Variable P.A.S	●	●	●	●
SCENIC II	UPC	●	●	●	●
SCENIC II	AC (Air Conditioning)	●	●	●	●
SCENIC II	Radio	●	●	●	●
SCENIC II	Multimedia Interface	●	●	●	●
SCENIC II	PAM (Parking Assistance)	●	●	●	●
SCENIC II	Engine Immobiliser	●	●	●	●
SCENIC II	Discharge Lamp	●	●	●	●
SCENIC III	ECM (Injection)	●	●	●	●
SCENIC III	TCM (Transmission Control Module)	●	●	●	●
SCENIC III	ABS (Antilock Brake System)	●	●	●	●
SCENIC III	SRS (Airbag/Pretensioners)	●	●	●	●
SCENIC III	IP (Instrument Panel)	●	●	●	●
SCENIC III	UCH	●	●	●	●
SCENIC III	Communications Unit	●	●	●	●
SCENIC III	EPB (Parking Brake)	●	●	●	●
SCENIC III	Variable P.A.S	●	●	●	●
SCENIC III	UPC	●	●	●	●
SCENIC III	AC (Air Conditioning)	●	●	●	●
SCENIC III	Radio	●	●	●	●
SCENIC III	Sunroof	●	●	●	●
SCENIC III	Multimedia Connection	●	●	●	●
SCENIC III	Multimedia Interface	●	●	●	●
SCENIC III	Driver's Door	●	●	●	●
SCENIC III	Passenger's Door	●	●	●	●
SCENIC III	Seat Management	●	●	●	●
SCENIC III	Telematic Control Unit	●	●	●	●
SCENIC III	Front Camera	●	●	●	●
SCENIC IV	ECM (Injection)	●	●	●	●
SCENIC IV	TCM (Transmission Control Module)	●	●	●	●
SCENIC IV	ABS (Antilock Brake System)	●	●	●	●
SCENIC IV	SRS (Airbag/Pretensioners)	●	●	●	●
SCENIC IV	IP (Instrument Panel)	●	●	●	●
SCENIC IV	UCH	●	●	●	●
SCENIC IV	Variable P.A.S	●	●	●	●
SCENIC IV	EPB (Parking Brake)	●	●	●	●
SCENIC IV	Parking Prox CAN	●	●	●	●
SCENIC IV	UPC	●	●	●	●
SCENIC IV	AC (Air Conditioning)	●	●	●	●
SCENIC IV	Seat Management	●	●	●	●
SCENIC IV	Front Camera	●	●	●	●
SCENIC IV	Radio	●	●	●	●
SCENIC IV	Multimedia Interface	●	●	●	●
SCENIC IV	Amplifier	●	●	●	●
SCENIC IV	Telematic Control Unit	●	●	●	●
SCENIC IV	Left-Hand Door	●	●	●	●
SCENIC IV	Right-Hand Door	●	●	●	●

SCENIC IV	Supervisor	●	●	●	●
SCENIC IV	LBC	●	●	●	●
SCENIC IV	PEB	●	●	●	●
SCENIC IV	LBC2	●	●	●	●
SCENIC IV	Distance Regulator	●	●	●	●
SM7-L47	ECM (Injection)	●	●	●	●
SM7-L47	TCM (Transmission Control Module)	●	●	●	●
SM7-L47	ABS (Antilock Brake System)	●	●	●	●
SM7-L47	SRS (Airbag/Pretensioners)	●	●	●	●
SM7-L47	IP (Instrument Panel)	●	●	●	●
SM7-L47	UCH	●	●	●	●
SM7-L47	Communications Unit	●	●	●	●
SM7-L47	EPB (Parking Brake)	●	●	●	●
SM7-L47	Parking Prox CAN	●	●	●	●
SM7-L47	UPC	●	●	●	●
SM7-L47	AC (Air Conditioning)	●	●	●	●
SM7-L47	Driver's Door	●	●	●	●
SM7-L47	Passenger's Door	●	●	●	●
SM7-L47	Lighting	●	●	●	●
SM7-L47	Radio	●	●	●	●
SM7-L47	Multimedia Connection	●	●	●	●
SM7-L47	Multimedia Interface	●	●	●	●
SM7-L47	Amplifier	●	●	●	●
TALISMAN SM6	ECM (Injection)	●	●	●	●
TALISMAN SM6	TCM (Transmission Control Module)	●	●	●	●
TALISMAN SM6	ABS (Antilock Brake System)	●	●	●	●
TALISMAN SM6	SRS (Airbag/Pretensioners)	●	●	●	●
TALISMAN SM6	IP (Instrument Panel)	●	●	●	●
TALISMAN SM6	UCH	●	●	●	●
TALISMAN SM6	4 Wheels Steering	●	●	●	●
TALISMAN SM6	Variable P.A.S	●	●	●	●
TALISMAN SM6	EPB (Parking Brake)	●	●	●	●
TALISMAN SM6	Parking Prox CAN	●	●	●	●
TALISMAN SM6	UPC	●	●	●	●
TALISMAN SM6	AC (Air Conditioning)	●	●	●	●
TALISMAN SM6	Seat Management	●	●	●	●
TALISMAN SM6	Front Camera	●	●	●	●
TALISMAN SM6	Radio	●	●	●	●
TALISMAN SM6	Multimedia Interface	●	●	●	●
TALISMAN SM6	Amplifier	●	●	●	●
TALISMAN SM6	Telematic Control Unit	●	●	●	●
TALISMAN SM6	Left-Hand Door	●	●	●	●
TALISMAN SM6	Distance Regulator	●	●	●	●
TALISMAN SM6	Power Back Door	●	●	●	●
TALISMAN SM6	Piloted Suspension	●	●	●	●
THALIA/SYMBL	ECM (Injection)	●	●	●	●
THALIA/SYMBL	TCM (Transmission Control Module)	●	●	●	●
THALIA/SYMBL	ABS (Antilock Brake System)	●	●	●	●
THALIA/SYMBL	SRS (Airbag/Pretensioners)	●	●	●	●
THALIA/SYMBL	Engine Immobiliser	●	●	●	●
THALIA/SYMBL	AC (Air Conditioning)	●	●	●	●
THALIA/SYMBL. 2	ECM (Injection)	●	●	●	●
THALIA/SYMBL. 2	TCM (Transmission Control Module)	●	●	●	●
THALIA/SYMBL. 2	ABS (Antilock Brake System)	●	●	●	●
THALIA/SYMBL. 2	SRS (Airbag/Pretensioners)	●	●	●	●

THALIA/SYMBL. 2	Variable P.A.S	●	●	●	●
THALIA/SYMBL. 2	AC (Air Conditioning)	●	●	●	●
THALIA/SYMBL. 2	UCH	●	●	●	●
THALIA/SYMBL. 2	Tracker	●	●	●	●
TRAFIC II	ECM (Injection)	●	●	●	●
TRAFIC II	TCM (Transmission Control Module)	●	●	●	●
TRAFIC II	ABS (Antilock Brake System)	●	●	●	●
TRAFIC II	SRS (Airbag/Pretensioners)	●	●	●	●
TRAFIC II	Interconnection Unit	●	●	●	●
TRAFIC II	Adaptation Unit	●	●	●	●
TRAFIC II	Heater	●	●	●	●
TRAFIC II PH2	ECM (Injection)	●	●	●	●
TRAFIC II PH2	TCM (Transmission Control Module)	●	●	●	●
TRAFIC II PH2	ABS (Antilock Brake System)	●	●	●	●
TRAFIC II PH2	SRS (Airbag/Pretensioners)	●	●	●	●
TRAFIC II PH2	IP (Instrument Panel)	●	●	●	●
TRAFIC II PH2	UCH	●	●	●	●
TRAFIC II PH2	Communications Unit	●	●	●	●
TRAFIC II PH2	AC (Air Conditioning)	●	●	●	●
TRAFIC II PH2	PAM (Parking Assistance)	●	●	●	●
TRAFIC II PH2	Radio	●	●	●	○
TRAFIC II PH2	Multimedia Interface	●	●	●	●
TRAFIC II PH2	Multimedia Connection	●	●	●	●
TRAFIC II PH2	Heater	●	●	●	●
TRAFIC II PH2	Adaptation Unit	●	●	●	●
TRAFIC III	ECM (Injection)	●	●	●	●
TRAFIC III	ABS (Antilock Brake System)	●	●	●	●
TRAFIC III	SRS (Airbag/Pretensioners)	●	●	●	●
TRAFIC III	IP (Instrument Panel)	●	●	●	●
TRAFIC III	UCH	●	●	●	●
TRAFIC III	Communications Unit	●	※	※	●
TRAFIC III	Variable P.A.S	●	●	●	●
TRAFIC III	Parking Prox CAN	●	●	●	●
TRAFIC III	UPC	●	●	●	●
TRAFIC III	AC (Air Conditioning)	●	●	●	●
TRAFIC III	Adaptation Unit	●	●	●	●
TRAFIC III	Radio	●	●	●	●
TRAFIC III	Multimedia Interface	●	●	●	●
TRAFIC III	Telematic Control Unit	●	●	●	●
TRAFIC III	Hands Free Kit	●	●	●	●
TRAFIC III	Heater	●	●	●	●
TWINGO II	ECM (Injection)	●	●	●	●
TWINGO II	TCM (Transmission Control Module)	●	●	●	●
TWINGO II	ABS (Antilock Brake System)	●	●	●	●
TWINGO II	SRS (Airbag/Pretensioners)	●	●	●	●
TWINGO II	IP (Instrument Panel)	●	●	●	●
TWINGO II	UCH	●	●	●	●
TWINGO II	Variable P.A.S	●	●	●	●
TWINGO II	PAM (Parking Assistance)	●	●	●	●
TWINGO II	UPC	●	●	●	●
TWINGO II	Rev Counter/Symbol	●	●	●	●
TWINGO II	AC (Air Conditioning)	●	●	●	●
TWINGO II	Radio	●	●	●	●
TWINGO II	Multimedia Interface	●	●	●	●
TWINGO II	Multimedia Connection	●	●	●	●

TWINGO III	ECM (Injection)	●	●	●	●
TWINGO III	TCM (Transmission Control Module)	●	●	●	●
TWINGO III	ABS (Antilock Brake System)	●	●	●	●
TWINGO III	SRS (Airbag/Pretensioners)	●	●	●	●
TWINGO III	IP (Instrument Panel)	●	●	●	●
TWINGO III	UCH	●	●	●	●
TWINGO III	Communications Unit	●	●	●	●
TWINGO III	Variable P.A.S	●	●	●	●
TWINGO III	UPC	●	●	●	●
TWINGO III	AC (Air Conditioning)	●	●	●	●
TWINGO III	Radio	●	●	●	●
TWINGO III	Multimedia Interface	●	●	●	●
TWINGO III	Telematic Control Unit	●	●	●	●
TWINGO PHASE 2	ECM (Injection)	●	●	●	●
TWINGO PHASE 2	TCM (Transmission Control Module)	●	●	●	●
TWINGO PHASE 2	ABS (Antilock Brake System)	●	●	●	●
TWINGO PHASE 2	SRS (Airbag/Pretensioners)	●	●	●	●
TWINGO PHASE 2	Gasoline ECM (Injection)	●	●	●	●
TWINGO PHASE 2	Engine Immobiliser	●	●	●	●
TWINGO PHASE 2	Interconnection Unit	●	●	●	●
TWIZY	LBC	●	●	●	●
TWIZY	SRS (Airbag/Pretensioners)	●	●	●	●
TWIZY	UCH	●	●	●	●
TWIZY	IP (Instrument Panel)	●	●	●	●
TWIZY	Adaptation Unit	●	●	●	●
VEL SATIS	ECM (Injection)	●	●	●	●
VEL SATIS	TCM (Transmission Control Module)	●	●	●	●
VEL SATIS	ABS (Antilock Brake System)	●	●	●	●
VEL SATIS	SRS (Airbag/Pretensioners)	●	●	●	●
VEL SATIS	IP (Instrument Panel)	●	●	●	●
VEL SATIS	UCH	●	●	●	●
VEL SATIS	EPB (Parking Brake)	●	●	●	●
VEL SATIS	PAM (Parking Assistance)	●	●	●	●
VEL SATIS	TPMS (Tire Pressure Monitoring System)	●	●	●	●
VEL SATIS	AC (Air Conditioning)	●	●	●	●
VEL SATIS	Distance Regulator	●	●	●	●
VEL SATIS	Heater	●	●	●	●
VEL SATIS	Hands Free Kit	●	●	●	●
VEL SATIS PH2	ECM (Injection)	●	●	●	●
VEL SATIS PH2	TCM (Transmission Control Module)	●	●	●	●
VEL SATIS PH2	ABS (Antilock Brake System)	●	●	●	●
VEL SATIS PH2	SRS (Airbag/Pretensioners)	●	●	●	●
VEL SATIS PH2	IP (Instrument Panel)	●	●	●	●
VEL SATIS PH2	UCH	●	●	●	●
VEL SATIS PH2	Communications Unit	●	●	●	●
VEL SATIS PH2	Parking Prox CAN	●	●	●	●
VEL SATIS PH2	EPB (Parking Brake)	●	●	●	●
VEL SATIS PH2	PAM (Parking Assistance)	●	●	●	●
VEL SATIS PH2	AC (Air Conditioning)	●	●	●	●
VEL SATIS PH2	Lighting	●	●	●	●
VEL SATIS PH2	Hands Free Kit	●	●	●	●
VEL SATIS PH2	Heater	●	●	●	●
WIND	ECM (Injection)	●	●	●	●
WIND	ABS (Antilock Brake System)	●	●	●	●
WIND	SRS (Airbag/Pretensioners)	●	●	●	●

WIND	IP (Instrument Panel)	●	●	●	●
WIND	UCH	●	●	●	●
WIND	Variable P. A. S	●	●	●	●
WIND	AC (Air Conditioning)	●	●	●	●
WIND	Sunroof	●	●	●	●
WIND	Radio	●	●	●	●
WIND	Multimedia Interface	●	●	●	●
WIND	Multimedia Connection	●	●	●	●
ZOE	LBC	●	●	●	●
ZOE	ABS (Antilock Brake System)	●	●	●	●
ZOE	SRS (Airbag/Pretensioners)	●	●	●	●
ZOE	IP (Instrument Panel)	●	●	●	●
ZOE	UCH	●	●	●	●
ZOE	Communications Unit	●	●	●	●
ZOE	Variable P. A. S	●	●	●	●
ZOE	Parking Prox CAN	●	●	●	●
ZOE	UPC	●	●	●	●
ZOE	AC (Air Conditioning)	●	●	●	●
ZOE	Telematic Control Unit	●	●	●	●
ZOE	Adaptation Unit	●	●	●	●
ZOE	EVC	●	●	●	●
ZOE	PEB	●	●	●	●
ZOE	Radio	●	●	●	●

Renault_V11.20 BLD Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	BLD
CLIO II	●
CLIO II P 2/3/4	●
CLIO III	●
DUSTER	●
KANGOO II	●
KANGOO MUX	●
LOGAN	●
MAST RWD PH3	●
MASTER III	●
MEGANE II	●
MODUS	●
SANDERO	●
SCENIC II	●
THALIA/SYMBL	●
THALIA/SYMBL. 2	●
TRAFIC II P 2/3	●
TWINGO II	●
TWINGO PHASE 2	●
WIND	●
KANGOO VLL	●

Renault_V11.20 EPB Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	EPB
Espace IV	●
Espace IV Ph2	●
Koleos/Qm5	●
Laguna II Ph2	●
Laguna III	●
Latitude/Sm5	●
Megane III/Scenic III	●
New Sm3/Fluence/Megane	●
Scenic II	●
Sm7-147	●
Vel Satis	●
Vel Satis Ph2	●

Renault_V11.20 ETC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	ETC
Renault	※

Renault_V11.20 INJ Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	INJ
AVANTIME	●
CAPTUR	●
CLIO 2	●
CLIO II P 2/3/4	●
CLIO III	●
CLIO IV	●
DOKKER	●
DUSTER	●
DUSTER PH2	●
ESPACE	●
ESPACE IV	●
ESPACE IV PH2	●
KANGOO	●
KANGOO II	●
KANGOO MUX	●
KANGOO ZE/STOPSTART/PH2	●
KOLEOS/QM5	●
LAGUNA II	●
LAGUNA II PH2	●
LAGUNA III	●
LATITUDE/SM5	●
LODGY	●
LOGAN	●
LOGAN II/SANDERO II	●
MAST RWD PH3	●
MASTER	●
MASTER III	●
MASTER PH2	●
MASTER PH3	●
MASTER RW DPH2	●
MEGANE II	●
MEGANE III/SCENIC III	●
MEGANE/SCENIC	●
MODUS	●
NEW SM3/FLUENCE/MEGANE	●
SANDERO	●
SCENIC II	●
THALIA/SYMBL	●
THALIA/SYMBL. 2	●
TRAFIC II	●
TRAFIC II P 2/3	●
TWINGO II	●
VEL SATIS	●

Renault_V11.20 OIL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	OIL
Captur	●
Clio	●
Clio II	●
Clio III	●
Clio IV	●
Espace IV	●
Espace IV Ph2	●
Espace V	●
Espace/Grand Espace IV	●
Fluence	●
Kadjar	●
Kadjar CN	●
Kangoo II	●
Kangoo Ze/Stopstart/Ph2	●
Kartur	●
Koleos	●
Koleos II	●
Koleos II CN	●
Koleos/QM5	●
Laguna	●
Laguna II	●
Laguna II Ph2	●
Laguna III	●
Latitude/Sm5	●
Master III	●
Megane II	●
Megane III	●
Megane III/Scenic III	●
Megane IV	●
Megane IV Sedan	●
Megane Scenic	●
Modus	●
New Sm3/Fluence/Megane	●
Opel Vivaro	●
Safrane	●
Scenic	●
Scenic II	●
Scenic III	●
Scenic IV	●
Sm7-147	●
Talisman SM6	●

Renault_V11.20 SAS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	SAS
Avantime	●
Captur	●
Clio II p 2/3/4	●
Clio III	●
Clio IV	●
Dokker	●
Duster Ph2	●
Espace IV	●
Espace IV Ph2	●
Kangoo II	●
Kangoo Ze/Stopstart/Ph2	●
Koleos/Qm5	●
Laguna III	●
Laguna II Ph2	●
Latitude/Sm5	●
Lodgy	●
Logan II/Sandero II	●
Megane Scenic	●
Master ph3	●
Megane II	●
Master III	●
Megane III/Scenic III	●
Modus	●
New Sm3/Fluence/Megane	●
Scenic II	●
Sm7-147	●
Trafic II/p/2/3	●
Twingo II	●
Twingo III	●
Vel Satis	●
Vel Satis Ph2	●
Wind	●
Zoe	●