

LEXUS_V01.15 Diag Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	EcuInfo	Read Codes	Erase Codes	Live Data
Engine	○	●	●	●
ECT	○	●	●	●
ABS	○	●	●	●
EMPS	○	●	●	●
Free-Tronic	○	●	●	●
Air suspension	○	●	●	●
AHC	○	●	●	●
VGRS	○	●	●	●
EMS	○	●	●	●
Tire Pressure Monitor	○	●	●	●
SRS Airbag	○	●	●	●
BODY	○	●	●	●
Immobiliser	○	●	●	●
Tvss	○	●	●	●
Entry&Start	○	●	●	●
Occupant Detection	○	●	●	●
D-SEAT SW	○	※	※	●
AFS	○	●	●	●
Pre-Crash	○	●	●	●
D-Door Motor	○	●	●	●
Theft Deterrent	○	●	●	●
Air Conditioner	○	●	●	●
Combination Meter	○	※	※	●
Back Door	○	●	●	●
Driver Seat	○	※	※	●
Tilt&Telescopic	○	●	●	●
Mirror	○	※	※	●
Gateway	○	●	●	●
Passenger Door	○	●	●	●
Rear left Door	○	●	●	●
Rear right door	○	●	●	●
Sliding Roof	○	※	※	●
Driver Door	○	●	●	●
Master Switch	○	●	●	●
Rear Right Seat	○	●	●	●
Rear Left Seat	○	※	※	●
Rear Seat Switch	○	※	※	●
Steering Pad Switch	○	※	※	●
Clearance Sonar	○	●	●	●
Rain Sensor	○	※	※	●
Wiper	○	※	※	●
Combination Switch	○	※	※	●
Steering Lock	○	●	●	●
Passenger Seat	○	※	※	●
Retractable Hardtop	○	●	●	●

Main Body	○	●	●	●
P-Door Motor	○	●	●	●
RL-Door Motor	○	●	●	●
RR-Door Motor	○	●	●	●
HV Gateway	○	●	●	●
Night View	○	●	●	●
HL Autoleveling	○	●	●	●
ECM Gateway	○	●	●	●
ECB Gateway	○	●	●	●
WIL Gateway	○	●	●	●
Center Console Switch	○	※	※	●
Rear Console Switch	○	●	●	●
Front Left Seat A/C	○	●	●	●
Front Right Seat A/C	○	●	●	●
Rear left Seat A/C	○	●	●	●
Rear Right Seat A/C	○	●	●	●
Electric Power Control	○	●	●	●
Active Headrest R	○	●	●	●
Active Headrest L	○	●	●	●
Pre-Crash 2	○	●	●	●
Accessory Gateway	○	●	●	●
MIRROR R	○	●	●	●
MIRROR L	○	●	●	●
Navigation System	○	●	●	●
PM1 Gateway	○	●	●	●
Charging Control	○	●	●	●
Starting Control	○	●	●	●
PM2 Gateway	○	●	●	●
Remote Engine Starter	○	●	●	●
Gateway BEAN	○	●	●	●
Gateway CAN	○	●	●	●
Back DoorPW	○	●	●	●
Transmission Control	○	●	●	●
Parking Assist Monitor System	○	●	●	●
Power Source Control	○	●	●	●
EHPS	○	●	●	●
Four Wheel Drive	○	●	●	●
Stabilizer	○	●	●	●
Intelligent Parking Assist	○	●	●	●
Electric Parking Brake	○	●	●	●
Lane Keeping Assist	○	●	●	●
Front Stabilizer	○	●	●	●
Rear Stabilizer	○	●	●	●
ENGINE AND ECT	○	●	●	●
Cruise Control	○	●	●	●
ENGINE (LH Bank)	○	●	●	●
ENGINE (RH Bank)	○	●	●	●
HV Battery	○	●	●	●
Hybrid Control	○	●	●	●
Sequential M/T	○	●	●	●
Multi-Mode M/T	○	●	●	●
Stop And Go	○	●	●	●
Radar Cruise	○	●	●	●
Laser Cruise	○	●	●	●

E-ACM	○	●	●	●
Telematics	○	●	●	●
PPS	○	●	●	●
Advanced Parking Guidance System	○	●	●	●
FC	○	●	●	●
FCHV	○	●	●	●
EV	○	●	●	●
Battery	○	●	●	●
Front Right Door	○	※	※	●
Front Left Door	○	※	※	●
KDSS	○	●	●	●
Telematics	○	●	●	●
A/B	○	●	●	○
A/T	○	●	●	●
AMT	○	●	●	●
ARS	○	●	●	●
ASG	○	●	●	●
Bluetooth communication module	○	●	●	●
CAN bus gateway	○	●	●	○
CAN bus gateway V	○	●	●	○
CVT	○	●	●	●
DRS	○	●	●	●
eco IDLE	○	●	●	●
ECT(SIL)	○	●	●	●
EFI	○	●	●	●
EPS	○	●	●	●
FC	○	●	●	○
FCHV	○	●	●	○
HV	○	●	●	●
ITC	○	●	●	●
KFS	○	●	●	※
RL seat headrest ACT	○	●	●	●
ACT RR seat headrest	○	●	●	●
Pre-crash seat back seat RL	○	●	●	●
Pre-crash seat back seat RR	○	●	●	●
Active rear wing	○	●	●	●
Engine 2	○	●	●	●
Grille shutter	○	●	●	●
Cruise Control 2	○	※	※	●
Stop & Go	○	●	●	●
Diagnostics recorder	○	●	●	○
Panoramic View Monitor	○	●	●	●
Blind Spot Monitor Slave	○	●	●	●
Blind Spot Monitor Master	○	●	●	●
Plug-in control	○	●	●	●
Body / gateway	○	●	●	●
Multi-bus gateway	○	●	●	○
No.1 multi-bus monitoring	○	●	●	○
No.2 multi-bus monitoring	○	●	●	○
The motor-generator	○	●	●	●
Remote Security	○	●	●	●
Vehicle control	○	●	●	●
PKB electric	○	●	●	●

LEXUS_V11.10 SAS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Area	Year	SAS
CT200H	EUROPE AND OTHER	Up to 2019	●
ES250	EUROPE AND OTHER	Up to 2019	●
ES300H	EUROPE AND OTHER	Up to 2019	●
ES350	EUROPE AND OTHER	Up to 2019	●
GS250	EUROPE AND OTHER	Up to 2019	●
GS300	EUROPE AND OTHER	Up to 2019	●
GS300H	EUROPE AND OTHER	Up to 2019	●
GS350	EUROPE AND OTHER	Up to 2019	●
GS430	EUROPE AND OTHER	Up to 2019	●
GS450H	EUROPE AND OTHER	Up to 2019	●
GS460	EUROPE AND OTHER	Up to 2019	●
HS250H	EUROPE AND OTHER	Up to 2019	●
IS F	EUROPE AND OTHER	Up to 2019	●
IS220D	EUROPE AND OTHER	Up to 2019	●
IS250	EUROPE AND OTHER	Up to 2019	●
IS250C	EUROPE AND OTHER	Up to 2019	●
IS300	EUROPE AND OTHER	Up to 2019	●
IS300C	EUROPE AND OTHER	Up to 2019	●
IS300H	EUROPE AND OTHER	Up to 2019	●
IS350	EUROPE AND OTHER	Up to 2019	●
IS350C	EUROPE AND OTHER	Up to 2019	●
LFA	EUROPE AND OTHER	Up to 2019	●
LS460	EUROPE AND OTHER	Up to 2019	●
LS600H	EUROPE AND OTHER	Up to 2019	●
NX200	EUROPE AND OTHER	Up to 2019	●
NX200T	EUROPE AND OTHER	Up to 2019	●
RC350	EUROPE AND OTHER	Up to 2019	●
RC-F	EUROPE AND OTHER	Up to 2019	●
RX270	EUROPE AND OTHER	Up to 2019	●
RX350	EUROPE AND OTHER	Up to 2019	●
RX400H	EUROPE AND OTHER	Up to 2019	●
RX450H	EUROPE AND OTHER	Up to 2019	●
CT200H	JAPAN	Up to 2019	●
GS250	JAPAN	Up to 2019	●
GS300H	JAPAN	Up to 2019	●
GS350	JAPAN	Up to 2019	●
GS430	JAPAN	Up to 2019	●
GS450H	JAPAN	Up to 2019	●
GS460	JAPAN	Up to 2019	●
IS F	JAPAN	Up to 2019	●
IS250	JAPAN	Up to 2019	●
IS250C	JAPAN	Up to 2019	●
IS300H	JAPAN	Up to 2019	●
IS350	JAPAN	Up to 2019	●
IS350C	JAPAN	Up to 2019	●
LFA	JAPAN	Up to 2019	●

LS460	JAPAN	Up to 2019	●
LS600H	JAPAN	Up to 2019	●
NX200T	JAPAN	Up to 2019	●
NX300H	JAPAN	Up to 2019	●
RC300H	JAPAN	Up to 2019	●
RC350	JAPAN	Up to 2019	●
RC-F	JAPAN	Up to 2019	●
RX270	JAPAN	Up to 2019	●
RX350	JAPAN	Up to 2019	●
RX450	JAPAN	Up to 2019	●
CT200H	NORTH AMERICA	2011 - 2015	●
ES300H	NORTH AMERICA	2013 - 2015	●
ES350	NORTH AMERICA	2013 - 2015	●
GS300	NORTH AMERICA	2006	●
GS350	NORTH AMERICA	2007 - 2015	●
GS430	NORTH AMERICA	2006 - 2007	●
GS450H	NORTH AMERICA	2007 - 2015	●
GS460	NORTH AMERICA	2008 - 2011	●
HS250H	NORTH AMERICA	2010 - 2012	●
IS F	NORTH AMERICA	2008 - 2014	●
IS250	NORTH AMERICA	2006 - 2015	●
IS250C	NORTH AMERICA	2010 - 2015	●
IS350	NORTH AMERICA	2006 - 2015	●
IS350C	NORTH AMERICA	2010 - 2015	●
LFA	NORTH AMERICA	2012 - 2013	●
LS460	NORTH AMERICA	2007 - 2015	●
LS600H	NORTH AMERICA	2008 - 2015	●
NX200T	NORTH AMERICA	2015	●
NX300H	NORTH AMERICA	2015	●
RC350	NORTH AMERICA	2015	●
RC-F	NORTH AMERICA	2015	●
RX350	NORTH AMERICA	2010 - 2015	●
RX400H	NORTH AMERICA	2006 - 2008	●
RX450H	NORTH AMERICA	2010 - 2015	●

LEXUS_V11.10 BLD Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Area	BLD
GS350	EUROPE AND OTHER	●
GS250	EUROPE AND OTHER	●
GS300h	EUROPE AND OTHER	●
GS450h	EUROPE AND OTHER	●
GS F	EUROPE AND OTHER	●
NX200	EUROPE AND OTHER	●
NX300h	EUROPE AND OTHER	●
RX450h	EUROPE AND OTHER	●
LFA	EUROPE AND OTHER	●
LX570	EUROPE AND OTHER	●
LS460	EUROPE AND OTHER	●
LS600h	EUROPE AND OTHER	●
LX450d	EUROPE AND OTHER	●
GS300h	JAPAN	●
NX300h	JAPAN	●
GS350	JAPAN	●
GS250	JAPAN	●
GS450h	JAPAN	●
GS F	JAPAN	●
RX400h	JAPAN	●
LFA	JAPAN	●
LX570	JAPAN	●
LS460	JAPAN	●
LS600h	JAPAN	●
NX200t	JAPAN	●

LEXUS_V11.10 BMS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Area	Year	BMS
CT200h	EUROPE AND OTHER	Up to 2019	●
ES200	EUROPE AND OTHER	Up to 2019	●
ES300H	EUROPE AND OTHER	Up to 2019	●
GS450H	EUROPE AND OTHER	Up to 2019	●
HS250H	EUROPE AND OTHER	Up to 2019	●
IS300H	EUROPE AND OTHER	Up to 2019	●
LS600H	EUROPE AND OTHER	Up to 2019	●
RX400H	EUROPE AND OTHER	Up to 2019	●
RX450H	EUROPE AND OTHER	Up to 2019	●
CT200H	JAPAN	Up to 2019	●
GS300H	JAPAN	Up to 2019	●
GS450H	JAPAN	Up to 2019	●
HS250H	JAPAN	Up to 2019	●
IS300H	JAPAN	Up to 2019	●
LS600H	JAPAN	Up to 2019	●
NX300H	JAPAN	Up to 2019	●
RC300H	JAPAN	Up to 2019	●
RX450H	JAPAN	Up to 2019	●
CT200H	NORTH AMERICA	2011 - 2015	●
ES300H	NORTH AMERICA	2013 - 2015	●
GS450H	NORTH AMERICA	2007 - 2015	●
HS250H	NORTH AMERICA	2010 - 2012	●
LS600H	NORTH AMERICA	2008 - 2015	●
NX300H	NORTH AMERICA	2015	●
RX400H	NORTH AMERICA	2006 - 2008	●
RX450H	NORTH AMERICA	2010 - 2015	●

LEXUS_V11.10 DPF Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Area	Year	DPF
CT200H	EUROPE AND OTHER	Up to 2019	●
ES240	EUROPE AND OTHER	Up to 2019	●
ES250	EUROPE AND OTHER	Up to 2019	●
ES300H	EUROPE AND OTHER	Up to 2019	●
ES350	EUROPE AND OTHER	Up to 2019	●
GS250	EUROPE AND OTHER	Up to 2019	●
GS300	EUROPE AND OTHER	Up to 2019	●
GS300H	EUROPE AND OTHER	Up to 2019	●
GS350	EUROPE AND OTHER	Up to 2019	●
GS430	EUROPE AND OTHER	Up to 2019	●
GS450H	EUROPE AND OTHER	Up to 2019	●
GS460	EUROPE AND OTHER	Up to 2019	●
GX400	EUROPE AND OTHER	Up to 2019	●
GX460	EUROPE AND OTHER	Up to 2019	●
GX470	EUROPE AND OTHER	Up to 2019	●
HS250H	EUROPE AND OTHER	Up to 2019	●
IS F	EUROPE AND OTHER	Up to 2019	●
IS200D	EUROPE AND OTHER	Up to 2019	●
IS220D	EUROPE AND OTHER	Up to 2019	●
IS250	EUROPE AND OTHER	Up to 2019	●
IS250C	EUROPE AND OTHER	Up to 2019	●
IS300	EUROPE AND OTHER	Up to 2019	●
IS300C	EUROPE AND OTHER	Up to 2019	●
IS300H	EUROPE AND OTHER	Up to 2019	●
IS350	EUROPE AND OTHER	Up to 2019	●
IS350C	EUROPE AND OTHER	Up to 2019	●
LFA	EUROPE AND OTHER	Up to 2019	●
LS430	EUROPE AND OTHER	Up to 2019	●
LS460	EUROPE AND OTHER	Up to 2019	●
LS600H	EUROPE AND OTHER	Up to 2019	●
LX460	EUROPE AND OTHER	Up to 2019	●
LX470	EUROPE AND OTHER	Up to 2019	●
LX570	EUROPE AND OTHER	Up to 2019	●
NX200	EUROPE AND OTHER	Up to 2019	●
RC350	EUROPE AND OTHER	Up to 2019	●
RC-F	EUROPE AND OTHER	Up to 2019	●
RX270	EUROPE AND OTHER	Up to 2019	●
RX350	EUROPE AND OTHER	Up to 2019	●
RX400H	EUROPE AND OTHER	Up to 2019	●
RX450H	EUROPE AND OTHER	Up to 2019	●

SC430	EUROPE AND OTHER	Up to 2019	●
CT200H	JAPAN	Up to 2019	●
GS250	JAPAN	Up to 2019	●
GS300H	JAPAN	Up to 2019	●
GS350	JAPAN	Up to 2019	●
GS430	JAPAN	Up to 2019	●
GS450H	JAPAN	Up to 2019	●
GS460	JAPAN	Up to 2019	●
HS250H	JAPAN	Up to 2019	●
IS F	JAPAN	Up to 2019	●
IS250	JAPAN	Up to 2019	●
IS250C	JAPAN	Up to 2019	●
IS300H	JAPAN	Up to 2019	●
IS350	JAPAN	Up to 2019	●
IS350C	JAPAN	Up to 2019	●
LFA	JAPAN	Up to 2019	●
LS460	JAPAN	Up to 2019	●
LS600H	JAPAN	Up to 2019	●
NX300H	JAPAN	Up to 2019	●
RC300H	JAPAN	Up to 2019	●
RC350	JAPAN	Up to 2019	●
RX270	JAPAN	Up to 2019	●
RX350	JAPAN	Up to 2019	●
RX450H	JAPAN	Up to 2019	●
SC430	JAPAN	Up to 2019	●
CT200H	NORTH AMERICA	2011 - 2015	●
ES300H	NORTH AMERICA	2013 - 2015	●
ES350	NORTH AMERICA	2007 - 2015	●
GS300	NORTH AMERICA	2006	●
GS350	NORTH AMERICA	2007 - 2015	●
GS430	NORTH AMERICA	2006 - 2007	●
GS450H	NORTH AMERICA	2007 - 2015	●
GS460	NORTH AMERICA	2008 - 2011	●
GX460	NORTH AMERICA	2010 - 2015	●
GX470	NORTH AMERICA	2005 - 2009	●
HS250H	NORTH AMERICA	2010 - 2012	●
IS F	NORTH AMERICA	2008 - 2014	●
IS250	NORTH AMERICA	2006 - 2015	●
IS250C	NORTH AMERICA	2010 - 2015	●
IS350	NORTH AMERICA	2006 - 2015	●
IS350C	NORTH AMERICA	2010 - 2015	●
LFA	NORTH AMERICA	2012 - 2013	●
LS430	NORTH AMERICA	2004 - 2006	●
LS460	NORTH AMERICA	2007 - 2015	●
LS600H	NORTH AMERICA	2008 - 2015	●
LX470	NORTH AMERICA	2006 - 2007	●
LX570	NORTH AMERICA	2008 - 2015	●
NX300H	NORTH AMERICA	2015	●
RC350	NORTH AMERICA	2015	●
RC-F	NORTH AMERICA	2015	●
RX350	NORTH AMERICA	2007 - 2015	●
RX400H	NORTH AMERICA	2006 - 2008	●
RX450H	NORTH AMERICA	2010 - 2015	●
SC430	NORTH AMERICA	2006 - 2010	●

LEXUS_V11.10 EPB Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Area	EPB
GS350	EUROPE AND OTHER	●
GS250	EUROPE AND OTHER	●
GS300h	EUROPE AND OTHER	●
GS450h	EUROPE AND OTHER	●
GS F	EUROPE AND OTHER	●
NX200	EUROPE AND OTHER	●
NX300h	EUROPE AND OTHER	●
RX450h	EUROPE AND OTHER	●
LFA	EUROPE AND OTHER	●
LX570	EUROPE AND OTHER	●
LS460	EUROPE AND OTHER	●
LS600h	EUROPE AND OTHER	●
LX450d	EUROPE AND OTHER	●
GS300h	JAPAN	●
NX300h	JAPAN	●
GS350	JAPAN	●
GS250	JAPAN	●
GS450h	JAPAN	●
GS F	JAPAN	●
RX400h	JAPAN	●
LFA	JAPAN	●
LX570	JAPAN	●
LS460	JAPAN	●
LS600h	JAPAN	●
NX200t	JAPAN	●

LEXUS_V11.10 ETC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Area	Year	ETC
ES240	EUROPE AND OTHER	Up to 2014	●
ES350	EUROPE AND OTHER	Up to 2014	●
GS300	EUROPE AND OTHER	Up to 2014	●
GS350	EUROPE AND OTHER	Up to 2014	●
GS430	EUROPE AND OTHER	Up to 2014	●
GS450H	EUROPE AND OTHER	Up to 2014	●
GS460	EUROPE AND OTHER	Up to 2014	●
GX470	EUROPE AND OTHER	Up to 2014	●
IS220D	EUROPE AND OTHER	Up to 2014	●
IS250	EUROPE AND OTHER	Up to 2014	●
IS250C	EUROPE AND OTHER	Up to 2014	●
IS300	EUROPE AND OTHER	Up to 2014	●
IS300C	EUROPE AND OTHER	Up to 2014	●
IS350	EUROPE AND OTHER	Up to 2014	●
IS350C	EUROPE AND OTHER	Up to 2014	●
LS430	EUROPE AND OTHER	Up to 2014	●
LS600H	EUROPE AND OTHER	Up to 2014	●
LX460	EUROPE AND OTHER	Up to 2014	●
LX470	EUROPE AND OTHER	Up to 2014	●
LX570	EUROPE AND OTHER	Up to 2014	●
RC350	EUROPE AND OTHER	Up to 2014	●
RX270	EUROPE AND OTHER	Up to 2014	●
RX350	EUROPE AND OTHER	Up to 2014	●
RX400H	EUROPE AND OTHER	Up to 2014	●
SC430	EUROPE AND OTHER	Up to 2014	●
CT200H	JAPAN	As of 2010	●
GS250	JAPAN	As of 2011	●
GS300H	JAPAN	As of 2013	●
GS350	JAPAN	As of 2005	●
GS430	JAPAN	As of 2005	●
GS450H	JAPAN	As of 2006	●
GS460	JAPAN	As of 2007	●
HS250H	JAPAN	As of 2009	●
IS F	JAPAN	As of 2007	●
IS250	JAPAN	As of 2005	●
IS250C	JAPAN	As of 2009	●
IS300H	JAPAN	As of 2013	●
IS350	JAPAN	As of 2005	●
IS350C	JAPAN	As of 2010	●
LS460	JAPAN	As of 2006	●
LS600H	JAPAN	As of 2007	●
NX300H	JAPAN	As of 2014	●
RC300H	JAPAN	As of 2014	●
RC350	JAPAN	As of 2014	●
RX270	JAPAN	As of 2010	●
RX350	JAPAN	As of 2008	●
RX450H	JAPAN	As of 2009	●
SC430	JAPAN	As of 2005	●

LEXUS_V11.10 INJ Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Area	INJ
GS350	EUROPE AND OTHER	●
GS250	EUROPE AND OTHER	●
GS300h	EUROPE AND OTHER	●
GS450h	EUROPE AND OTHER	●
GS F	EUROPE AND OTHER	●
NX200	EUROPE AND OTHER	●
NX300h	EUROPE AND OTHER	●
RX450h	EUROPE AND OTHER	●
LFA	EUROPE AND OTHER	●
LX570	EUROPE AND OTHER	●
LS460	EUROPE AND OTHER	●
LS600h	EUROPE AND OTHER	●
LX450d	EUROPE AND OTHER	●
GS300h	JAPAN	●
NX300h	JAPAN	●
GS350	JAPAN	●
GS250	JAPAN	●
GS450h	JAPAN	●
GS F	JAPAN	●
RX400h	JAPAN	●
LFA	JAPAN	●
LX570	JAPAN	●
LS460	JAPAN	●
LS600h	JAPAN	●
NX200t	JAPAN	●

LEXUS_V11.10 OIL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Area	Year	OIL
CT200h	USA	2011 - 2012	※
ES330	USA	2006	※
ES350	USA	2007 - 2012	※
GS300	USA	2006	※
GS350	USA	2007 - 2011	※
GS430	USA	2006 - 2007	※
GS450h	USA	2007 - 2011	※
GS460	USA	2008 - 2011	※
GX470	USA	2006 - 2009	※
HS250h	USA	2010 - 2011	※
IS F	USA	2008 - 2012	※
IS250	USA	2006 - 2012	※
IS350	USA	2006 - 2012	※
LS430	USA	2006	※
LS460	USA	2007 - 2012	※
LS600h	USA	2012	※
LX470	USA	2006 - 2007	※
LX570	USA	2008 - 2011	※
RX330	USA	2006	※
RX350	USA	2012	※
RX400h	USA	2006 - 2008	※
RX450h	USA	2010 - 2012	※
SC430	USA	2006 - 2010	※