

SUBARU_V11.10 Diag Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Model Years			
FORESTER	-2018			
IMPREZA	-2018			
LEGACY	-2018			
OUTBACK	-2018			
PLEO	-2018			
R2	-2018			
VIVIO	-2018			
System	EcuInfo	Read Codes	Erase Codes	Live Data
ECM (Engine Control System)	●	●	●	●
HPC (Hybrid Powertrain Control)	●	●	●	●
TCM (Transmission Control System)	●	●	●	●
ABS (Brake Control System)	●	●	●	●
BVP (Brake Vacuum Pump)	●	●	●	●
SRS (Supplemental Inflatable Restraint System)	●	●	●	●
AC (Air Condition System)	●	●	●	●
METER (Combination Meter System)	●	●	●	●
IMMO (Immobiliser)	●	●	●	●
SSP (Air Suspension System)	●	●	●	●
EPB (Parking Brake System)	●	●	●	●
CCS (Cruise Control System)	●	●	●	●
HVB (High Voltage Battery)	●	●	●	●
TPM (Tire pressure monitor)	●	●	●	●
LT (Headlight / Foglight)	●	●	●	●
ASS (Auto Start Stop)	●	●	●	●
BCM (Body Control System)	●	●	●	●
EPS (Electric Power steering)	●	●	●	●
CS (CAN System)	●	●	●	●
DM (Drive Motor)	●	●	●	●
ALAWS (Automatic Light And Wiper System)	●	●	●	●
DCCD (Driver's Control Center Differential)	●	●	●	●
(ES) EyeSight	●	●	●	●
KLE (Keyless Entry)	●	●	●	●
KAS (Keyless Access System) (Collation ECM)	●	●	●	●
KAS (Keyless Access System) (Power Supply ECM)	●	●	●	●
KAS (Keyless Access System) (G/W ECM)	●	●	●	●
IUM (Integrated Unit Mode)	●	●	●	●
INF (Infotainment)	●	●	●	●
MFD (Multifunction Display)	●	●	●	●
ODS (Occupant Detection System)	●	●	●	●
PSM (Power Seat Memory)	●	●	●	●
PRG (Power Rear Gate)	●	●	●	●
PWD (Power Window Driver)	●	●	●	●
PWP (Power Window Passenger)	●	●	●	●
PWS (Power Window Switch)	●	●	●	●
RABL (RADAR ASSY B&S RH System)	●	●	●	●
RABL (RADAR ASSY B&S LH System)	●	●	●	●
RAB (Reverse Automatic Braking)	●	●	●	●
SMT (Keyless Access with Push Button Start)	●	●	●	●
TLM (Telematics)	●	●	●	●

SUBARU_V11.15 DPF Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	DPF
FORESTER	Up to 2019	※
IMPREZA	Up to 2019	※
LEGACY	Up to 2019	※
OUTBACK	Up to 2019	※
R2	Up to 2019	※
PLEO	Up to 2019	※
VIVIO	Up to 2019	※

SUBARU_V11.15 INJ Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	INJ
FORESTER	Up to 2019	※
IMPREZA	Up to 2019	※
LEGACY	Up to 2019	※
OUTBACK	Up to 2019	※
R2	Up to 2019	※
PLEO	Up to 2019	※
VIVIO	Up to 2019	※

SUBARU_V11.15 OIL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	OIL
FORESTER	up to 2019	※
IMPREZA	up to 2019	※
LEGACY	up to 2019	※
LIBERTY	up to 2019	※
OUTBACK	up to 2019	※
PLEO	up to 2019	※
R2	up to 2019	※
TRIBECA	up to 2019	※
VIVIO	up to 2019	※
WRX/LEVORG	up to 2019	※
XV/CROSSTREK	up to 2019	※
BRZ VEHICLE	up to 2019	※

SUBARU_V11.15 SAS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	SAS
FORESTER	Up to 2019	※
IMPREZA	Up to 2019	※
LEGACY	Up to 2019	※
OUTBACK	Up to 2019	※
R2	Up to 2019	※
PLEO	Up to 2019	※
VIVIO	Up to 2019	※