

## Sprinter V01.40 Diag Function List (Note: For reference only)

**NOTES:**

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	Chassis	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData
Sprinter	2000-2006	690.6	AB (Airbag with window airbag)	●	●	●	●
Sprinter	2000-2006	690.6	AB (Airbag)	●	●	●	●
Sprinter	2000-2006	690.6	ABS (Anti lock braking system)	●	●	●	●
Sprinter	2000-2006	690.6	AH (Auxiliary heater)	●	●	●	●
Sprinter	2000-2006	690.6	AHWA (Auxiliary heater warm air)	●	●	●	●
Sprinter	2000-2006	690.6	APS (Auto pilot system)	●	●	●	●
Sprinter	2000-2006	690.6	ARS (All wheel system)	●	●	●	●
Sprinter	2000-2006	690.6	ATA (Anti theft alarm)	●	●	●	●
Sprinter	2000-2006	690.6	BA (Backup assist)	●	●	●	●
Sprinter	2000-2006	690.6	CLS (Central locking system)	●	●	●	●
Sprinter	2000-2006	690.6	CR (Common rail)	●	●	●	●
Sprinter	2000-2006	690.6	CRDI (Common rail diesel injection)	●	●	●	●
Sprinter	2000-2006	690.6	ESLM (Electronic selector lever module)	●	●	●	●
Sprinter	2000-2006	690.6	ETC (Electronic transmission control)	●	●	●	●
Sprinter	2000-2006	690.6	HC (Heating control)	●	●	●	●
Sprinter	2000-2006	690.6	IC (Instrument cluster)	●	●	●	●
Sprinter	2000-2006	690.6	IMMO (Immobilizer)	●	●	●	●
Sprinter	2000-2006	690.6	LPG (Liquified Petroleum Gas)	●	●	●	●
Sprinter	2000-2006	690.6	ME (Motor electronics)	●	●	●	●
Sprinter	2000-2006	690.6	ST (Sprintshift transmission)	●	●	●	●
Sprinter	2000-2006	901.6	AB (Airbag with window airbag)	●	●	●	●
Sprinter	2000-2006	901.6	AB (Airbag)	●	●	●	●
Sprinter	2000-2006	901.6	ABS (Anti lock braking system)	●	●	●	●
Sprinter	2000-2006	901.6	AH (Auxiliary heater)	●	●	●	●
Sprinter	2000-2006	901.6	AHWA (Auxiliary heater warm air)	●	●	●	●
Sprinter	2000-2006	901.6	APS (Auto pilot system)	●	●	●	●
Sprinter	2000-2006	901.6	ARS (All wheel system)	●	●	●	●
Sprinter	2000-2006	901.6	ATA (Anti theft alarm)	●	●	●	●
Sprinter	2000-2006	901.6	BA (Backup assist)	●	●	●	●
Sprinter	2000-2006	901.6	CLS (Central locking system)	●	●	●	●
Sprinter	2000-2006	901.6	CR (Common rail)	●	●	●	●
Sprinter	2000-2006	901.6	CRDI (Common rail diesel injection)	●	●	●	●
Sprinter	2000-2006	901.6	ESLM (Electronic selector lever module)	●	●	●	●
Sprinter	2000-2006	901.6	ETC (Electronic transmission control)	●	●	●	●
Sprinter	2000-2006	901.6	HC (Heating control)	●	●	●	●
Sprinter	2000-2006	901.6	IC (Instrument cluster)	●	●	●	●
Sprinter	2000-2006	901.6	IMMO (Immobilizer)	●	●	●	●
Sprinter	2000-2006	901.6	LPG (Liquified Petroleum Gas)	●	●	●	●
Sprinter	2000-2006	901.6	ME (Motor electronics)	●	●	●	●
Sprinter	2000-2006	901.6	ST (Sprintshift transmission)	●	●	●	●
Sprinter	2000-2006	902.6	AB (Airbag with window airbag)	●	●	●	●
Sprinter	2000-2006	902.6	AB (Airbag)	●	●	●	●
Sprinter	2000-2006	902.6	ABS (Anti lock braking system)	●	●	●	●
Sprinter	2000-2006	902.6	AH (Auxiliary heater)	●	●	●	●
Sprinter	2000-2006	902.6	AHWA (Auxiliary heater warm air)	●	●	●	●
Sprinter	2000-2006	902.6	APS (Auto pilot system)	●	●	●	●
Sprinter	2000-2006	902.6	ARS (All wheel system)	●	●	●	●
Sprinter	2000-2006	902.6	ATA (Anti theft alarm)	●	●	●	●
Sprinter	2000-2006	902.6	BA (Backup assist)	●	●	●	●
Sprinter	2000-2006	902.6	CLS (Central locking system)	●	●	●	●
Sprinter	2000-2006	902.6	CR (Common rail)	●	●	●	●
Sprinter	2000-2006	902.6	CRDI (Common rail diesel injection)	●	●	●	●

Sprinter	2000-2006	902.6	ESLM (Electronic selector lever module)	●	●	●	●
Sprinter	2000-2006	902.6	ETC (Electronic transmission control)	●	●	●	●
Sprinter	2000-2006	902.6	HC (Heating control)	●	●	●	●
Sprinter	2000-2006	902.6	IC (Instrument cluster)	●	●	●	●
Sprinter	2000-2006	902.6	IMMO (Immobilizer)	●	●	●	●
Sprinter	2000-2006	902.6	LPG (Liquified Petroleum Gas)	●	●	●	●
Sprinter	2000-2006	902.6	ME (Motor electronics)	●	●	●	●
Sprinter	2000-2006	902.6	ST (Sprintshift transmission)	●	●	●	●
Sprinter	2000-2006	903.6	AB (Airbag with window airbag)	●	●	●	●
Sprinter	2000-2006	903.6	AB (Airbag)	●	●	●	●
Sprinter	2000-2006	903.6	ABS (Anti lock braking system)	●	●	●	●
Sprinter	2000-2006	903.6	AH (Auxiliary heater)	●	●	●	●
Sprinter	2000-2006	903.6	AHWA (Auxiliary heater warm air)	●	●	●	●
Sprinter	2000-2006	903.6	APS (Auto pilot system)	●	●	●	●
Sprinter	2000-2006	903.6	ARS (All wheel system)	●	●	●	●
Sprinter	2000-2006	903.6	ATA (Anti theft alarm)	●	●	●	●
Sprinter	2000-2006	903.6	BA (Backup assist)	●	●	●	●
Sprinter	2000-2006	903.6	CLS (Central locking system)	●	●	●	●
Sprinter	2000-2006	903.6	CR (Common rail)	●	●	●	●
Sprinter	2000-2006	903.6	CRDI (Common rail diesel injection)	●	●	●	●
Sprinter	2000-2006	903.6	ESLM (Electronic selector lever module)	●	●	●	●
Sprinter	2000-2006	903.6	ETC (Electronic transmission control)	●	●	●	●
Sprinter	2000-2006	903.6	HC (Heating control)	●	●	●	●
Sprinter	2000-2006	903.6	IC (Instrument cluster)	●	●	●	●
Sprinter	2000-2006	903.6	IMMO (Immobilizer)	●	●	●	●
Sprinter	2000-2006	903.6	LPG (Liquified Petroleum Gas)	●	●	●	●
Sprinter	2000-2006	903.6	ME (Motor electronics)	●	●	●	●
Sprinter	2000-2006	903.6	ST (Sprintshift transmission)	●	●	●	●
Sprinter	2000-2006	904.6	AB (Airbag with window airbag)	●	●	●	●
Sprinter	2000-2006	904.6	AB (Airbag)	●	●	●	●
Sprinter	2000-2006	904.6	ABS (Anti lock braking system)	●	●	●	●
Sprinter	2000-2006	904.6	AH (Auxiliary heater)	●	●	●	●
Sprinter	2000-2006	904.6	AHWA (Auxiliary heater warm air)	●	●	●	●
Sprinter	2000-2006	904.6	APS (Auto pilot system)	●	●	●	●
Sprinter	2000-2006	904.6	ARS (All wheel system)	●	●	●	●
Sprinter	2000-2006	904.6	ATA (Anti theft alarm)	●	●	●	●
Sprinter	2000-2006	904.6	BA (Backup assist)	●	●	●	●
Sprinter	2000-2006	904.6	CLS (Central locking system)	●	●	●	●
Sprinter	2000-2006	904.6	CR (Common rail)	●	●	●	●
Sprinter	2000-2006	904.6	CRDI (Common rail diesel injection)	●	●	●	●
Sprinter	2000-2006	904.6	ESLM (Electronic selector lever module)	●	●	●	●
Sprinter	2000-2006	904.6	ETC (Electronic transmission control)	●	●	●	●
Sprinter	2000-2006	904.6	HC (Heating control)	●	●	●	●
Sprinter	2000-2006	904.6	IC (Instrument cluster)	●	●	●	●
Sprinter	2000-2006	904.6	IMMO (Immobilizer)	●	●	●	●
Sprinter	2000-2006	904.6	LPG (Liquified Petroleum Gas)	●	●	●	●
Sprinter	2000-2006	904.6	ME (Motor electronics)	●	●	●	●
Sprinter	2000-2006	904.6	ST (Sprintshift transmission)	●	●	●	●
Sprinter	2000-2006	905.6	AB (Airbag with window airbag)	●	●	●	●
Sprinter	2000-2006	905.6	AB (Airbag)	●	●	●	●
Sprinter	2000-2006	905.6	ABS (Anti lock braking system)	●	●	●	●
Sprinter	2000-2006	905.6	AH (Auxiliary heater)	●	●	●	●
Sprinter	2000-2006	905.6	AHWA (Auxiliary heater warm air)	●	●	●	●
Sprinter	2000-2006	905.6	APS (Auto pilot system)	●	●	●	●
Sprinter	2000-2006	905.6	ARS (All wheel system)	●	●	●	●
Sprinter	2000-2006	905.6	ATA (Anti theft alarm)	●	●	●	●
Sprinter	2000-2006	905.6	BA (Backup assist)	●	●	●	●
Sprinter	2000-2006	905.6	CLS (Central locking system)	●	●	●	●

Sprinter	2000-2006	905.6	CR (Common rail)	●	●	●	●
Sprinter	2000-2006	905.6	CRDI (Common rail diesel injection)	●	●	●	●
Sprinter	2000-2006	905.6	ESLM (Electronic selector lever module)	●	●	●	●
Sprinter	2000-2006	905.6	ETC (Electronic transmission control)	●	●	●	●
Sprinter	2000-2006	905.6	HC (Heating control)	●	●	●	●
Sprinter	2000-2006	905.6	IC (Instrument cluster)	●	●	●	●
Sprinter	2000-2006	905.6	IMMO (Immobilizer)	●	●	●	●
Sprinter	2000-2006	905.6	LPG (Liquified Petroleum Gas)	●	●	●	●
Sprinter	2000-2006	905.6	ME (Motor electronics)	●	●	●	●
Sprinter	2000-2006	905.6	ST (Sprintshift transmission)	●	●	●	●
Sprinter	2006-	906	AACT (Automatic air conditioning/Automatic temperature control)	●	●	●	●
Sprinter	2006-	906	AH (Auxiliary heater)	●	●	●	●
Sprinter	2006-	906	CDI4 (4 Cylinder)	●	●	●	●
Sprinter	2006-	906	CDI4 (6 Cylinder)	●	●	●	●
Sprinter	2006-	906	DCM (Door control module)	●	●	●	●
Sprinter	2006-	906	EIS (Electronic ignition switch)	●	●	●	●
Sprinter	2006-	906	ELC (Electronic level control)	●	●	●	●
Sprinter	2006-	906	ESM (Electronic selector module)	●	●	●	●
Sprinter	2006-	906	ESP (Electronic stability program)	●	●	●	●
Sprinter	2006-	906	ETC (Electronic transmission control)	●	●	●	●
Sprinter	2006-	906	FP (Fuel pump)	●	●	●	●
Sprinter	2006-	906	HB (Heater booster)	●	●	●	●
Sprinter	2006-	906	HRD (Headlamp range adjustment)	●	●	●	●
Sprinter	2006-	906	IC (Instrument cluster)	●	●	●	●
Sprinter	2006-	906	KE (Keyless Entry)	●	●	●	●
Sprinter	2006-	906	LES (Left electric sliding door)	●	●	●	●
Sprinter	2006-	906	ME (Motor electronics)	●	●	●	●
Sprinter	2006-	906	OCP (Overhead control panel)	●	●	●	●
Sprinter	2006-	906	PS (Parktronic system)	●	●	●	●
Sprinter	2006-	906	PSM (Parameterizable special module)	●	●	●	●
Sprinter	2006-	906	RES (Right electric sliding door)	●	●	●	●
Sprinter	2006-	906	SAM (Signal acquisition and actuation module)	●	●	●	●
Sprinter	2006-	906	SCM (Steering column module)	●	●	●	●
Sprinter	2006-	906	SCR (Selective catalytic reduction)	●	●	●	●
Sprinter	2006-	906	SRS (Supplemental restraint system (LowLine) As of production month 12/2011)	●	●	●	●
Sprinter	2006-	906	SRS (Supplemental restraint system)	●	●	●	●
Sprinter	2006-	906	TC (Transfer case)	●	●	●	●
Sprinter	2006-	906	TCU (Trailer connection unit)	●	●	●	●
Sprinter	2006-	906	TPM (Tire pressure monitor) (As of model year 2011)	●	●	●	●
Sprinter	2006-	906	TPM (Tire pressure monitor) (Up to model year 2010)	●	●	●	●
Sprinter	2006-	906	UCP (Upper control panel)	●	●	●	●
Sprinter	2006-	906	UCP2 (Upper control panel 2)	●	●	●	●
Vito/V-Class		638	CRDI (Common rail diesel injection)	●	●	●	●
Vito/V-Class		638	ME2 (Motor electronics 2)	●	●	●	●
Vito/V-Class		638	ENG (Engine V6)	●	●	●	●
Vito/V-Class		638	ABS (Anti lock braking system)	●	●	●	●
Vito/V-Class		638	AB (Airbag)	●	●	●	●
Vito/V-Class		638	IC (Instrument cluster)	●	●	●	●
Vito/V-Class		638	HC (Heating control)	●	●	●	●
Vito/V-Class		638	HB (Heater booster)	●	●	●	●
Vito/V-Class		638	ELC (Electronic level control)	●	●	●	●
Vito/V-Class		638	APS (Auto pilot system)	●	●	●	●
Vito/V-Class		638	IMMO (Immobilizer)	●	●	●	●
Vito/V-Class		638	ATA (Anti theft alarm system)	●	●	●	●
Vito/V-Class		638	CLR (Cigar lighter relay)	●	●	●	●
Vito/Viano		639	AAC (Automatic air conditioning/Automatic temperature control/Heating-ventilation)	●	●	●	●

Vito/Viano		639	CDI4 (4 Cylinder)	●	●	●	●
Vito/Viano		639	CDI4 (6 Cylinder)	●	●	●	●
Vito/Viano		639	COMM (Commanded)	●	●	●	●
Vito/Viano		639	DCMFL (Door control module front left)	●	●	●	●
Vito/Viano		639	DCMFR (Door control module front right)	●	●	●	●
Vito/Viano		639	EHC (Electric heater control)	●	●	●	●
Vito/Viano		639	EIS (Electronic ignition switch)	●	●	●	●
Vito/Viano		639	ELC (Electronic level control)	●	●	●	●
Vito/Viano		639	ESAD (Electric seat adjustment driver)	●	●	●	●
Vito/Viano		639	ESAP (Electric seat adjustment passenger)	●	●	●	●
Vito/Viano		639	ESM (Electronic selector module)	●	●	●	●
Vito/Viano		639	ESP (Electronic stability program)	●	●	●	●
Vito/Viano		639	ETC (Electronic transmission control)	●	●	●	●
Vito/Viano		639	HRD (Headlamp range adjustment)	●	●	●	●
Vito/Viano		639	IC (Instrument cluster)	●	●	●	●
Vito/Viano		639	LESD (Left electric sliding door)	●	●	●	●
Vito/Viano		639	ME (Motor electronics)	●	●	●	●
Vito/Viano		639	OCP (Overhead control panel)	●	●	●	●
Vito/Viano		639	PS (Parktronic system)	●	●	●	●
Vito/Viano		639	PSM (Parameterizable special module) (Body manufacturer)	●	●	●	●
Vito/Viano		639	PSM (Parameterizable special module) (Electric drive)	●	●	●	●
Vito/Viano		639	PSM (Parameterizable special module) (Kerster cooling system)	●	●	●	●
Vito/Viano		639	PSM (Parameterizable special module) (Recreational vehicles)	●	●	●	●
Vito/Viano		639	PSM (Parameterizable special module) (Rental vehicle)	●	●	●	●
Vito/Viano		639	PSM (Parameterizable special module) (Taxi)	●	●	●	●
Vito/Viano		639	RACRH (Rear Air conditioning/Rear heater)	●	●	●	●
Vito/Viano		639	RESD (Right electric sliding door)	●	●	●	●
Vito/Viano		639	RSTS (Rear sliding/tilting sunroof unit)	●	●	●	●
Vito/Viano		639	SAM (Signal acquisition and actuation module)	●	●	●	●
Vito/Viano		639	SHB (Stationary heater/Heater booster)	●	●	●	●
Vito/Viano		639	SRS (Supplemental restraint system)	●	●	●	●
Vito/Viano		639	TCU (Trailer connection unit)	●	●	●	●
Vito/Viano		639	TPM (Tire pressure monitor)	●	●	●	●
Vito/Viano		639	UCP (Upper control panel)	●	●	●	●
Vaneo	2002-2005		AB (Airbag)	●	●	●	●
Vaneo	2002-2005		ACS (Automatic clutch system)	●	●	●	●
Vaneo	2002-2005		ATA (Anti theft alarm system)	●	●	●	●
Vaneo	2002-2005		ATHB (Automatic temperature/PTC-Heater booster)	●	●	●	●
Vaneo	2002-2005		CLS (Central locking system)	●	●	●	●
Vaneo	2002-2005		CRDI (Common rail diesel injection)	●	●	●	●
Vaneo	2002-2005		DAS (Drive authorization system)	●	●	●	●
Vaneo	2002-2005		ECM (Engine Control Module)	●	●	●	●
Vaneo	2002-2005		ESM (Electronic selector module)	●	●	●	●
Vaneo	2002-2005		ESP (Electronic stability program)	●	●	●	●
Vaneo	2002-2005		FTC (Front transmission control)	●	●	●	●
Vaneo	2002-2005		IC (Instrument cluster)	●	●	●	●
Vaneo	2002-2005		PS (Parktronic system)	●	●	●	●
Vaneo	2002-2005		SH (Stationary heater)	●	●	●	●

Sprinter\_V01.35 OIL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Year	Chassis	OIL
Sprinter	2002 - 2006	901.6	●
Sprinter	2002 - 2006	902.6	●
Sprinter	2002 - 2006	903.6	●
Sprinter	2002 - 2006	904.6	●
Sprinter	2002 - 2006	905.6	●
Sprinter	2006 -	906	●
Sprinter	2002 - 2006	690.6	●
Vaneo	2002 - 2005	414	●
Viano	- 2008	639	●
Viano	2008 -	639	●
Vito/V-Class		638	●
Vito/V-Class	- 2008	639	●
Vito/V-Class	2008 -	639	●