SEAT Diagnostic Function List(Note:For reference only)

NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported.▲ This function is the new feature in this version.

| ▲ This function is the new feature in t | his vers | ion. | | | | | |
|---|-------------|-------|-------|------|------------------|---------|------------|
| Vehicle | Year | | | | | | |
| Alhambra | | | | | - 2019 | | |
| Altea | 2004 - 2015 | | | | | | |
| Ateca | | | | | - 2019 | | |
| Arosa | | | | | - 2004 | | |
| Cordoba | | | | | - 2009 | | |
| Exeo | | | | | - 2014 | | |
| Ibiza | | | | | - 2019 | | |
| Inca | | | | | - 2003 | | |
| Leon Mii | | | | | - 2019 | | |
| M11 Toledo | | | | | - 2019 | | |
| Toledo | | | | | - 2010 - 2019 | | |
| ToTedo | EcuInfo | Read | Erase | Live | Actuation | Racio | |
| Systemlist | | Codes | Codes | Data | Test | Setting | Adaptation |
| 01 Engine Control Module 1 | • | • | • | • | • | • | • |
| 02 Transmission Control Module | • | • | • | • | • | • | • |
| 03 Brakes 1 | • | • | • | • | • | • | • |
| 04 Steering Angle Sender | • | • | • | • | • | • | • |
| 05 Kessy | • | • | • | • | • | 0 | 0 |
| 06 Seat Adjustment Passenger Side | • | • | • | • | • | 0 | 0 |
| 07 Display Control Unit | • | • | • | • | • | 0 | 0 |
| 08 Air Conditioning | • | • | • | • | • | • | • |
| 09 Central Electrics | • | • | • | • | • | • | • |
| OB Auxiliary Air Heater | • | • | • | • | • | 0 | 0 |
| OC Rear Axle Steering 2 | • | • | • | • | • | 0 | 0 |
| OD Sliding Door Left | • | • | • | • | • | 0 | 0 |
| OE Media Player Position 1 | • | • | • | • | • | 0 | 0 |
| OF Radio Tuner - Digital | • | • | • | • | • | 0 | 0 |
| 10 Parking Assistance 2 | • | • | • | • | • | 0 | 0 |
| 11 Engine Control Module 2 | • | • | • | • | • | 0 | 0 |
| 12 Clutch Control Unit | • | • | • | • | • | 0 | 0 |
| 13 Adaptive Cruise Control | • | • | • | • | • | 0 | 0 |
| 14 Wheel Dampening Electronics | • | • | • | • | • | 0 | 0 |
| 15 Airbag | • | • | • | • | • | • | • |
| 16 Steering Column Electronics | • | • | • | • | • | • | • |
| 17 Dash Board | • | • | • | • | • | • | • |
| 18 Auxiliary Parking Heater | • | • | • | • | • | 0 | 0 |
| 19 Gateway | • | • | • | • | • | • | • |
| 1A Fuel Cell Engine | • | • | • | • | • | 0 | 0 |
| 1B Active Steering | • | • | • | • | • | 0 | 0 |
| 1C Vehicle Position Detection | • | • | • | • | • | 0 | 0 |
| 1D Driver Identification | • | • | • | • | • | 0 | 0 |
| 1E Media Player Position 2 | • | • | • | • | • | 0 | 0 |
| 20 High Beam Assistance | • | • | • | • | • | 0 | 0 |
| 21 Battery Energy Control Module 2 | • | • | • | • | • | 0 | 0 |
| 22 All Wheel Control | • | • | • | • | • | 0 | 0 |
| 23 Brake Boost | • | • | • | • | • | 0 | 0 |
| 25 Immobilizer | • | • | • | • | • | 0 | 0 |

| 20 Electronic Book Control 27 Elegator Control Unit Rear 28 Climate Control Unit Rear 28 Climate Control Unit Rear 29 Climate Control Unit Rear 20 Climate Control Unit Rear 28 Climate Control Unit Rear 29 Climate Control Unit Rear 20 Climate Control Unit Rear 21 Climate Control Unit Rear 22 Climate Control Unit Rear 23 Rear Electronic Control Module 24 Climate Control Unit Rear 25 Climate Control Unit Rear 26 Climate Control Unit Rear 27 Rear Electronic Control Module 28 Climate Control Unit Rear 29 Climate Control Unit Rear 20 Climate Control U | 26 Flootmania Doof Control | | | • | • | • | Ιο | 0 |
|--|--|---|---|---|---|---|--|---|
| 28 Climte Control Unit Rear 29 Light Control Left 30 Special Function 2 31 Rapine Electronics Group 32 Lock Electronics Group 32 Lock Electronics Group 33 Langine Electronics Group 34 Ride Control Module 35 Sear Adjustment Bear Electronics 36 Special Function 37 Navigation 38 Special Function 39 Special Function 30 Special Function 30 Special Function 30 Special Function 30 Special Function 31 Rapine Electronics 32 Lock Electronics 33 All Office Systems 40 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 | 26 Electronic Roof Control | | | | | | + - | _ |
| 29 Light Control Left | | | | | • | | + - | |
| 28 Control Unit Wireless Charging 28 Steering Column Lacking 29 Voice Amplifier 20 O O O O O O O O O O O O O O O O O O O | | | | - | • | | + - | _ |
| 28 Steering Column Locking | | | | | • | | | _ |
| 2D Voice Amplifier | | | | | | | _ | |
| 2E Media Player Position 3 | | | - | | | | | _ |
| 30 Special Function 2 | | • | • | • | | • | | |
| 31 Engine Electronics Group | | • | • | - | | • | | _ |
| 32 Lock Electronics | | • | | | | • | | _ |
| 33 All OBD Systems 34 Ride Control System 35 Central Locking Control Module 36 Seat Adjustment Driver Side 37 Navigation 38 Roof Electronic Control Module 39 Light Control Right 30 Special Vehicle Assistant 30 Sepsial Function 30 Lane Change Assistant 30 Sepsial Function 30 Special Function 30 Special Player Position 4 30 Special Player Position 4 30 Special Player Position 4 30 Special Function 40 Air Conditioning Compressor 41 Diesel Player Electronics Septian System 43 Bremskraftunterstutzung 44 Steering Assistance 45 Longitudinal Confort System 46 Central Module Comfort System 47 Sound System 48 Seat Adjustment Rear Driver Side 48 Rear Light 48 Multifunction Module 40 Ala Transfer Car2X XXX 48 Control Hoad Rear Right 49 Central Electronics 50 Departion 51 Drive Motor Control Module 52 Door Electronics Passenger Side 53 Parking Brake 54 Rear Spoiler 55 Headlight Regulation 56 Control Head Rear Left 50 Operation 56 Control Head Rear Left | | • | • | • | • | • | _ | |
| 34 Ride Control System | | - | - | • | • | • | | |
| 36 Seart Adjustment Driver Side | | - | | | | • | + | _ |
| 38 Seat Adjustment Driver Side | | - | • | • | | • | | |
| 37 Navigation | | - | • | • | | • | _ | _ |
| 38 Roof Electronic Control Module | | - | • | • | | • | + - | _ |
| 39 Light Control Right 30 A Special Vehicle Assistant 30 Separation Sasistant 30 Separation Separation Sasistant 30 Separation Separation Sasistant 31 Separation Separation Sasistant 32 Separation Separation Sasistant 33 Separation Separatio | | - | • | • | • | • | | |
| 3A Special Vehicle Assistant 3B Sensor Electronics 3C Lane Change Assistant 3D Special Punction 3D Special Punction 3E Media Player Position 4 3F Dynamic Assembly Mounting 4D Air Conditioning Compressor 4D Dissel Pump Electronics 4D Door Electronics Driver Side 4D Door Electronics Driver Side 4D Sterring Assistance 4D S | | • | • | • | • | • | _ | _ |
| 38 Sensor Electronics 30 Clane Change Assistant 30 Special Function 30 Special Function 31 Special Function 32 Same Media Player Position 4 33 Dynamic Assembly Mounting 40 Air Conditioning Compressor 41 Diesel Pump Electronics 42 Door Electronics Driver Side 43 Bremskraftunterstutzung 44 Steering Assistance 45 Interior Monitoring 46 Central Module Comfort System 47 Sound System 48 Seat Adjustment Rear Driver Side 48 Multifunction Module 40 Air Fressure Monitoring 40 Air Fressure Monitoring 40 Company System 40 Company System 41 Deata Transfer Car2X XXX 42 Control Head Rear Right 43 Company System 44 Company System 45 Door Electronics Driver Side 46 Central Electrics 2 47 Sound System 48 Company System 49 Company System 40 Company System 40 Company System 41 Company System 42 Company System 43 Sent Adjustment Rear Passenger Side 44 Company System 45 Company System 46 Company System 47 Company System 48 Company System 49 Company System 40 Company System 40 Company System 40 Company System 41 Company System 42 Company System 43 Sent Adjustment System 44 Company System 45 Company System 46 Company System 47 Company System 48 Company System 49 Company System 40 Company System 41 Company System 41 Company System 41 Company System 42 Company System 43 Company System 44 Company System 45 Company System 46 Company System 47 Company System 48 Company System 49 Company System 40 Company | | • | • | • | | • | | |
| 3C Lane Change Assistant 3D Special Function 3D Special Function 3D Special Function 3D Media Player Position 4 3D Air Conditioning Compressor 4D On Air Conditioning Compressor 4D Data Transfer Car2XXXX 4D Data Transfer Car2XXXX 4D Data Transfer Car2XXXX 4D Control Head Rear Right 4F Central Electrics 2 5D Seat Adjustment 3rd Row 5D Farking Brake 5D Farking Brake 5D Radio Control Module 5D Farking Brake 5D Radio Control Module 5D Seat Adjustment Rear Data Control Module 5D Seat Adjustment Rear Data Control Module 5D Seat Adjustment Rear Data Control Module 5D Seat Rear Spoiler 5D Seat Adjustment Rear Data Control Module 5D Seat Adjustment Rear Passenger Side 5D Seat Adjustment Rear P | · · | • | • | • | • | • | | _ |
| 3D Special Function | | • | • | • | • | • | | _ |
| 3E Media Player Position 4 | | • | • | • | | • | | |
| 3F Dynamic Assembly Mounting | | • | • | • | • | • | | |
| 40 Air Conditioning Compressor 41 Diesel Pump Electronics 42 Door Electronics Driver Side 43 Bremskraftunterstutzung 44 Steering Assistance 45 Interior Monitoring 46 Central Module Comfort System 47 Sound System 48 Seat Adjustment Rear Driver Side 48 Rear Light 40 Cartier Pressure Monitoring 40 Cartier Pressure Monitoring 41 Diesel Pump Electronics Cartier | | • | • | • | • | • | _ | |
| 41 Diesel Pump Electronics 42 Door Electronics Driver Side 43 Bremskraftunterstutzung 44 Steering Assistance 45 Interior Monitoring 46 Central Module Comfort System 47 Sound System 48 Seat Adjustment Rear Driver Side 48 Rear Light 49 Data Transfer Car2X_XXX 40 Data Transfer Car2X_XXX 40 Control Head Rear Right 47 Control Head Rear Right 48 Control Head Rear Right 49 Control Head Rear Bright 40 Control Head Rear Bright 40 Control Head Rear Right 41 Control Head Rear Right 42 Control Head Rear Right 43 Parking Brake 44 Rear Spoiler 45 Rear Spoiler 46 Rear Spoiler 47 Control Head Rear Right 48 Control Head Rear Right 49 Control Head Rear Right 40 Control Head Rear Right 40 Control Head Rear Left 41 Control Head Rear Left 41 Control Head Rear Left 42 Control Head Rear Left 43 Control Head Rear Left 44 Control Head Rear Left | 3F Dynamic Assembly Mounting | • | • | • | • | • | | |
| 42 Door Electronics Driver Side 43 Bremskraftunterstutzung 44 Steering Assistance 45 Interior Monitoring 46 Central Module Comfort System 47 Sound System 48 Seat Adjustment Rear Driver Side 4A Rear Light 4B Multifunction Module 4C Tire Pressure Monitoring 2 4D Data Transfer Car2X_XXX 4E Control Head Rear Right 4F Central Electrics 2 50 Seat Adjustment 3rd Row 51 Drive Motor Control Module 52 Door Electronics Passenger Side 53 Parking Brake 54 Rear Spoiler 55 Headlight Regulation 56 Radio 77 TV Tuner 58 Fuel Supply 58 Lane Departure Warning System 50 Operation 55 Control Head Rear Left 56 Control Head Rear Left 57 Control Head Rear Passenger Side 58 Control Head Rear Left 59 Operation 50 Operation | 40 Air Conditioning Compressor | • | • | • | • | • | 0 | 0 |
| 43 Bremskraftunterstutzung | 41 Diesel Pump Electronics | • | • | • | • | • | 0 | 0 |
| 44 Steering Assistance | 42 Door Electronics Driver Side | • | • | • | • | • | + - | 0 |
| 45 Interior Monitoring | 43 Bremskraftunterstutzung | • | • | • | • | • | 0 | 0 |
| 46 Central Module Comfort System | 44 Steering Assistance | • | • | • | • | • | • | • |
| 47 Sound System | 45 Interior Monitoring | • | • | • | • | • | 0 | 0 |
| 48 Seat Adjustment Rear Driver Side • • • • • • • • • • • • • • • • • • • | 46 Central Module Comfort System | • | • | • | • | • | • | • |
| 4A Rear Light • • • • • • • • • • • • • • • • • • • | 47 Sound System | • | • | • | • | • | 0 | 0 |
| ## Multifunction Module ## ## ## ## ## ## ## ## ## ## ## ## ## | 48 Seat Adjustment Rear Driver Side | • | • | • | • | • | 0 | 0 |
| ### C Tire Pressure Monitoring 2 | 4A Rear Light | • | • | • | • | • | 0 | 0 |
| 4D Data Transfer Car2X_XXX ● ● ● ○ ○ 4E Control Head Rear Right ● ● ● ○ ○ 4F Central Electrics 2 ● ● ● ○ ○ 50 Seat Adjustment 3rd Row ● ● ● ○ ○ 51 Drive Motor Control Module ● ● ● ● ○ ○ 52 Door Electronics Passenger Side ● ● ● ● ● ○ ○ 53 Parking Brake ● | 4B Multifunction Module | • | • | • | • | • | 0 | 0 |
| 4E Control Head Rear Right • • • • • • • • • • • • • • • • • • • | 4C Tire Pressure Monitoring 2 | • | • | • | • | • | 0 | 0 |
| ## Central Electrics 2 | 4D Data Transfer Car2X_XXX | • | • | • | • | • | 0 | 0 |
| 50 Seat Adjustment 3rd Row ● ● ● ○ ○ 51 Drive Motor Control Module ● ● ● ○ ○ 52 Door Electronics Passenger Side ● ● ● ● ○ ○ 53 Parking Brake ● </td <td>4E Control Head Rear Right</td> <td>•</td> <td>•</td> <td>•</td> <td>•</td> <td>•</td> <td>0</td> <td>0</td> | 4E Control Head Rear Right | • | • | • | • | • | 0 | 0 |
| 51 Drive Motor Control Module • • • • • • • • • • • • • • • • • • • | 4F Central Electrics 2 | • | • | • | • | • | 0 | 0 |
| 52 Door Electronics Passenger Side ● | 50 Seat Adjustment 3rd Row | • | • | • | • | • | 0 | 0 |
| 53 Parking Brake ● | 51 Drive Motor Control Module | • | • | • | • | • | 0 | 0 |
| 54 Rear Spoiler ● ● ● ○ ○ 55 Headlight Regulation ● ● ● ● ○ ○ 56 Radio ● ● ● ● ○ ○ 57 TV Tuner ● ● ● ● ○ ○ 58 Fuel Supply ● ● ● ● ○ ○ 5A Longitudinal Control ● ● ● ● ○ ○ 5B Seat Adjustment Rear Passenger Side ● ● ● ● ○ ○ 5D Operation ● ● ● ● ● ○ ○ 5E Control Head Rear Left ● ● ● ● ○ ○ | 52 Door Electronics Passenger Side | • | • | • | • | • | 0 | 0 |
| 55 Headlight Regulation • • • • • • • • • • • • • • • • • • • | 53 Parking Brake | • | • | • | • | • | • | • |
| 56 Radio • • • • • • • • • • • • • • • • • • • | 54 Rear Spoiler | • | • | • | • | • | 0 | 0 |
| 57 TV Tuner • • • • • • • • • • • • • • • • • • • | 55 Headlight Regulation | • | • | • | • | • | 0 | 0 |
| 58 Fuel Supply • • • • • • • • • • • • • • • • • • • | 56 Radio | • | • | • | • | • | 0 | 0 |
| 5A Longitudinal Control • • • • • • • • • • • • • • • • • • • | 57 TV Tuner | • | • | • | • | • | 0 | 0 |
| 5B Seat Adjustment Rear Passenger Side • • • • • • • • • • • • • • • • • • • | 58 Fuel Supply | • | • | • | • | • | 0 | 0 |
| 5C Lane Departure Warning System • < | 5A Longitudinal Control | • | • | | • | • | 0 | 0 |
| 5C Lane Departure Warning System • • • • • • • • • • • • • • • • • • • | 5B Seat Adjustment Rear Passenger Side | • | • | • | • | • | 0 | 0 |
| 5D Operation ● ● ● ● ○ ○ 5E Control Head Rear Left ● ● ● ● ○ ○ | 5C Lane Departure Warning System | • | • | • | • | • | 0 | 0 |
| 5E Control Head Rear Left | | • | • | • | • | • | 0 | 0 |
| 5F Information Control Unit 1 | | • | • | • | • | • | 0 | 0 |
| | 5F Information Control Unit 1 | • | • | • | • | • | 0 | 0 |

| 60 Tachograph | | | • | • | • | | 0 |
|---|---|---|---|---|---|---|---|
| 61 Battery Regulation | | | | | | | |
| 62 Door Electronics Rear Left | | | | _ | | 0 | 0 |
| 63 Entry Assistance Driver Side | | | | • | | 0 | 0 |
| 64 Stabilizers | | • | | • | • | 0 | 0 |
| 65 Tire Pressure Monitoring 1 | • | • | | • | • | 0 | 0 |
| 66 Seat Adjustment Rear | | | | • | • | 0 | 0 |
| 67 Voice Control | | | | | • | 0 | 0 |
| 68 Wiper Control Unit | | • | | • | • | 0 | 0 |
| 69 Trailer Function | • | • | | • | • | 0 | 0 |
| 6A Door Automatic Rear Driver Side | • | • | | • | • | 0 | 0 |
| 6B Aerodynamics Control Unit | • | • | | • | • | 0 | 0 |
| 6C Camera System Rear View | • | • | • | • | • | 0 | 0 |
| 6D Deck Lid Control Unit | • | • | • | • | • | 0 | 0 |
| 6E Display Control Roof | • | • | • | • | • | 0 | 0 |
| 6F Central Module Comfort System 2 | • | • | • | • | • | 0 | 0 |
| 71 Battery Charger | • | • | • | • | • | 0 | 0 |
| 72 Door Electronics Rear Right | • | • | • | • | • | 0 | 0 |
| 73 Entry Assistance Passenger Side | • | • | | • | • | 0 | 0 |
| 74 Chassis Control | • | • | • | • | • | 0 | 0 |
| 75 Telematics Communication Unit | • | • | • | • | • | 0 | 0 |
| 76 Parking Assistance | • | • | • | • | • | • | • |
| 77 Telephone | • | • | • | • | • | 0 | 0 |
| 78 Sliding Door Right | • | • | • | • | • | 0 | 0 |
| 7A Door Automatic Rear Passenger Side | • | • | • | • | • | 0 | 0 |
| 7D Auxiliary Heater | • | • | • | • | • | 0 | 0 |
| 7E Dash Board Display Unit | • | • | • | • | • | 0 | 0 |
| 7F Information Control Unit 2 | • | • | • | • | • | 0 | 0 |
| 80 Battery Regulation Auxiliary Accumulator | • | • | • | • | • | 0 | 0 |
| 81 Gear Shift Control Module | • | • | • | • | • | 0 | 0 |
| 82 Head Up Display | • | • | • | • | • | 0 | 0 |
| 84 Night Vision | • | • | • | • | • | 0 | 0 |
| 85 On-Board Camera | • | • | • | • | • | 0 | 0 |
| 87 Lane Assist LT3 | • | • | • | • | • | 0 | 0 |
| 88 Multi Contour Seat Driver Side | • | • | • | • | • | 0 | 0 |
| 89 Multi Contour Seat Passenger Side | • | • | • | • | • | 0 | 0 |
| 8A Multi Contour Seat Rear Driver Side | • | • | • | • | • | 0 | 0 |
| 8B Adaptive Cruise Control 2 | • | • | • | • | • | 0 | 0 |
| 8C Battery Energy Control Module | • | • | • | • | • | 0 | 0 |
| 8D Multi Contour Seat Rear Passenger Side | • | • | • | • | • | 0 | 0 |
| 8E Image Processing Electronics | • | • | • | • | • | 0 | 0 |
| 8F Pretensioner Front Left | • | • | • | • | • | 0 | 0 |
| 90 Pretensioner Front Right | • | • | • | • | • | 0 | 0 |
| 91 Engine Control Module (ECM) | • | • | • | • | • | 0 | 0 |
| 92 Transmission Electronics | • | • | • | • | • | 0 | 0 |
| 93 Immobilizer | • | • | • | • | • | 0 | 0 |
| 94 Airbag (SRS) | • | • | • | • | • | 0 | 0 |
| 95 Electronic Stability Program | • | • | • | • | • | 0 | 0 |
| 96 Instrument Cluster | • | • | • | • | • | 0 | 0 |
| 97 Tachograph | • | • | • | • | • | 0 | 0 |
| 98 Tire Pressure Monitoring | • | • | • | • | • | 0 | 0 |
| 99 Electrical Ignition/starter Switch | • | • | • | • | • | 0 | 0 |
| 9A Remote Control | • | • | • | • | • | 0 | 0 |
| 9B Driver's Door Electronics | • | • | • | • | • | 0 | 0 |
| <u> </u> | • | • | • | | • | • | |

| 9C A/C Electronics | • | | • | | • | ΤοΙ | 0 |
|--|--------------|---|---|---|---|-----|---|
| 9D Auxiliary Heater (Fuel) | | | • | | • | 0 | 0 |
| 9E Auxiliary Heater (Electric) | • | • | • | • | • | 0 | 0 |
| 9F Parking Heater, Water | • | • | • | • | • | 0 | 0 |
| AO Audio 5 Radio. | • | • | • | • | • | 0 | 0 |
| Al Navigation | • | • | • | • | • | 0 | 0 |
| A2 CD Changer | | • | • | • | | 0 | 0 |
| A3 Telephone | | | | | | 0 | 0 |
| A5 Front Sensors Driver Assistance System | | • | • | | • | 0 | 0 |
| A6 Microphone Control Unit | | | • | | | 0 | 0 |
| A7 Infotainment Interface | | | • | | • | 0 | 0 |
| A8 External Communication Interface | | • | • | • | | 0 | 0 |
| A9 Actuator For Structure-Borne Sound | | • | • | | • | 0 | 0 |
| AA Wheel Brake Rear Right | | | | | | 0 | 0 |
| AB Wheel Brake Rear Left | | | • | | | 0 | 0 |
| AC Reductant Control Module | | | • | | | 0 | 0 |
| AD Sensors Brake Systems | | | | | | 0 | 0 |
| AE Telemetry Diagnostic Control Unit | - | | • | • | | 0 | 0 |
| BU Roof Display/control Head (Roof Control | | | | | | 0 | 0 |
| D1 Upper Operating Field | | | | | | 0 | 0 |
| B1 Upper Operating Field | | | • | | | 0 | 0 |
| B2 Parking Aid | | | | | | 0 | 0 |
| B3 Trailer Function | | | | | | 0 | 0 |
| B4 Vehicle Electrical System Control Module | | | • | | • | 0 | 0 |
| B5 Programmable Special Module | • | | | • | | 0 | 0 |
| B6 Steering Column Jacket Switch Module | _ | | _ | | | + + | |
| B7 Access Startsystem Interface B8 Electronic Roof Control 2 | | | • | | | 0 | 0 |
| | • | | | | • | 0 | 0 |
| B9 Auxiliary Display Control Unit | • | • | | • | | + + | 0 |
| BA Assembly Mounting | | • | • | | | 0 | 0 |
| BB Door Electronics Rear Driver Side | • | • | • | • | | 0 | 0 |
| BC Door Electronics Rear Passenger Side | • | • | • | • | • | 0 | 0 |
| BD High Voltage Battery Charge Management | • | • | • | • | | 0 | 0 |
| BE Sliding Door Rear Left | • | • | • | • | | 0 | 0 |
| BF Sliding Door Rear Right | • | • | • | • | | 0 | 0 |
| CO Actuator For Exterior Noise | • | • | • | • | | 0 | 0 |
| C1 Battery Regulation | • | • | • | • | | 0 | 0 |
| C2 Transmission Control Module 2 | • | • | • | • | | 0 | 0 |
| C3 Drive Motor Control Module 3 | | • | • | • | | 0 | 0 |
| C4 DC/DC Converter Control Module | • | • | • | • | | 0 | 0 |
| C5 Thermal Management | • | • | • | • | | 0 | 0 |
| C6 Battery Charger Control Module | | • | • | • | | 0 | 0 |
| C7 Pedestrian Protection | • | • | • | • | | 0 | 0 |
| C8 Auxiliary Display Control Unit 2 | | • | • | • | | 0 | 0 |
| C9 Rear Mirror | | | • | • | • | 0 | 0 |
| CA Control Module For Sunroof | • | | • | • | | 0 | 0 |
| CB Rear Axle Steering | | | • | • | | 0 | 0 |
| CC Starter / Generator Control Module | _ | | • | | | 0 | 0 |
| CD Laser Scanner | | | | | | 0 | 0 |
| CE Drive Motor Control Module 2 | • | | • | | | 0 | 0 |
| CF Control Unit Lane Change Assistant 2 | • | • | • | • | • | 0 | 0 |
| DO Front Axle Lift System | • | | - | • | | 0 | 0 |
| D1 Center Display | • | • | • | • | • | 0 | 0 |
| D2 Sliding Door Left | • | • | • | • | • | 0 | 0 |
| D3 Sliding Door Right | • | | | | • | 0 | 0 |

| D4 Roll Control System 1 | • | • | • | • | • | 0 | 0 |
|--|---|---|---|---|---|---|---|
| D5 Roll Control System 2 | • | • | • | • | • | 0 | 0 |
| D6 Light Control Left 2 | • | • | • | • | • | 0 | 0 |
| D7 Light Control Right 2 | • | • | • | • | • | 0 | 0 |
| D8 Projection Module in Left Matrix Headlamp | • | • | • | • | • | 0 | 0 |
| D9 Projection Module in Right Matrix | • | • | • | • | • | 0 | 0 |
| DB Front Corner Radar 1 | • | • | • | • | • | 0 | 0 |
| DC Front Corner Radar 2 | • | • | • | • | • | 0 | 0 |
| DD Control Module 2 For Sunroof | • | • | • | • | • | 0 | 0 |
| DE Charger 1 Mobile Devices | • | • | • | • | • | 0 | 0 |
| DF Charger 2 Mobile Devices | • | • | • | • | • | 0 | 0 |
| EO Auxiliary Display Control Unit 1 | • | • | • | • | • | 0 | 0 |
| EF Reference Control Unit | • | • | • | • | • | 0 | 0 |

SEAT BMS Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | Year | BMS |
|----------|-------------|-----|
| ALHAMBRA | 2001 - 2019 | |
| Altea | 2004 - 2015 | • |
| Ateca | 2017 - 2019 | |
| Leon | 2000 - 2019 | • |
| Mii | 2012 - 2019 | • |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | • |

BMS Function List

Configure new battery parameter

| SEAT DPF Function List(Note:For reference only) | | | | |
|--|--|--|--|--|
| NOTES: | | | | |
| • This function is supported. (Except that the electronic control unit not equipped) | | | | |
| * This function may be supported, which depends on the actual condition of the | | | | |
| O This function is not supported. | | | | |
| ▲ This function is the new feature in this version. | | | | |
| Vehicle Year DPF | | | | |
| LEON 2000 - 2019 | | | | |
| DPF Function List | | | | |
| DPF Check | | | | |
| DPF Matching | | | | |
| DPF Regeneration | | | | |

SEAT EPB Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | Year | EPB |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | • |
| Altea | 2004 - 2015 | • |
| Ateca | 2017 - 2019 | • |
| Arosa | 2001 - 2004 | • |
| Cordoba | 1999 - 2009 | • |
| Exeo | 2009 - 2014 | • |
| Ibiza | 1999 - 2019 | • |
| Inca | 2001 - 2003 | • |
| Leon | 2000 - 2019 | • |
| Mii | 2012 - 2019 | • |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | • |

EPB Function List

Open Rear Brake Calipers(Ready to change brake pads) Close Rear Brake Calipers(After replacement of brake pads)

SEAT ETC Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- * This function may be supported, which depends on the actual condition of the O This function is not supported.
- ▲ This function is the new feature in this version.

| 77 1 . 1 | 37 | I DTC |
|----------|-------------|-------|
| Vehicle | Year | ETC |
| Alhambra | 2001 - 2019 | • |
| Altea | 2004 - 2015 | • |
| Ateca | 2017 - 2019 | • |
| Arosa | 2001 - 2004 | |
| Cordoba | 1999 - 2009 | • |
| Exeo | 2009 - 2014 | • |
| Ibiza | 1999 - 2019 | • |
| Inca | 2001 - 2003 | |
| Leon | 2000 - 2019 | • |
| Mii | 2012 - 2019 | • |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | • |

ETC Function List

Electronic throttle sensor reset

| S | SEAT INJ Function List(Note:For reference only) | | | | |
|--|---|---|--|--|--|
| NOTES: | | | | | |
| ● This function is supported. (Except that the electronic control unit not equipped) | | | | | |
| ₩ This fund | ction may be suppo | orted, which depends on the actual condition of the | | | |
| O This fund | ction is not suppo | orted. | | | |
| ▲ This fund | ction is the new t | feature in this version. | | | |
| Vehicle | Year | INJ | | | |
| LEON | 2000 - 2019 | • | | | |
| | INJ Function List | | | | |
| Injector matching | | | | | |

SEAT LAP Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- ** This function may be supported, which depends on the actual condition of the O This function is not supported.
- ▲ This function is the new feature in this version.

| This rune | cion is the new . | reactive in this version. |
|-----------|-------------------|---------------------------|
| Vehicle | Year | LAP |
| Alhambra | 2001 - 2019 | * |
| Altea | 2004 - 2015 | * |
| Arosa | 2001 - 2004 | * |
| Cordoba | 1999 - 2009 | * |
| Exeo | 2009 - 2014 | * |
| Ibiza | 1999 - 2019 | * |
| Inca | 2001 - 2003 | * |
| Leon | 2000 - 2019 | * |
| Mii | 2012 - 2019 | * |
| Toledo | 1999 - 2010 | * |
| Toledo | 2013 - 2019 | * |

LAP Function List

Headlamp Adjustment

SEAT OIL Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- lpha This function may be supported, which depends on the actual condition of the
- O This function is not supported.
- lacktriangle This function is the new feature in this version.

| Vehicle | Year | OIL |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | • |
| Altea | 2004 - 2015 | • |
| Arosa | 2001 - 2004 | • |
| Cordoba | 1999 - 2009 | • |
| Exeo | 2009 - 2014 | • |
| Ibiza | 1999 - 2019 | • |
| Inca | 2001 - 2003 | |
| Leon | 2000 - 2019 | • |
| Mii | 2012 - 2019 | • |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | |

OIL Function List

Adapting Vehicle To Fixed Interval

Adapting Vehicle To Flexible Service Interval

SEAT SAS Function List (Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- lepha This function may be supported, which depends on the actual condition of the
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | Year | SAS |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | • |
| Altea | 2004 - 2015 | • |
| Arosa | 2001 - 2004 | • |
| Cordoba | 1999 - 2009 | |
| Exeo | 2009 - 2014 | • |
| Ibiza | 1999 - 2019 | • |
| Inca | 2001 - 2003 | • |
| Leon | 2000 - 2019 | • |
| Mii | 2012 - 2019 | • |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | • |

SAS Function List

Steering Angle Learning

SEAT SPS Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- lpha This function may be supported, which depends on the actual condition of the
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | Year | SPS |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | * |
| Altea | 2004 - 2015 | * |
| Arosa | 2001 - 2004 | * |
| Cordoba | 1999 - 2009 | * |
| Exeo | 2009 - 2014 | * |
| Ibiza | 1999 - 2019 | * |
| Inca | 2001 - 2003 | * |
| Leon | 2000 - 2019 | * |
| Mii | 2012 - 2019 | * |
| Toledo | 1999 - 2010 | * |
| Toledo | 2013 - 2019 | * |

SPS Function List

Air Suspension Matching