

# FUNCTION LIST

CR Genius

Ford

**iCarsoft** Europe

FORD Diagnostic Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	Systemlist	EcuInfo.	ReadCodes	EraseCodes	LiveData	ActTest
Aspire	1996-1997	PCM	●	●	●	●	※
B-Max	ALL	RCM	●	●	●	●	●
B-Max	ALL	PCM	●	●	●	●	●
B-Max	ALL	DDM	●	●	●	●	※
B-Max	ALL	PDM	●	●	●	●	●
B-Max	ALL	ABS	●	●	●	●	●
B-Max	ALL	BCMII	●	●	●	●	※
B-Max	ALL	ACM	●	●	●	●	●
B-Max	ALL	IPC	●	●	●	●	●
B-Max	ALL	PSCM	●	●	●	●	●
Bantam	ALL	PCM	●	●	●	●	●
Bantam	ALL	ECS	●	●	●	●	●
Bantam	ALL	ABS/TCS	●	●	●	●	●
Bantam	ALL	HEC	●	●	●	●	※
Bantam	ALL	GEM	●	●	●	●	※
Blue Bird	2012-2013	PCM	●	●	●	●	※
Bravo	ALL	ABS/TCS	●	●	●	●	※
Bravo	ALL	PCM	●	●	●	●	●
C-MAX	2013-2018	PCM	●	●	●	●	●
C-MAX	2013-2018	ABS	●	●	●	●	●
C-MAX	2013-2018	RGTM	●	●	●	●	●
C-MAX	2013-2018	BECM	●	●	●	●	●
C-MAX	2013-2018	DDM	●	●	●	●	●
C-MAX	2013-2018	PDM	●	●	●	●	●
C-MAX	2013-2018	BCMII	●	●	●	●	●
C-MAX	2013-2018	OCSM	●	●	●	●	●
Cargo	2009-2012	TBM	●	●	●	●	※
CF/LCF	2006-2009	ABS/TCS	●	●	●	●	●
Contour	1996-2000	PCM	●	●	●	●	●
Contour	1996-2000	ABS/TCS	●	●	●	●	●
Cougar	1998-2002	PCM	●	●	●	●	●
Cougar	1998-2002	ABS/TCS	●	●	●	●	●
Courier	1998-2001	PCM	●	●	●	●	※
Courier	1998-2001	GEM	●	●	●	●	※
Courier	1998-2001	RAP	●	●	●	●	※
Courier	1998-2001	ABS/TCS	●	●	●	●	●
Crown Victoria	1995-2011	ABS/TCS	●	●	●	●	●
Crown Victoria	1995-2011	PATS	●	●	●	●	※
Crown Victoria	1995-2011	PCM	●	●	●	●	●
Crown Victoria	1995-2011	RCM	●	●	●	●	●

Crown Victoria	1995-2011	ABS	●	●	●	●	●
Crown Victoria	1995-2011	VDM	●	●	●	●	●
Crown Victoria	1995-2011	DDM	●	●	●	●	●
E-Series	1995-2016	PCM	●	●	●	●	●
E-Series	1995-2016	ABS/TCS	●	●	●	●	●
E-Series	1995-2016	ABS	●	●	●	●	●
E-Series	1995-2016	IC	●	●	●	●	※
E-Series	1995-2016	VSM	●	●	●	●	※
E-Series	1995-2016	ACM	●	●	●	●	●
E-Series	1995-2016	TBC	●	●	●	●	●
E-Series	1995-2016	IPC	●	●	●	●	●
E-Series	1995-2016	RCM	●	●	●	●	●
E-Series	1995-2016	GEM/SJB	●	●	●	●	※
Econovan	ALL	PCM	●	●	●	●	●
Econovan	ALL	IC	●	●	●	●	●
EcoSport	2003-2014	PCM	●	●	●	●	●
EcoSport	2003-2014	ABS/TCS	●	●	●	●	●
EcoSport	2003-2014	RKE	●	●	●	●	●
EcoSport	2003-2014	ABS	●	●	●	●	●
EcoSport	2003-2014	PSCM	●	●	●	●	●
EcoSport	2003-2014	IPC	●	●	●	●	●
EcoSport	2003-2014	TBM	●	●	●	●	●
EcoSport	2003-2014	RFA	●	●	●	●	●
EcoSport	2003-2014	BCMII	●	●	●	●	●
EcoSport	2003-2014	RCM	●	●	●	●	※
Edge	2007-2019	RCM	●	●	●	●	●
Edge	2007-2019	IC	●	●	●	●	●
Edge	2007-2019	PCM	●	●	●	●	●
Edge	2007-2019	ACM	●	●	●	●	●
Edge	2007-2019	GEM/SJB	●	●	●	●	※
Edge	2007-2019	TBM	●	●	●	●	●
Edge	2007-2019	ABS	●	●	●	●	●
Edge	2007-2019	OCSM	●	●	●	●	●
Edge	2007-2019	RFA	●	●	●	●	※
Edge	2007-2019	BCMII	●	●	●	●	●
Edge	2007-2019	IPC	●	●	●	●	●
Edge	2007-2019	C-CM	●	●	●	●	※
Edge	2007-2019	SASM	●	●	●	●	●
Edge	2007-2019	SECM	●	●	●	●	●
Edge	2007-2019	DSM	●	●	●	●	●
Endeavour	ALL	PCM	●	●	●	●	●
Escape	2001-2019	PSCM	●	●	●	●	●
Escape	2001-2019	IC	●	●	●	●	●
Escape	2001-2019	ACM	●	●	●	●	●
Escape	2001-2019	OCSM	●	●	●	●	●
Escape	2001-2019	GEM/SJB	●	●	●	●	※
Escape	2001-2019	PCM	●	●	●	●	●
Escape	2001-2019	ABS	●	●	●	●	●
Escape	2001-2019	RGTM	●	●	●	●	※

Escape	2001-2019	DDM	●	●	●	●	●
Escape	2001-2019	PDM	●	●	●	●	●
Escape	2001-2019	BCMII	●	●	●	●	●
Escape	2001-2019	RFA	●	●	●	●	※
Escape	2001-2019	DSM	●	●	●	●	●
Escort	1992-1998	ABS/TCS	●	●	●	●	●
Escort	1992-2003	RAP	●	●	●	●	※
Escort	1997-2003	PCM	●	●	●	●	※
Everest	ALL	PCM	●	●	●	●	●
Excursion	2000-2005	GEM	●	●	●	●	※
Excursion	2000-2005	ABS/TCS	●	●	●	●	●
Excursion	2000-2005	PATS	●	●	●	●	※
Excursion	2000-2005	VSM	●	●	●	●	※
Excursion	2000-2005	PAM	●	●	●	●	●
Excursion	2000-2005	EATC	●	●	●	●	※
Excursion	2000-2005	DSM	●	●	●	●	●
Excursion	2000-2005	HEC	●	●	●	●	●
Excursion	2000-2005	RCM	●	●	●	●	●
Excursion	2000-2005	PCM	●	●	●	●	●
Expedition	1997-2015	GEM	●	●	●	●	※
Expedition	1997-2015	ABS/TCS	●	●	●	●	●
Expedition	1997-2015	RAP	●	●	●	●	※
Expedition	1997-2015	HEC	●	●	●	●	※
Expedition	1997-2015	4WAS	●	●	●	●	●
Expedition	1997-2015	PCM	●	●	●	●	※
Expedition	1997-2015	RCM	●	●	●	●	●
Expedition	1997-2015	VDM	●	●	●	●	※
Expedition	1997-2015	VSM	●	●	●	●	※
Expedition	1997-2015	PAM	●	●	●	●	●
Expedition	1997-2015	4X4	●	●	●	●	※
Expedition	1997-2015	EATC	●	●	●	●	●
Expedition	1997-2015	DCSM	●	●	●	●	※
Expedition	1997-2015	DSM	●	●	●	●	●
Expedition	1997-2015	PCSM	●	●	●	●	●
Expedition	1997-2015	TPM	●	●	●	●	●
Expedition	1997-2015	BCMII	●	●	●	●	●
Expedition	1997-2015	RFA	●	●	●	●	※
Expedition	1997-2015	ABS	●	●	●	●	●
Expedition EL	2007-2014	VDM	●	●	●	●	●
Expedition EL	2007-2014	GEM/SJB	●	●	●	●	※
Expedition EL	2007-2014	ABS	●	●	●	●	●
Expedition EL	2007-2014	PCM	●	●	●	●	●
Expedition EL	2007-2014	IC	●	●	●	●	※
Expedition EL	2007-2014	TBC	●	●	●	●	●
Expedition EL	2007-2014	PRB	●	●	●	●	●
Expedition EL	2007-2014	RCU	●	●	●	●	●
Expedition EL	2007-2014	HVAC	●	●	●	●	●
Expedition EL	2007-2014	LTM	●	●	●	●	●
Expedition EL	2007-2014	DCSM	●	●	●	●	●

Expedition EL	2007-2014	DSM	●	●	●	●	●
Expedition EL	2007-2014	TCCM	●	●	●	●	●
Expedition EL	2007-2014	DSP	●	●	●	●	※
Expedition EL	2007-2014	APIM	●	●	●	●	●
Expedition EL	2007-2014	SDARS	●	●	●	●	●
Expedition EL	2007-2014	RCM	●	●	●	●	●
Expedition EL	2007-2014	ACM	●	●	●	●	●
Expedition EL	2007-2014	PAM	●	●	●	●	●
Expedition EL	2007-2014	GPSM	●	●	●	●	●
Explorer	1996-2019	ABS/TCS	●	●	●	●	●
Explorer	1996-2019	PATS	●	●	●	●	※
Explorer	1996-2019	RAP	●	●	●	●	※
Explorer	1996-2019	ARC	●	●	●	●	●
Explorer	1996-2019	PCM	●	●	●	●	※
Explorer	1996-2019	GEM	●	●	●	●	※
Explorer	1996-2019	EATC	●	●	●	●	●
Explorer	1996-2019	DSM	●	●	●	●	●
Explorer	1996-2019	PAM	●	●	●	●	●
Explorer	1996-2019	RCM	●	●	●	●	●
Explorer	1996-2019	VSM	●	●	●	●	※
Explorer	1996-2019	4X4	●	●	●	●	※
Explorer	1996-2019	IC	●	●	●	●	●
Explorer	1996-2019	TPM	●	●	●	●	●
Explorer	1996-2019	OCSM	●	●	●	●	●
Explorer	1996-2019	ACM	●	●	●	●	●
Explorer	1996-2019	PRB	●	●	●	●	●
Explorer	1996-2019	HVAC	●	●	●	●	※
Explorer	1996-2019	APIM	●	●	●	●	●
Explorer	1996-2019	RETM	●	●	●	●	※
Explorer	1996-2019	SDARS	●	●	●	●	※
Explorer	1996-2019	GPSM	●	●	●	●	●
Explorer	1996-2019	C-CM	●	●	●	●	※
Explorer	1996-2019	RFA	●	●	●	●	※
Explorer	1996-2019	IPM-A	●	●	●	●	●
Explorer	1996-2019	IPC	●	●	●	●	●
Explorer	1996-2019	TCM	●	●	●	●	●
Explorer	1996-2019	BCMII	●	●	●	●	●
Explorer	1996-2019	PSCM	●	●	●	●	●
Explorer	1996-2019	HSWM	●	●	●	●	※
Explorer	1996-2019	LTM	●	●	●	●	※
Explorer	1996-2019	DCSM	●	●	●	●	●
Explorer	1996-2019	HUD	●	●	●	●	●
Explorer	1996-2019	FCIM	●	●	●	●	※
Explorer	1996-2019	FLM	●	●	●	●	※
Explorer	1996-2019	SOD-R	●	●	●	●	●
Explorer	1996-2019	SOD-L	●	●	●	●	●
Explorer	1996-2019	RLCM_A	●	●	●	●	※
Explorer	1996-2019	ATCM	●	●	●	●	●
Explorer	1996-2019	CLM	●	●	●	●	※

Explorer	1996-2019	RTM	●	●	●	●	●
Explorer	1996-2019	GFM	●	●	●	●	※
Explorer	1996-2019	FCDIM	●	●	●	●	※
Explorer	1996-2019	SCCM	●	●	●	●	●
Explorer	1996-2019	HCM	●	●	●	●	●
Explorer	1996-2019	RHVAC	●	●	●	●	●
Explorer	1996-2019	FCIM-B	●	●	●	●	●
Explorer	1996-2019	DSP	●	●	●	●	●
Explorer	1996-2019	SCM-E	●	●	●	●	●
Explorer	1996-2019	DACM-C	●	●	●	●	●
Explorer	1996-2019	BECM-B	●	●	●	●	●
Explorer	1996-2019	GWM	●	●	●	●	※
Explorer	1996-2019	TCU1	●	●	●	●	●
Explorer	1996-2019	DDM	●	●	●	●	●
Explorer	1996-2019	PDM	●	●	●	●	●
Explorer	1996-2019	SCM-G	●	●	●	●	●
Explorer	1996-2019	SCM-H	●	●	●	●	●
Explorer	1996-2019	RGTM	●	●	●	●	●
Explorer	1996-2019	IPM-B	●	●	●	●	※
Explorer Sport	2000-2003	GEM	●	●	●	●	※
Explorer Sport	2000-2003	ABS/TCS	●	●	●	●	●
Explorer Sport	2000-2003	RAP	●	●	●	●	※
Explorer Sport	2000-2003	RCM	●	●	●	●	●
Explorer Sport	2000-2003	4X4	●	●	●	●	※
Explorer Sport	2000-2003	PCM	●	●	●	●	※
Explorer SportTrac	2000-2005	ABS/TCS	●	●	●	●	●
Explorer SportTrac	2000-2005	RAP	●	●	●	●	●
Explorer SportTrac	2000-2005	RCM	●	●	●	●	●
Explorer SportTrac	2000-2005	HEC	●	●	●	●	●
Explorer SportTrac	2000-2005	4X4	●	●	●	●	●
Explorer SportTrac	2000-2005	PCM	●	●	●	●	●
Explorer SportTrac	2007-2010	4X4	●	●	●	●	●
Explorer SportTrac	2007-2010	PCM	●	●	●	●	●
Explorer SportTrac	2007-2010	RETM	●	●	●	●	●
Explorer SportTrac	2007-2010	PAM	●	●	●	●	●
Explorer SportTrac	2007-2010	RCM	●	●	●	●	●
Explorer SportTrac	2007-2010	OCSM	●	●	●	●	●
Explorer SportTrac	2007-2010	HVAC	●	●	●	●	●
Explorer SportTrac	2007-2010	ACM	●	●	●	●	●
Explorer SportTrac	2007-2010	APIM	●	●	●	●	●
Explorer SportTrac	2007-2010	ABS	●	●	●	●	●
Explorer SportTrac	2007-2010	ACM	●	●	●	●	●
Explorer SportTrac	2007-2010	IC	●	●	●	●	●
Explorer SportTrac	2007-2010	GEM/SJB	●	●	●	●	●
Explorer SportTrac	2007-2010	SDARS	●	●	●	●	●
Explorer SportTrac	2007-2010	GPSM	●	●	●	●	●
F-150	1997-2002	GEM	●	●	●	●	●
F-150	1997-2002	ABS/TCS	●	●	●	●	●
F-150	1997-2002	RAP	●	●	●	●	●

F-150	1997-2002	RCM	●	●	●	●	●
F-150	1997-2002	IC	●	●	●	●	●
F-150	1997-2002	PCM	●	●	●	●	●
F-150	2003-2019	IPC	●	●	●	●	※
F-150	2003-2019	ABS	●	●	●	●	●
F-150	2003-2019	PCM	●	●	●	●	●
F-150	2003-2019	BCMII	●	●	●	●	●
F-150	2003-2019	OCSM	●	●	●	●	●
F-150	2003-2019	TBC	●	●	●	●	●
F-150	2003-2019	PRB	●	●	●	●	●
F-150	2003-2019	FDIM	●	●	●	●	※
F-150	2003-2019	TCCM	●	●	●	●	※
F-150	2003-2019	DCSM	●	●	●	●	※
F-150	2003-2019	DSM	●	●	●	●	●
F-150	2003-2019	APIM	●	●	●	●	●
F-150	2003-2019	RCM	●	●	●	●	●
F-150	2003-2019	PSCM	●	●	●	●	●
F-150	2003-2019	PAM	●	●	●	●	●
F-150	2003-2019	RTM	●	●	●	●	※
F-150	2003-2019	DSP	●	●	●	●	※
F-150	2003-2019	HVAC	●	●	●	●	※
F-150	2003-2019	SCCM	●	●	●	●	●
F-150	2003-2019	GPSM	●	●	●	●	●
F-150	2003-2019	ACM	●	●	●	●	●
F-150	2003-2019	FCDIM	●	●	●	●	●
F-150	2003-2019	FCIM	●	●	●	●	●
F-250	1997-2002	GEM	●	●	●	●	●
F-250	1997-2002	ABS/TCS	●	●	●	●	●
F-250	1997-2002	RAP	●	●	●	●	●
F-250	1997-2002	RCM	●	●	●	●	●
F-250	1997-2002	IC	●	●	●	●	●
F-250	1997-2002	PCM	●	●	●	●	●
F-250	2003-2019	IPC	●	●	●	●	※
F-250	2003-2019	ABS	●	●	●	●	●
F-250	2003-2019	PCM	●	●	●	●	●
F-250	2003-2019	BCMII	●	●	●	●	●
F-250	2003-2019	OCSM	●	●	●	●	●
F-250	2003-2019	TBC	●	●	●	●	●
F-250	2003-2019	PRB	●	●	●	●	●
F-250	2003-2019	FDIM	●	●	●	●	※
F-250	2003-2019	TCCM	●	●	●	●	※
F-250	2003-2019	DCSM	●	●	●	●	※
F-250	2003-2019	DSM	●	●	●	●	●
F-250	2003-2019	APIM	●	●	●	●	●
F-250	2003-2019	RCM	●	●	●	●	●
F-250	2003-2019	PSCM	●	●	●	●	●
F-250	2003-2019	PAM	●	●	●	●	●
F-250	2003-2019	RTM	●	●	●	●	※
F-250	2003-2019	DSP	●	●	●	●	※

F-250	2003-2019	HVAC	●	●	●	●	※
F-250	2003-2019	SCCM	●	●	●	●	●
F-250	2003-2019	GPSM	●	●	●	●	●
F-250	2003-2019	ACM	●	●	●	●	●
F-250	2003-2019	FCDIM	●	●	●	●	●
F-250	2003-2019	FCIM	●	●	●	●	●
F-350	1997-2002	GEM	●	●	●	●	●
F-350	1997-2002	ABS/TCS	●	●	●	●	●
F-350	1997-2002	RAP	●	●	●	●	●
F-350	1997-2002	RCM	●	●	●	●	●
F-350	1997-2002	IC	●	●	●	●	●
F-350	1997-2002	PCM	●	●	●	●	●
F-350	2003-2019	IPC	●	●	●	●	※
F-350	2003-2019	ABS	●	●	●	●	●
F-350	2003-2019	PCM	●	●	●	●	●
F-350	2003-2019	BCMII	●	●	●	●	●
F-350	2003-2019	OCSM	●	●	●	●	●
F-350	2003-2019	TBC	●	●	●	●	●
F-350	2003-2019	PRB	●	●	●	●	●
F-350	2003-2019	FDIM	●	●	●	●	※
F-350	2003-2019	TCCM	●	●	●	●	※
F-350	2003-2019	DCSM	●	●	●	●	※
F-350	2003-2019	DSM	●	●	●	●	●
F-350	2003-2019	APIM	●	●	●	●	●
F-350	2003-2019	RCM	●	●	●	●	●
F-350	2003-2019	PSCM	●	●	●	●	●
F-350	2003-2019	PAM	●	●	●	●	●
F-350	2003-2019	RTM	●	●	●	●	※
F-350	2003-2019	DSP	●	●	●	●	※
F-350	2003-2019	HVAC	●	●	●	●	※
F-350	2003-2019	SCCM	●	●	●	●	●
F-350	2003-2019	GPSM	●	●	●	●	●
F-350	2003-2019	ACM	●	●	●	●	●
F-350	2003-2019	FCDIM	●	●	●	●	●
F-350	2003-2019	FCIM	●	●	●	●	●
F-650	1997-2002	GEM	●	●	●	●	●
F-650	1997-2002	ABS/TCS	●	●	●	●	●
F-650	1997-2002	RAP	●	●	●	●	●
F-650	1997-2002	RCM	●	●	●	●	●
F-650	1997-2002	IC	●	●	●	●	●
F-650	1997-2002	PCM	●	●	●	●	●
F-650	2003-2019	IPC	●	●	●	●	※
F-650	2003-2019	ABS	●	●	●	●	●
F-650	2003-2019	PCM	●	●	●	●	●
F-650	2003-2019	BCMII	●	●	●	●	●
F-650	2003-2019	OCSM	●	●	●	●	●
F-650	2003-2019	TBC	●	●	●	●	●
F-650	2003-2019	PRB	●	●	●	●	●
F-650	2003-2019	FDIM	●	●	●	●	※

F-650	2003-2019	TCCM	●	●	●	●	※
F-650	2003-2019	DCSM	●	●	●	●	※
F-650	2003-2019	DSM	●	●	●	●	●
F-650	2003-2019	APIM	●	●	●	●	●
F-650	2003-2019	RCM	●	●	●	●	●
F-650	2003-2019	PSCM	●	●	●	●	●
F-650	2003-2019	PAM	●	●	●	●	●
F-650	2003-2019	RTM	●	●	●	●	※
F-650	2003-2019	DSP	●	●	●	●	※
F-650	2003-2019	HVAC	●	●	●	●	※
F-650	2003-2019	SCCM	●	●	●	●	●
F-650	2003-2019	GPSM	●	●	●	●	●
F-650	2003-2019	ACM	●	●	●	●	●
F-650	2003-2019	FCDIM	●	●	●	●	●
F-650	2003-2019	FCIM	●	●	●	●	●
F-750	1997-2002	GEM	●	●	●	●	●
F-750	1997-2002	ABS/TCS	●	●	●	●	●
F-750	1997-2002	RAP	●	●	●	●	●
F-750	1997-2002	RCM	●	●	●	●	●
F-750	1997-2002	IC	●	●	●	●	●
F-750	1997-2002	PCM	●	●	●	●	●
F-750	2003-2019	IPC	●	●	●	●	※
F-750	2003-2019	ABS	●	●	●	●	●
F-750	2003-2019	PCM	●	●	●	●	●
F-750	2003-2019	BCMII	●	●	●	●	●
F-750	2003-2019	OCSM	●	●	●	●	●
F-750	2003-2019	TBC	●	●	●	●	●
F-750	2003-2019	PRB	●	●	●	●	●
F-750	2003-2019	FDIM	●	●	●	●	※
F-750	2003-2019	TCCM	●	●	●	●	※
F-750	2003-2019	DCSM	●	●	●	●	※
F-750	2003-2019	DSM	●	●	●	●	●
F-750	2003-2019	APIM	●	●	●	●	●
F-750	2003-2019	RCM	●	●	●	●	●
F-750	2003-2019	PSCM	●	●	●	●	●
F-750	2003-2019	PAM	●	●	●	●	●
F-750	2003-2019	RTM	●	●	●	●	※
F-750	2003-2019	DSP	●	●	●	●	※
F-750	2003-2019	HVAC	●	●	●	●	※
F-750	2003-2019	SCCM	●	●	●	●	●
F-750	2003-2019	GPSM	●	●	●	●	●
F-750	2003-2019	ACM	●	●	●	●	●
F-750	2003-2019	FCDIM	●	●	●	●	●
F-750	2003-2019	FCIM	●	●	●	●	●
Fairlane/LTD	2003-2006	PCM	●	●	●	●	●
Fairlane/LTD	2003-2006	TCM	●	●	●	●	●
Fairlane/LTD	2003-2006	IC	●	●	●	●	※
Fairlane/LTD	2003-2006	ACM	●	●	●	●	※
Fairlane/LTD	2003-2006	BEM	●	●	●	●	※

Fairlane/LTD	2003-2006	ABS/TCS	●	●	●	●	●
Fairlane/LTD	2003-2006	PAM	●	●	●	●	●
Fairlane/LTD	2003-2006	RCM	●	●	●	●	●
Fairlane/LTD	2003-2006	HIM	●	●	●	●	※
Fairmont	2003-2006	PCM	●	●	●	●	●
Fairmont	2003-2006	TCM	●	●	●	●	●
Fairmont	2003-2006	IC	●	●	●	●	●
Fairmont	2003-2006	ACM	●	●	●	●	●
Fairmont	2003-2006	BEM	●	●	●	●	●
Fairmont	2003-2006	ABS/TCS	●	●	●	●	●
Fairmont	2003-2006	PAM	●	●	●	●	●
Fairmont	2003-2006	RCM	●	●	●	●	●
Fairmont	2003-2006	HIM	●	●	●	●	※
Falcon	2003-2014	BEM	●	●	●	●	※
Falcon	2003-2014	PCM	●	●	●	●	●
Falcon	2003-2014	ABS	●	●	●	●	●
Falcon	2003-2014	APIM	●	●	●	●	●
Falcon	2003-2014	HIM	●	●	●	●	※
Falcon	2003-2014	GWM	●	●	●	●	●
Falcon	2003-2014	PAM	●	●	●	●	●
Falcon	2003-2014	ACM	●	●	●	●	●
Falcon	2003-2014	IPC	●	●	●	●	●
Falcon	2003-2014	FCIM	●	●	●	●	●
Falcon	2003-2014	GPSM	●	●	●	●	●
Falcon	2003-2014	RCM	●	●	●	●	●
Festiva	ALL	PCM	●	●	●	●	●
Festiva Sedan	ALL	PCM	●	●	●	●	●
Fiesta	1996-2000	PCM	●	●	●	●	●
Fiesta	1996-2000	ABS/TCS	●	●	●	●	●
Fiesta	1996-2000	GEM	●	●	●	●	●
Fiesta	1996-2000	HEC	●	●	●	●	※
Fiesta	1996-2000	ECS	●	●	●	●	※
Fiesta	2001-2007	ABS/TCS	●	●	●	●	●
Fiesta	2001-2007	GEM	●	●	●	●	●
Fiesta	2001-2007	PCM	●	●	●	●	●
Fiesta	2001-2007	EATC	●	●	●	●	※
Fiesta	2001-2007	RCM	●	●	●	●	●
Fiesta	2001-2007	ACM	●	●	●	●	●
Fiesta	2001-2007	SRM	●	●	●	●	※
Fiesta	2001-2007	IC	●	●	●	●	●
Fiesta	2008-2018	BCMII	●	●	●	●	※
Fiesta	2008-2018	PCM	●	●	●	●	●
Fiesta	2008-2018	ABS	●	●	●	●	●
Fiesta	2008-2018	RCM	●	●	●	●	※
Fiesta	2008-2018	PSCM	●	●	●	●	●
Fiesta	2008-2018	FCDIM	●	●	●	●	※
Fiesta	2008-2018	IPC	●	●	●	●	●
Fiesta	2008-2018	RFA	●	●	●	●	※
Fiesta	2008-2018	APIM	●	●	●	●	●

Fiesta	2008-2018	FDSM	●	●	●	●	※
Fiesta	2008-2018	GPSM	●	●	●	●	※
Fiesta	2008-2018	DDM	●	●	●	●	●
Fiesta	2008-2018	PDM	●	●	●	●	●
Fiesta	2008-2018	HVAC	●	●	●	●	※
Fiesta	2008-2018	ACM	●	●	●	●	●
Fiesta	2008-2018	TCU1	●	●	●	●	●
FIGO	2010-2018	ABS	●	●	●	●	●
FIGO	2010-2018	PCM	●	●	●	●	●
FIGO	2010-2018	GPSM	●	●	●	●	●
FIGO	2010-2018	PAM	●	●	●	●	●
FIGO	2010-2018	PSCM	●	●	●	●	●
FIGO	2010-2018	HVAC	●	●	●	●	※
FIGO	2010-2018	RCM	●	●	●	●	●
FIGO	2010-2018	BCMII	●	●	●	●	●
FIGO	2010-2018	IPC	●	●	●	●	●
FIGO	2010-2018	APIM	●	●	●	●	●
FIGO	2010-2018	GWM	●	●	●	●	●
FIGO	2010-2018	FCDIM	●	●	●	●	※
FIGO	2010-2018	ACM	●	●	●	●	●
FIGO	2010-2018	TCU1	●	●	●	●	●
Five Hundred	2005-2007	PCM	●	●	●	●	●
Five Hundred	2005-2007	RCM	●	●	●	●	●
Five Hundred	2005-2007	TCM	●	●	●	●	●
Five Hundred	2005-2007	GEM	●	●	●	●	●
Five Hundred	2005-2007	PAM	●	●	●	●	●
Five Hundred	2005-2007	ABS	●	●	●	●	●
Five Hundred	2005-2007	ACM	●	●	●	●	●
Five Hundred	2005-2007	RETM	●	●	●	●	※
Five Hundred	2005-2007	EATC	●	●	●	●	※
Five Hundred	2005-2007	DSM	●	●	●	●	※
Five Hundred	2005-2007	4X4	●	●	●	●	※
Five Hundred	2005-2007	IC	●	●	●	●	●
Five Hundred	2005-2007	SDARS	●	●	●	●	※
Flex	2009-2019	IC	●	●	●	●	●
Flex	2009-2019	GEM/SJB	●	●	●	●	●
Flex	2009-2019	DSP	●	●	●	●	●
Flex	2009-2019	ACM	●	●	●	●	●
Flex	2009-2019	PCM	●	●	●	●	●
Flex	2009-2019	ABS	●	●	●	●	●
Flex	2009-2019	OCSM	●	●	●	●	●
Flex	2009-2019	4X4	●	●	●	●	※
Flex	2009-2019	FCIM	●	●	●	●	※
Flex	2009-2019	LTM	●	●	●	●	※
Flex	2009-2019	SASM	●	●	●	●	●
Flex	2009-2019	DCSM	●	●	●	●	※
Flex	2009-2019	DSM	●	●	●	●	●
Flex	2009-2019	FDIM	●	●	●	●	※
Flex	2009-2019	HCM	●	●	●	●	●

Flex	2009-2019	FCIM	●	●	●	●	※
Flex	2009-2019	HVAC	●	●	●	●	●
Flex	2009-2019	APIM	●	●	●	●	●
Flex	2009-2019	DDM	●	●	●	●	●
Flex	2009-2019	HCM-2	●	●	●	●	※
Flex	2009-2019	ILCM	●	●	●	●	※
Flex	2009-2019	RETM	●	●	●	●	※
Flex	2009-2019	RCM	●	●	●	●	●
Flex	2009-2019	PAM	●	●	●	●	●
Flex	2009-2019	PSCM	●	●	●	●	●
Flex	2009-2019	GPSM	●	●	●	●	●
Focus	1999-2002	GEM	●	●	●	●	●
Focus	1999-2002	ABS/TCS	●	●	●	●	●
Focus	1999-2002	HCM	●	●	●	●	●
Focus	1999-2002	PCM	●	●	●	●	●
Focus	1999-2002	MC	●	●	●	●	※
Focus	1999-2002	RCM	●	●	●	●	※
Focus	1999-2002	HEC	●	●	●	●	※
Focus	1999-2002	EATC	●	●	●	●	※
Focus	2003-2011	IC	●	●	●	●	●
Focus	2003-2011	OCSM	●	●	●	●	●
Focus	2003-2011	PCM	●	●	●	●	●
Focus	2003-2011	ABS	●	●	●	●	●
Focus	2003-2011	GEM/SJB	●	●	●	●	●
Focus	2003-2011	ACM	●	●	●	●	●
Focus	2003-2011	HVAC	●	●	●	●	※
Focus	2003-2011	FDIM	●	●	●	●	※
Focus	2003-2011	FCIM	●	●	●	●	※
Focus	2003-2011	APIM	●	●	●	●	●
Focus	2003-2011	GPSM	●	●	●	●	●
Focus	2003-2011	RCM	●	●	●	●	●
Focus	2012-2019	IPM-A	●	●	●	●	●
Focus	2012-2019	DDM	●	●	●	●	●
Focus	2012-2019	PDM	●	●	●	●	●
Focus	2012-2019	BCMII	●	●	●	●	●
Focus	2012-2019	RFA	●	●	●	●	※
Focus	2012-2019	OCSM	●	●	●	●	●
Focus	2012-2019	PCM	●	●	●	●	●
Focus	2012-2019	PSCM	●	●	●	●	●
Focus	2012-2019	ABS	●	●	●	●	●
Focus	2012-2019	SOD-R	●	●	●	●	※
Focus	2012-2019	APIM	●	●	●	●	●
Focus	2012-2019	SOD-L	●	●	●	●	※
Focus	2012-2019	RCM	●	●	●	●	●
Focus	2012-2019	DSP	●	●	●	●	●
Focus	2012-2019	GPSM	●	●	●	●	●
Focus	2012-2019	HVAC	●	●	●	●	※
Focus	2012-2019	ACM	●	●	●	●	●
Focus	2012-2019	GWM	●	●	●	●	●

Focus	2012-2019	TCU1	●	●	●	●	●
Focus	2012-2019	IPC	●	●	●	●	●
Focus	2012-2019	FCDIM	●	●	●	●	※
Focus	2012-2019	FCIM	●	●	●	●	※
Focus	2012-2019	DCDC	●	●	●	●	●
Focus	2012-2019	PAM	●	●	●	●	●
Focus	2012-2019	ACCM	●	●	●	●	●
Focus	2012-2019	BECM	●	●	●	●	※
Focus	2012-2019	SASM	●	●	●	●	●
Focus	2012-2019	GFM	●	●	●	●	※
Focus	2012-2019	SOBDM	●	●	●	●	※
Focus	2012-2019	TCM	●	●	●	●	●
Focus Cabriolet	2006-2008	EATC	●	●	●	●	●
Focus Cabriolet	2006-2008	SRM	●	●	●	●	●
Focus Cabriolet	2006-2008	RKE	●	●	●	●	●
Focus Cabriolet	2006-2008	FTCM	●	●	●	●	●
Focus Cabriolet	2006-2008	NAV	●	●	●	●	●
Focus Cabriolet	2006-2008	ACM	●	●	●	●	●
Focus Cabriolet	2006-2008	RCM	●	●	●	●	●
Focus Cabriolet	2006-2008	D_DCU	●	●	●	●	●
Focus Cabriolet	2006-2008	P_DCU	●	●	●	●	●
Focus Cabriolet	2006-2008	IC	●	●	●	●	●
Focus Cabriolet	2006-2008	FFH	●	●	●	●	●
Focus Cabriolet	2006-2008	CDP	●	●	●	●	●
Focus Cabriolet	2006-2008	GEM	●	●	●	●	●
Focus Cabriolet	2006-2008	HCM	●	●	●	●	●
Focus Cabriolet	2006-2008	PAM	●	●	●	●	●
Focus Cabriolet	2006-2008	GDM	●	●	●	●	●
Focus Cabriolet	2006-2008	ABS	●	●	●	●	●
Focus Cabriolet	2006-2008	PCM	●	●	●	●	●
Focus C-MAX	2002-2015	TRM	●	●	●	●	●
Focus C-MAX	2002-2015	RFA	●	●	●	●	●
Focus C-MAX	2002-2015	ACM	●	●	●	●	●
Focus C-MAX	2002-2015	IPC	●	●	●	●	●
Focus C-MAX	2002-2015	RCM	●	●	●	●	●
Focus C-MAX	2002-2015	SRM	●	●	●	●	●
Focus C-MAX	2002-2015	DDM	●	●	●	●	●
Focus C-MAX	2002-2015	PDM	●	●	●	●	●
Focus C-MAX	2002-2015	HCM	●	●	●	●	●
Focus C-MAX	2002-2015	SASM	●	●	●	●	●
Focus C-MAX	2002-2015	PCM	●	●	●	●	●
Focus C-MAX	2002-2015	TCM	●	●	●	●	●
Focus C-MAX	2002-2015	IPM-A	●	●	●	●	●
Focus C-MAX	2002-2015	HVAC	●	●	●	●	●
Focus C-MAX	2002-2015	ABS	●	●	●	●	●
Focus C-MAX	2002-2015	PAM	●	●	●	●	●
Focus C-MAX	2002-2015	AHCM	●	●	●	●	●
Focus C-MAX	2002-2015	APIM	●	●	●	●	●
Focus C-MAX	2002-2015	SOD-L	●	●	●	●	●

Focus C-MAX	2002-2015	SOD-R	●	●	●	●	●
Focus C-MAX	2002-2015	FCDIM	●	●	●	●	●
Focus C-MAX	2002-2015	FDSM	●	●	●	●	●
Focus C-MAX	2002-2015	RGTM	●	●	●	●	●
Focus C-MAX	2002-2015	BCMII	●	●	●	●	●
Focus C-MAX	2002-2015	IPM-B	●	●	●	●	●
Focus C-MAX	2002-2015	PSCM	●	●	●	●	●
Ford GT	2005-2006	ABS/TCS	●	●	●	●	●
Ford GT	2005-2006	IC	●	●	●	●	●
Ford GT	2005-2006	GEM	●	●	●	●	●
Ford GT	2005-2006	PATS	●	●	●	●	●
Ford GT	2005-2006	RCM	●	●	●	●	●
Ford GT	2005-2006	GEM	●	●	●	●	●
Ford GT	2005-2006	PCM	●	●	●	●	●
Ford GT	2017-2018	BCMII	●	●	●	●	●
Ford GT	2017-2018	DACM-C	●	●	●	●	●
Ford GT	2017-2018	SCCM	●	●	●	●	●
Ford GT	2017-2018	GWM	●	●	●	●	●
Ford GT	2017-2018	RTM	●	●	●	●	●
Ford GT	2017-2018	VDM	●	●	●	●	●
Ford GT	2017-2018	BECM-B	●	●	●	●	●
Ford GT	2017-2018	IPC	●	●	●	●	●
Ford GT	2017-2018	ACM	●	●	●	●	●
Ford GT	2017-2018	TCU1	●	●	●	●	●
Ford GT	2017-2018	GSM	●	●	●	●	●
Ford GT	2017-2018	PCM	●	●	●	●	●
Ford GT	2017-2018	TCM	●	●	●	●	●
Ford GT	2017-2018	APIM	●	●	●	●	●
Ford GT	2017-2018	OCSM	●	●	●	●	●
Ford GT	2017-2018	RCM	●	●	●	●	●
Ford GT	2017-2018	ABS	●	●	●	●	●
Freestar	2004-2007	IC	●	●	●	●	●
Freestar	2004-2007	EATC	●	●	●	●	●
Freestar	2004-2007	PCM	●	●	●	●	●
Freestar	2004-2007	PAM	●	●	●	●	●
Freestar	2004-2007	RPSDM	●	●	●	●	※
Freestar	2004-2007	NGSC	●	●	●	●	※
Freestar	2004-2007	LPSDM	●	●	●	●	※
Freestar	2004-2007	RCM	●	●	●	●	●
Freestar	2004-2007	GEM	●	●	●	●	●
Freestar	2004-2007	DSM	●	●	●	●	●
Freestar	2004-2007	DCSM	●	●	●	●	●
Freestar	2004-2007	PCSM	●	●	●	●	●
Freestar	2004-2007	ABS	●	●	●	●	●
Freestar	2004-2007	LTM	●	●	●	●	※
Freestyle	2005-2007	RETM	●	●	●	●	●
Freestyle	2005-2007	EATC	●	●	●	●	●
Freestyle	2005-2007	DSM	●	●	●	●	●
Freestyle	2005-2007	4X4	●	●	●	●	●

Freestyle	2005-2007	PCM	●	●	●	●	●
Freestyle	2005-2007	RCM	●	●	●	●	●
Freestyle	2005-2007	IC	●	●	●	●	●
Freestyle	2005-2007	GEM	●	●	●	●	●
Freestyle	2005-2007	PAM	●	●	●	●	●
Freestyle	2005-2007	ABS	●	●	●	●	●
Freestyle	2005-2007	SDARS	●	●	●	●	※
Freestyle	2005-2007	ACM	●	●	●	●	●
Freestyle	2005-2007	TCM	●	●	●	●	●
Fusion	2006-2012	PSCM	●	●	●	●	※
Fusion	2006-2012	HVAC	●	●	●	●	※
Fusion	2006-2012	4X4	●	●	●	●	※
Fusion	2006-2012	ABS	●	●	●	●	●
Fusion	2006-2012	FDIM	●	●	●	●	●
Fusion	2006-2012	FCIM	●	●	●	●	●
Fusion	2006-2012	PAM	●	●	●	●	●
Fusion	2006-2012	FCIM	●	●	●	●	●
Fusion	2006-2012	GEM/SJB	●	●	●	●	※
Fusion	2006-2012	APIM	●	●	●	●	●
Fusion	2006-2012	DSP	●	●	●	●	●
Fusion	2006-2012	IPC	●	●	●	●	●
Fusion	2006-2012	RCM	●	●	●	●	●
Fusion	2006-2012	SOD-R	●	●	●	●	●
Fusion	2006-2012	ACM	●	●	●	●	●
Fusion	2006-2012	PCM	●	●	●	●	●
Fusion	2006-2012	SOD-L	●	●	●	●	●
Fusion	2006-2012	TBM	●	●	●	●	●
Fusion	2006-2012	GPSM	●	●	●	●	●
Fusion	2006-2012	OCSM	●	●	●	●	●
Fusion	2013-2019	DACM-C	●	●	●	●	●
Fusion	2013-2019	GSM	●	●	●	●	●
Fusion	2013-2019	SOD-L	●	●	●	●	●
Fusion	2013-2019	SOD-R	●	●	●	●	●
Fusion	2013-2019	SCCM	●	●	●	●	●
Fusion	2013-2019	FCDIM	●	●	●	●	●
Fusion	2013-2019	IPM-A	●	●	●	●	●
Fusion	2013-2019	DSP	●	●	●	●	●
Fusion	2013-2019	GPSM	●	●	●	●	●
Fusion	2013-2019	C-CM	●	●	●	●	●
Fusion	2013-2019	FCIM	●	●	●	●	●
Fusion	2013-2019	PSCM	●	●	●	●	●
Fusion	2013-2019	BECM-B	●	●	●	●	●
Fusion	2013-2019	RCM	●	●	●	●	●
Fusion	2013-2019	BCMII	●	●	●	●	●
Fusion	2013-2019	VDM	●	●	●	●	●
Fusion	2013-2019	DDM	●	●	●	●	●
Fusion	2013-2019	PDM	●	●	●	●	●
Fusion	2013-2019	TCU1	●	●	●	●	●
Fusion	2013-2019	ACM	●	●	●	●	●

Fusion	2013-2019	DSM	●	●	●	●	●
Fusion	2013-2019	SCM-E	●	●	●	●	●
Fusion	2013-2019	IPC	●	●	●	●	●
Fusion	2013-2019	GWM	●	●	●	●	●
Fusion	2013-2019	APIM	●	●	●	●	●
Fusion	2013-2019	HCM	●	●	●	●	●
Fusion	2013-2019	HSWM	●	●	●	●	●
Fusion	2013-2019	PCM	●	●	●	●	●
Fusion	2013-2019	HUD	●	●	●	●	●
Fusion	2013-2019	OCSM	●	●	●	●	●
Fusion	2013-2019	RACM	●	●	●	●	●
Fusion	2013-2019	ABS	●	●	●	●	●
Fusion	2013-2019	TRCM	●	●	●	●	●
Fusion	2013-2019	SCM-G	●	●	●	●	●
Fusion	2013-2019	SCM-H	●	●	●	●	●
Fusion	2013-2019	PAM	●	●	●	●	●
Fusion	2013-2019	DCDC	●	●	●	●	●
Fusion	2013-2019	RTM	●	●	●	●	●
Galaxy	2006-2009	VDM	●	●	●	●	●
Galaxy	2006-2009	SASM	●	●	●	●	●
Galaxy	2006-2009	RHVAC	●	●	●	●	※
Galaxy	2006-2009	RGTM	●	●	●	●	※
Galaxy	2006-2009	CCMII	●	●	●	●	※
Galaxy	2006-2009	NAV	●	●	●	●	●
Galaxy	2006-2009	ACM	●	●	●	●	●
Galaxy	2006-2009	GDM	●	●	●	●	●
Galaxy	2006-2009	CDP	●	●	●	●	●
Galaxy	2006-2009	TRM	●	●	●	●	●
Galaxy	2006-2009	PCM	●	●	●	●	●
Galaxy	2006-2009	PBM	●	●	●	●	●
Galaxy	2006-2009	PSCM	●	●	●	●	●
Galaxy	2006-2009	ABS	●	●	●	●	●
Galaxy	2006-2009	IPC	●	●	●	●	●
Galaxy	2006-2009	SRM	●	●	●	●	●
Galaxy	2006-2009	HVAC	●	●	●	●	●
Galaxy	2006-2009	DDM	●	●	●	●	●
Galaxy	2006-2009	PDM	●	●	●	●	●
Galaxy	2006-2009	PAM	●	●	●	●	●
Galaxy	2006-2009	ACM	●	●	●	●	●
Galaxy	2006-2009	TCM	●	●	●	●	●
Galaxy	2006-2009	BCMII	●	●	●	●	●
Galaxy	2006-2009	AHCM	●	●	●	●	●
Galaxy	2006-2009	RCM	●	●	●	●	●
Galaxy	2006-2009	RFA	●	●	●	●	●
Galaxy	2006-2009	HCM	●	●	●	●	●
Galaxy	2010-2015	RGTM	●	●	●	●	●
Galaxy	2010-2015	CCMII	●	●	●	●	●
Galaxy	2010-2015	CDP	●	●	●	●	●
Galaxy	2010-2015	NAV	●	●	●	●	●

Galaxy	2010-2015	HVAC	●	●	●	●	●
Galaxy	2010-2015	PCM	●	●	●	●	●
Galaxy	2010-2015	BCMII	●	●	●	●	●
Galaxy	2010-2015	TRM	●	●	●	●	●
Galaxy	2010-2015	ACM	●	●	●	●	●
Galaxy	2010-2015	AHCM	●	●	●	●	●
Galaxy	2010-2015	DSM	●	●	●	●	●
Galaxy	2010-2015	DDM	●	●	●	●	●
Galaxy	2010-2015	PBM	●	●	●	●	●
Galaxy	2010-2015	PDM	●	●	●	●	●
Galaxy	2010-2015	SRM	●	●	●	●	●
Galaxy	2010-2015	PSCM	●	●	●	●	●
Galaxy	2010-2015	CMR	●	●	●	●	●
Galaxy	2010-2015	RHVAC	●	●	●	●	●
Galaxy	2010-2015	SASM	●	●	●	●	●
Galaxy	2010-2015	IPM-A	●	●	●	●	●
Galaxy	2010-2015	RCM	●	●	●	●	●
Galaxy	2010-2015	VDM	●	●	●	●	●
Galaxy	2010-2015	ABS	●	●	●	●	●
Galaxy	2010-2015	SOD-L	●	●	●	●	●
Galaxy	2010-2015	SOD-R	●	●	●	●	●
Galaxy	2010-2015	TCM	●	●	●	●	●
Galaxy	2010-2015	IPC	●	●	●	●	●
Galaxy	2010-2015	PAM	●	●	●	●	●
Galaxy	2010-2015	RFA	●	●	●	●	●
Galaxy	2010-2015	HCM	●	●	●	●	●
Galaxy	2010-2015	DABM	●	●	●	●	●
Granada	1991-1998	ABS/TCS	●	●	●	●	●
Granada	1991-1998	PATS	●	●	●	●	●
Granada	1991-1998	RCM	●	●	●	●	●
Granada	1991-1998	PCM	●	●	●	●	●
Ikon	1999-2013	PCM	●	●	●	●	●
Ikon	1999-2013	HEC	●	●	●	●	※
Ikon	1999-2013	ECS	●	●	●	●	※
KA	1997-2008	ABS/TCS	●	●	●	●	※
KA	1997-2008	GEM	●	●	●	●	※
KA	1997-2008	ECS	●	●	●	●	※
KA	1997-2008	CSM	●	●	●	●	※
KA	1997-2008	PCM	●	●	●	●	※
KA	2008-2015	RCM	●	●	●	●	●
KA	2008-2015	IC	●	●	●	●	●
KA	2008-2015	RKE	●	●	●	●	●
KA	2008-2015	TBM	●	●	●	●	●
KA	2008-2015	PCM	●	●	●	●	●
KA	2015-2018	ABS	●	●	●	●	●
KA	2015-2018	GPSM	●	●	●	●	●
KA	2015-2018	PCM	●	●	●	●	●
KA	2015-2018	PAM	●	●	●	●	●
KA	2015-2018	PSCM	●	●	●	●	●

KA	2015-2018	HVAC	●	●	●	●	●
KA	2015-2018	RCM	●	●	●	●	●
KA	2015-2018	BCMII	●	●	●	●	●
KA	2015-2018	IPC	●	●	●	●	●
KA	2015-2018	APIM	●	●	●	●	●
KA	2015-2018	GWM	●	●	●	●	●
KA	2015-2018	FCDIM	●	●	●	●	●
KA	2015-2018	ACM	●	●	●	●	●
KA	2015-2018	TCU1	●	●	●	●	●
Kuga	2008-2012	RKE	●	●	●	●	※
Kuga	2008-2012	EATC	●	●	●	●	※
Kuga	2008-2012	AWD	●	●	●	●	●
Kuga	2008-2012	IC	●	●	●	●	●
Kuga	2008-2012	D_DCU	●	●	●	●	●
Kuga	2008-2012	P_DCU	●	●	●	●	●
Kuga	2008-2012	ABS	●	●	●	●	●
Kuga	2008-2012	RCM	●	●	●	●	●
Kuga	2008-2012	GEM	●	●	●	●	●
Kuga	2008-2012	FFH	●	●	●	●	●
Kuga	2008-2012	TCM	●	●	●	●	●
Kuga	2008-2012	HCM	●	●	●	●	●
Kuga	2008-2012	CMR	●	●	●	●	●
Kuga	2008-2012	PAM	●	●	●	●	●
Kuga	2008-2012	RETM	●	●	●	●	※
Kuga	2008-2012	PCM	●	●	●	●	●
Kuga	2008-2012	EPS	●	●	●	●	●
Kuga	2008-2012	ACM	●	●	●	●	●
Kuga	2008-2012	SRM	●	●	●	●	●
Kuga	2013-2019	RFA	●	●	●	●	●
Kuga	2013-2019	BCMII	●	●	●	●	●
Kuga	2013-2019	TRM	●	●	●	●	●
Kuga	2013-2019	DDM	●	●	●	●	●
Kuga	2013-2019	PDM	●	●	●	●	●
Kuga	2013-2019	DSP	●	●	●	●	●
Kuga	2013-2019	IPC	●	●	●	●	●
Kuga	2013-2019	DSM	●	●	●	●	●
Kuga	2013-2019	RGTM	●	●	●	●	●
Kuga	2013-2019	APIM	●	●	●	●	●
Kuga	2013-2019	IPM-A	●	●	●	●	●
Kuga	2013-2019	C-CM	●	●	●	●	●
Kuga	2013-2019	TCU1	●	●	●	●	●
Kuga	2013-2019	FCDIM	●	●	●	●	●
Kuga	2013-2019	HVAC	●	●	●	●	●
Kuga	2013-2019	ACM	●	●	●	●	●
Kuga	2013-2019	FCIM	●	●	●	●	●
Kuga	2013-2019	OCSM	●	●	●	●	●
Kuga	2013-2019	HUD	●	●	●	●	●
Kuga	2013-2019	SASM	●	●	●	●	●
Kuga	2013-2019	PSCM	●	●	●	●	●

Kuga	2013-2019	ABS	●	●	●	●	●
Kuga	2013-2019	GPSM	●	●	●	●	●
Kuga	2013-2019	HCM	●	●	●	●	●
Kuga	2013-2019	PCM	●	●	●	●	●
Kuga	2013-2019	PAM	●	●	●	●	●
Kuga	2013-2019	RCM	●	●	●	●	●
Kuga	2013-2019	SOD-L	●	●	●	●	●
Kuga	2013-2019	SOD-R	●	●	●	●	●
Maverick	2001-2004	GEM	●	●	●	●	●
Maverick	2001-2004	PCM	●	●	●	●	●
Maverick	2001-2004	ABS/TCS	●	●	●	●	●
Maverick	2001-2004	PAM	●	●	●	●	●
Maverick	2001-2004	RCM	●	●	●	●	●
Maverick	2001-2004	IC	●	●	●	●	●
Maverick	2005-2007	GEM	●	●	●	●	●
Maverick	2005-2007	PAM	●	●	●	●	●
Maverick	2005-2007	RCM	●	●	●	●	●
Maverick	2005-2007	4X4	●	●	●	●	●
Maverick	2005-2007	IC	●	●	●	●	●
Maverick	2005-2007	ABS	●	●	●	●	●
Maverick	2005-2007	PCM	●	●	●	●	●
Mondeo	1993-2007	ABS/TCS	●	●	●	●	●
Mondeo	1993-2007	CSM	●	●	●	●	※
Mondeo	1993-2007	AFCM	●	●	●	●	※
Mondeo	1993-2007	PCM	●	●	●	●	●
Mondeo	2007-2013	SCCM	●	●	●	●	●
Mondeo	2007-2013	IPC	●	●	●	●	●
Mondeo	2007-2013	C-CM	●	●	●	●	●
Mondeo	2007-2013	BCMII	●	●	●	●	●
Mondeo	2007-2013	SCM-E	●	●	●	●	●
Mondeo	2007-2013	HCM	●	●	●	●	●
Mondeo	2007-2013	ACM	●	●	●	●	●
Mondeo	2007-2013	DDM	●	●	●	●	●
Mondeo	2007-2013	PDM	●	●	●	●	●
Mondeo	2007-2013	APIM	●	●	●	●	●
Mondeo	2007-2013	DSP	●	●	●	●	●
Mondeo	2007-2013	RCM	●	●	●	●	●
Mondeo	2007-2013	GWM	●	●	●	●	●
Mondeo	2007-2013	RTM	●	●	●	●	●
Mondeo	2007-2013	GPSM	●	●	●	●	●
Mondeo	2007-2013	HUD	●	●	●	●	●
Mondeo	2007-2013	RACM	●	●	●	●	●
Mondeo	2007-2013	SOD-L	●	●	●	●	●
Mondeo	2007-2013	ABS	●	●	●	●	●
Mondeo	2007-2013	PCM	●	●	●	●	●
Mondeo	2007-2013	IPM-A	●	●	●	●	●
Mondeo	2007-2013	PSCM	●	●	●	●	●
Mondeo	2007-2013	SOD-R	●	●	●	●	●
Mondeo	2007-2013	FDSM	●	●	●	●	●

Mondeo	2007-2013	DSM	●	●	●	●	●
Mondeo	2007-2013	SCM-G	●	●	●	●	●
Mondeo	2007-2013	SCM-H	●	●	●	●	●
Mondeo	2007-2013	PAM	●	●	●	●	●
Mondeo	2007-2013	FCDIM	●	●	●	●	●
Mondeo	2007-2013	FCIM	●	●	●	●	●
Mondeo	2013-2019	DACM-C	●	●	●	●	●
Mondeo	2013-2019	BCMII	●	●	●	●	●
Mondeo	2013-2019	VDM	●	●	●	●	●
Mondeo	2013-2019	SOD-L	●	●	●	●	●
Mondeo	2013-2019	SOD-R	●	●	●	●	●
Mondeo	2013-2019	SCCM	●	●	●	●	●
Mondeo	2013-2019	FCDIM	●	●	●	●	●
Mondeo	2013-2019	IPM-A	●	●	●	●	●
Mondeo	2013-2019	DSP	●	●	●	●	●
Mondeo	2013-2019	SCM-E	●	●	●	●	●
Mondeo	2013-2019	GPSM	●	●	●	●	●
Mondeo	2013-2019	C-CM	●	●	●	●	●
Mondeo	2013-2019	BECM-B	●	●	●	●	●
Mondeo	2013-2019	RCM	●	●	●	●	●
Mondeo	2013-2019	HCM	●	●	●	●	●
Mondeo	2013-2019	PSCM	●	●	●	●	●
Mondeo	2013-2019	DSM	●	●	●	●	●
Mondeo	2013-2019	GWM	●	●	●	●	●
Mondeo	2013-2019	GSM	●	●	●	●	●
Mondeo	2013-2019	ACM	●	●	●	●	●
Mondeo	2013-2019	IPC	●	●	●	●	●
Mondeo	2013-2019	DDM	●	●	●	●	●
Mondeo	2013-2019	PDM	●	●	●	●	●
Mondeo	2013-2019	TCU1	●	●	●	●	●
Mondeo	2013-2019	APIM	●	●	●	●	●
Mondeo	2013-2019	HSWM	●	●	●	●	●
Mondeo	2013-2019	PCM	●	●	●	●	●
Mondeo	2013-2019	HUD	●	●	●	●	●
Mondeo	2013-2019	OCSM	●	●	●	●	●
Mondeo	2013-2019	RACM	●	●	●	●	●
Mondeo	2013-2019	ABS	●	●	●	●	●
Mondeo	2013-2019	TRCM	●	●	●	●	●
Mondeo	2013-2019	SCM-G	●	●	●	●	●
Mondeo	2013-2019	SCM-H	●	●	●	●	●
Mondeo	2013-2019	PAM	●	●	●	●	●
Mondeo	2013-2019	DCDC	●	●	●	●	●
Mondeo	2013-2019	RTM	●	●	●	●	●
Mondeo	2013-2019	FCIM	●	●	●	●	●
Motorhome	2006-2019	PCM	●	●	●	●	●
Motorhome	2006-2019	ABS	●	●	●	●	●
Motorhome	2006-2019	IC	●	●	●	●	●
Mustang	1996-2004	GEM	●	●	●	●	●
Mustang	1996-2004	ABS/TCS	●	●	●	●	●

Mustang	1996-2004	RCM	●	●	●	●	●
Mustang	1996-2004	HEC	●	●	●	●	●
Mustang	1996-2004	PCM	●	●	●	●	●
Mustang	2005-2010	PCM	●	●	●	●	●
Mustang	2005-2010	OCSM	●	●	●	●	●
Mustang	2005-2010	FCIM	●	●	●	●	※
Mustang	2005-2010	GEM/SJB	●	●	●	●	※
Mustang	2005-2010	FDIM	●	●	●	●	※
Mustang	2005-2010	IPC	●	●	●	●	●
Mustang	2005-2010	HVAC	●	●	●	●	●
Mustang	2005-2010	ABS	●	●	●	●	●
Mustang	2005-2010	ACM	●	●	●	●	●
Mustang	2005-2010	RCM	●	●	●	●	●
Mustang	2005-2010	APIM	●	●	●	●	●
Mustang	2005-2010	BCM-B	●	●	●	●	●
Mustang	2005-2010	GPSM	●	●	●	●	●
Mustang	2011-2019	DACM-C	●	●	●	●	●
Mustang	2011-2019	HCM	●	●	●	●	●
Mustang	2011-2019	MRCM-A	●	●	●	●	●
Mustang	2011-2019	MRCM-B	●	●	●	●	●
Mustang	2011-2019	VDM	●	●	●	●	●
Mustang	2011-2019	FCDIM	●	●	●	●	●
Mustang	2011-2019	SCCM	●	●	●	●	●
Mustang	2011-2019	SOD-L	●	●	●	●	●
Mustang	2011-2019	SOD-R	●	●	●	●	●
Mustang	2011-2019	DDM	●	●	●	●	●
Mustang	2011-2019	PDM	●	●	●	●	●
Mustang	2011-2019	SCM-E	●	●	●	●	●
Mustang	2011-2019	HSWM	●	●	●	●	●
Mustang	2011-2019	BCMII	●	●	●	●	●
Mustang	2011-2019	C-CM	●	●	●	●	●
Mustang	2011-2019	DSM	●	●	●	●	●
Mustang	2011-2019	TCU1	●	●	●	●	●
Mustang	2011-2019	FCIM	●	●	●	●	●
Mustang	2011-2019	IPM-A	●	●	●	●	●
Mustang	2011-2019	BECM-B	●	●	●	●	●
Mustang	2011-2019	PSCM	●	●	●	●	●
Mustang	2011-2019	PCM	●	●	●	●	●
Mustang	2011-2019	DSP	●	●	●	●	●
Mustang	2011-2019	ABS	●	●	●	●	●
Mustang	2011-2019	IPC	●	●	●	●	●
Mustang	2011-2019	ACM	●	●	●	●	●
Mustang	2011-2019	APIM	●	●	●	●	●
Mustang	2011-2019	HUD	●	●	●	●	●
Mustang	2011-2019	OCSM	●	●	●	●	●
Mustang	2011-2019	RCM	●	●	●	●	●
Mustang	2011-2019	GWM	●	●	●	●	●
Mustang	2011-2019	BCM-B	●	●	●	●	●
Mustang	2011-2019	PAM	●	●	●	●	●

Mustang	2011-2019	ICMI	●	●	●	●	●
Mustang	2011-2019	GPSM	●	●	●	●	●
Mustang	2011-2019	RTM	●	●	●	●	●
Puma	1997-2001	ABS/TCS	●	●	●	●	●
Puma	1997-2001	GEM	●	●	●	●	※
Puma	1997-2001	HEC	●	●	●	●	※
Puma	1997-2001	PCM	●	●	●	●	●
Ranger	1993-2002	GEM	●	●	●	●	●
Ranger	1993-2002	ABS/TCS	●	●	●	●	●
Ranger	1993-2002	RAP	●	●	●	●	●
Ranger	1993-2002	4X4	●	●	●	●	※
Ranger	1993-2002	RCM	●	●	●	●	●
Ranger	1993-2002	PCM	●	●	●	●	●
Ranger	2003-2011	4X4	●	●	●	●	※
Ranger	2003-2011	IC	●	●	●	●	●
Ranger	2003-2011	OCSM	●	●	●	●	●
Ranger	2003-2011	ABS	●	●	●	●	●
Ranger	2003-2011	RCM	●	●	●	●	●
Ranger	2003-2011	GEM/SJB	●	●	●	●	※
Ranger	2003-2011	PCM	●	●	●	●	●
Ranger	2003-2011	SDARS	●	●	●	●	※
S-Max	2006-2009	VDM	●	●	●	●	●
S-Max	2006-2009	SASM	●	●	●	●	●
S-Max	2006-2009	RHVAC	●	●	●	●	※
S-Max	2006-2009	RGTM	●	●	●	●	※
S-Max	2006-2009	CCMII	●	●	●	●	※
S-Max	2006-2009	NAV	●	●	●	●	●
S-Max	2006-2009	ACM	●	●	●	●	●
S-Max	2006-2009	GDM	●	●	●	●	●
S-Max	2006-2009	CDP	●	●	●	●	●
S-Max	2006-2009	TRM	●	●	●	●	●
S-Max	2006-2009	PCM	●	●	●	●	●
S-Max	2006-2009	PBM	●	●	●	●	●
S-Max	2006-2009	PSCM	●	●	●	●	●
S-Max	2006-2009	ABS	●	●	●	●	●
S-Max	2006-2009	IPC	●	●	●	●	●
S-Max	2006-2009	SRM	●	●	●	●	●
S-Max	2006-2009	HVAC	●	●	●	●	●
S-Max	2006-2009	DDM	●	●	●	●	●
S-Max	2006-2009	PDM	●	●	●	●	●
S-Max	2006-2009	PAM	●	●	●	●	●
S-Max	2006-2009	ACM	●	●	●	●	●
S-Max	2006-2009	TCM	●	●	●	●	●
S-Max	2006-2009	BCMII	●	●	●	●	●
S-Max	2006-2009	AHCM	●	●	●	●	●
S-Max	2006-2009	RCM	●	●	●	●	●
S-Max	2006-2009	RFA	●	●	●	●	●
S-Max	2006-2009	HCM	●	●	●	●	●
S-Max	2010-2015	RGTM	●	●	●	●	●

S-Max	2010-2015	CCMII	●	●	●	●	●
S-Max	2010-2015	CDP	●	●	●	●	●
S-Max	2010-2015	NAV	●	●	●	●	●
S-Max	2010-2015	HVAC	●	●	●	●	●
S-Max	2010-2015	PCM	●	●	●	●	●
S-Max	2010-2015	BCMII	●	●	●	●	●
S-Max	2010-2015	TRM	●	●	●	●	●
S-Max	2010-2015	ACM	●	●	●	●	●
S-Max	2010-2015	AHCM	●	●	●	●	●
S-Max	2010-2015	DSM	●	●	●	●	●
S-Max	2010-2015	DDM	●	●	●	●	●
S-Max	2010-2015	PBM	●	●	●	●	●
S-Max	2010-2015	PDM	●	●	●	●	●
S-Max	2010-2015	SRM	●	●	●	●	●
S-Max	2010-2015	PSCM	●	●	●	●	●
S-Max	2010-2015	CMR	●	●	●	●	●
S-Max	2010-2015	RHVAC	●	●	●	●	●
S-Max	2010-2015	SASM	●	●	●	●	●
S-Max	2010-2015	IPM-A	●	●	●	●	●
S-Max	2010-2015	RCM	●	●	●	●	●
S-Max	2010-2015	VDM	●	●	●	●	●
S-Max	2010-2015	ABS	●	●	●	●	●
S-Max	2010-2015	SOD-L	●	●	●	●	●
S-Max	2010-2015	SOD-R	●	●	●	●	●
S-Max	2010-2015	TCM	●	●	●	●	●
S-Max	2010-2015	IPC	●	●	●	●	●
S-Max	2010-2015	PAM	●	●	●	●	●
S-Max	2010-2015	RFA	●	●	●	●	●
S-Max	2010-2015	HCM	●	●	●	●	●
S-Max	2010-2015	DABM	●	●	●	●	●
Scorpio	1991-1992	ABS/TCS	●	●	●	●	●
Scorpio	1991-1992	PATS	●	●	●	●	●
Scorpio	1991-1992	RCM	●	●	●	●	●
Scorpio	1991-1992	PCM	●	●	●	●	●
Scorpio	1993-1994	ABS/TCS	●	●	●	●	●
Scorpio	1993-1994	PATS	●	●	●	●	●
Scorpio	1993-1994	RCM	●	●	●	●	●
Scorpio	1993-1994	PCM	●	●	●	●	●
Scorpio	1995-1996	ABS/TCS	●	●	●	●	●
Scorpio	1995-1996	PATS	●	●	●	●	●
Scorpio	1995-1996	RCM	●	●	●	●	●
Scorpio	1995-1996	PCM	●	●	●	●	●
Scorpio	1997-1998	ABS/TCS	●	●	●	●	●
Scorpio	1997-1998	PATS	●	●	●	●	●
Scorpio	1997-1998	RCM	●	●	●	●	●
Scorpio	1997-1998	PCM	●	●	●	●	●
Step Van	2006-2019	PCM	●	●	●	●	●
Step Van	2006-2019	ABS	●	●	●	●	●
Step Van	2006-2019	PCM	●	●	●	●	●

Step Van	2006-2019	IC	●	●	●	●	●
Stripped Chassis	2006-2019	PCM	●	●	●	●	●
Stripped Chassis	2006-2019	ABS	●	●	●	●	●
Stripped Chassis	2006-2019	PCM	●	●	●	●	●
Stripped Chassis	2006-2019	IC	●	●	●	●	●
Taurus	1996-2002	GEM	●	●	●	●	●
Taurus	1996-2002	ABS/TCS	●	●	●	●	●
Taurus	1996-2002	EATC	●	●	●	●	※
Taurus	1996-2002	RCM	●	●	●	●	●
Taurus	1996-2002	PCM	●	●	●	●	●
Taurus	2003-2007	PCM	●	●	●	●	●
Taurus	2003-2007	IC	●	●	●	●	●
Taurus	2003-2007	RCM	●	●	●	●	●
Taurus	2003-2007	GEM	●	●	●	●	●
Taurus	2003-2007	ABS	●	●	●	●	●
Taurus	2003-2007	EATC	●	●	●	●	※
Taurus	2008-2019	4X4	●	●	●	●	●
Taurus	2008-2019	DCSM	●	●	●	●	●
Taurus	2008-2019	FDIM	●	●	●	●	●
Taurus	2008-2019	FCIM	●	●	●	●	●
Taurus	2008-2019	SASM	●	●	●	●	●
Taurus	2008-2019	ABS	●	●	●	●	●
Taurus	2008-2019	RETM	●	●	●	●	●
Taurus	2008-2019	DSM	●	●	●	●	●
Taurus	2008-2019	HCM	●	●	●	●	●
Taurus	2008-2019	FCIM	●	●	●	●	●
Taurus	2008-2019	HVAC	●	●	●	●	●
Taurus	2008-2019	GEM/SJB	●	●	●	●	●
Taurus	2008-2019	APIM	●	●	●	●	●
Taurus	2008-2019	DSP	●	●	●	●	●
Taurus	2008-2019	HUD	●	●	●	●	●
Taurus	2008-2019	IPC	●	●	●	●	●
Taurus	2008-2019	RCM	●	●	●	●	●
Taurus	2008-2019	DDM	●	●	●	●	●
Taurus	2008-2019	PCM	●	●	●	●	●
Taurus	2008-2019	ILCM	●	●	●	●	●
Taurus	2008-2019	PAM	●	●	●	●	●
Taurus	2008-2019	HCM-2	●	●	●	●	●
Taurus	2008-2019	C-CM	●	●	●	●	●
Taurus	2008-2019	RFA	●	●	●	●	●
Taurus	2008-2019	OCSM	●	●	●	●	●
Taurus	2008-2019	SOD-R	●	●	●	●	●
Taurus	2008-2019	SOD-L	●	●	●	●	●
Taurus	2008-2019	PSCM	●	●	●	●	●
Taurus	2008-2019	ACM	●	●	●	●	●
Taurus	2008-2019	GPSM	●	●	●	●	●
Taurus X	2008-2009	4X4	●	●	●	●	※
Taurus X	2008-2009	PAM	●	●	●	●	●
Taurus X	2008-2009	LTM	●	●	●	●	※

Taurus X	2008-2009	OCSM	●	●	●	●	●
Taurus X	2008-2009	ABS	●	●	●	●	●
Taurus X	2008-2009	SECM	●	●	●	●	●
Taurus X	2008-2009	RCM	●	●	●	●	●
Taurus X	2008-2009	ACM	●	●	●	●	●
Taurus X	2008-2009	PCM	●	●	●	●	●
Taurus X	2008-2009	RETM	●	●	●	●	●
Taurus X	2008-2009	DSM	●	●	●	●	●
Taurus X	2008-2009	HVAC	●	●	●	●	●
Taurus X	2008-2009	GEM/SJB	●	●	●	●	●
Taurus X	2008-2009	IC	●	●	●	●	●
Taurus X	2008-2009	APIM	●	●	●	●	●
Taurus X	2008-2009	SDARS	●	●	●	●	※
Territory	2004-2010	PAM	●	●	●	●	●
Territory	2004-2010	PCM	●	●	●	●	●
Territory	2004-2010	IC	●	●	●	●	●
Territory	2004-2010	ACM	●	●	●	●	●
Territory	2004-2010	BEM	●	●	●	●	●
Territory	2004-2010	RCM	●	●	●	●	●
Territory	2004-2010	ABS	●	●	●	●	●
Territory	2004-2010	HIM	●	●	●	●	※
Territory	2011-2014	TCM	●	●	●	●	●
Territory	2011-2014	FDIM	●	●	●	●	●
Territory	2011-2014	PCM	●	●	●	●	●
Territory	2011-2014	PAM	●	●	●	●	●
Territory	2011-2014	PSCM	●	●	●	●	●
Territory	2011-2014	ABS	●	●	●	●	●
Territory	2011-2014	HIM	●	●	●	●	●
Territory	2011-2014	IPC	●	●	●	●	●
Territory	2011-2014	RCM	●	●	●	●	●
Territory	2011-2014	BEM	●	●	●	●	●
Territory	2011-2014	ACM	●	●	●	●	●
Thunderbird	1994-1997	PCM	●	●	●	●	●
Thunderbird	2002-2005	ABS/TCS	●	●	●	●	●
Thunderbird	2002-2005	PCM	●	●	●	●	●
Thunderbird	2002-2005	EATC	●	●	●	●	●
Thunderbird	2002-2005	DDM	●	●	●	●	●
Thunderbird	2002-2005	REM	●	●	●	●	●
Thunderbird	2002-2005	ACM	●	●	●	●	●
Thunderbird	2002-2005	GEM	●	●	●	●	●
Thunderbird	2002-2005	RCM	●	●	●	●	●
Thunderbird	2002-2005	HEC	●	●	●	●	●
Tourneo Connect	2002-2009	CSM	●	●	●	●	●
Tourneo Connect	2002-2009	ABS/TCS	●	●	●	●	●
Tourneo Connect	2002-2009	SRM	●	●	●	●	●
Tourneo Connect	2002-2009	PAM	●	●	●	●	●
Tourneo Connect	2002-2009	ECS	●	●	●	●	●
Tourneo Connect	2002-2009	IC	●	●	●	●	●
Tourneo Connect	2002-2009	PCM	●	●	●	●	●

Tourneo Connect	2002-2009	FFH	●	●	●	●	●
Tourneo Connect	2002-2009	ACM	●	●	●	●	●
Tourneo Connect	2002-2009	ABS	●	●	●	●	●
Transit	1995-1999	AFCM	●	●	●	●	●
Transit	1995-1999	ABS/TCS	●	●	●	●	●
Transit	1995-1999	PCM	●	●	●	●	●
Transit	2000-2005	RCM	●	●	●	●	●
Transit	2000-2005	ABS/TCS	●	●	●	●	●
Transit	2000-2005	PAM	●	●	●	●	●
Transit	2000-2005	CSM	●	●	●	●	●
Transit	2000-2005	HEC	●	●	●	●	●
Transit	2000-2005	FFH	●	●	●	●	●
Transit	2000-2005	PCM	●	●	●	●	●
Transit	2000-2005	ICU	●	●	●	●	●
Transit	2006-2009	RCM	●	●	●	●	●
Transit	2006-2009	IPC	●	●	●	●	●
Transit	2006-2009	FFH	●	●	●	●	●
Transit	2006-2009	SRM	●	●	●	●	●
Transit	2006-2009	ACM	●	●	●	●	●
Transit	2006-2009	PAM	●	●	●	●	●
Transit	2006-2009	ABS	●	●	●	●	●
Transit	2006-2009	ACM	●	●	●	●	●
Transit	2006-2009	PCM	●	●	●	●	●
Transit	2006-2009	TBM	●	●	●	●	●
Transit	2006-2009	BCMII	●	●	●	●	●
Transit	2010-2019	C-CM	●	●	●	●	●
Transit	2010-2019	ACM	●	●	●	●	●
Transit	2010-2019	HVAC	●	●	●	●	●
Transit	2010-2019	IPC	●	●	●	●	●
Transit	2010-2019	PAM	●	●	●	●	●
Transit	2010-2019	PSCM	●	●	●	●	●
Transit	2010-2019	RCM	●	●	●	●	●
Transit	2010-2019	TRM	●	●	●	●	●
Transit	2010-2019	APIM	●	●	●	●	●
Transit	2010-2019	BECM-B	●	●	●	●	●
Transit	2010-2019	DDM	●	●	●	●	●
Transit	2010-2019	GFM	●	●	●	●	●
Transit	2010-2019	GFM-2	●	●	●	●	●
Transit	2010-2019	IPM-A	●	●	●	●	●
Transit	2010-2019	PDM	●	●	●	●	●
Transit	2010-2019	RTM	●	●	●	●	●
Transit	2010-2019	SCCM	●	●	●	●	●
Transit	2010-2019	SOD-L	●	●	●	●	●
Transit	2010-2019	SOD-R	●	●	●	●	●
Transit	2010-2019	TCU1	●	●	●	●	●
Transit	2010-2019	AHCM	●	●	●	●	●
Transit	2010-2019	WACM	●	●	●	●	●
Transit	2010-2019	GWM	●	●	●	●	●
Transit	2010-2019	BCMII	●	●	●	●	●

Transit	2010-2019	OCSM	●	●	●	●	●
Transit	2010-2019	ABS	●	●	●	●	●
Transit	2010-2019	PCM	●	●	●	●	●
Transit Courier	ALL	APIM	●	●	●	●	●
Transit Courier	ALL	IPC	●	●	●	●	●
Transit Courier	ALL	PCM	●	●	●	●	●
Transit Courier	ALL	RCM	●	●	●	●	●
Transit Courier	ALL	GPSM	●	●	●	●	●
Transit Courier	ALL	FCDIM	●	●	●	●	●
Transit Courier	ALL	BCMII	●	●	●	●	●
Transit Courier	ALL	PSCM	●	●	●	●	●
Transit Courier	ALL	ABS	●	●	●	●	●
Transit Courier	ALL	HVAC	●	●	●	●	●
Transit Courier	ALL	ACM	●	●	●	●	●
Troller	2011-2015	BCMII	●	●	●	●	●
Troller	2011-2015	GPSM	●	●	●	●	●
Troller	2011-2015	ACM	●	●	●	●	●
Troller	2011-2015	PCM	●	●	●	●	●
Troller	2011-2015	FCDIM	●	●	●	●	●
Troller	2011-2015	TRM	●	●	●	●	●
Troller	2011-2015	PAM	●	●	●	●	●
Troller	2011-2015	SRM	●	●	●	●	●
Troller	2011-2015	APIM	●	●	●	●	●
Troller	2011-2015	TBM	●	●	●	●	●
Troller	2011-2015	RCM	●	●	●	●	●
Troller	2011-2015	DDM	●	●	●	●	●
Troller	2011-2015	PDM	●	●	●	●	●
Troller	2011-2015	TCM	●	●	●	●	●
Troller	2011-2015	ABS	●	●	●	●	●
Troller	2011-2015	HVAC	●	●	●	●	●
Troller	2011-2015	IPC	●	●	●	●	●
Windstar	1995-2003	MC	●	●	●	●	●
Windstar	1995-2003	DSM	●	●	●	●	●
Windstar	1995-2003	DDM	●	●	●	●	●
Windstar	1995-2003	REM	●	●	●	●	●
Windstar	1995-2003	ABS/TCS	●	●	●	●	●
Windstar	1995-2003	PAM	●	●	●	●	●
Windstar	1995-2003	RPSDM	●	●	●	●	●
Windstar	1995-2003	NGSC	●	●	●	●	●
Windstar	1995-2003	LPSDM	●	●	●	●	●
Windstar	1995-2003	RCM	●	●	●	●	●
Windstar	1995-2003	IC	●	●	●	●	●
Windstar	1995-2003	FEM	●	●	●	●	●
Windstar	1995-2003	PCM	●	●	●	●	●
<b>System List</b>							
4WAS	Air Suspension						
4X4	4X4 Control Module						
ABS	Anti-Lock Braking System						

ABS/TCS	Anti-Lock Braking System/Traction Control Module
ACCM	Air Conditioning Control Module
ACM	Audio Control Module
AFCM	Alternative Fuel Control Module
AHCM	Auxiliary Heater Control Module
AIM	Audio Interface Module
APIM	Accessory Protocol Interface Module
ARC	Automatic Ride Control
ATCM	All Terrain Control Module
AWD	All Wheel Drive
BCM-B	Body Control Module B
BCMII	Body Control Module
BECM	Battery Energy Control Module
BECM-B	Battery Energy Control Module B
BEM	Body Electronic Module
BPM	Bluetooth Phone Module
C-CM	Cruise-Control Module
CCMII	Cruise Control Module
CDP	Compact Disc Player
CLM	Column Lock Module
CMR	Camera Module Rear
CSM	Security Module
DABM	Digital Audio Broadcast Module
DACM-C	Digital Audio Control Module C
DCDC	DC To DC Converter Control Module
DCSM	Driver/Dual Climate-Control Seat Module
DDM	Driver Front Door Module
DDM	Drivers Door Module
DSM	Driver Front Seat Module
DSM	Drivers Seat Module
DSP	Audio Digital Signal Processing Module
D DCU	Driver Door Control Unit
EATC	Electronic Automatic Temperature Control
ECS	Electronic Crash Sensor
EPB	Electric Parking Brake
EPS	Electronic-Controlled Power Steering
FACM	Fuel Additive Control Module
FCDIM	Front Control/Display Interface Module
FCIM	Front Controls Interface Module
FCIM-B	Front Controls Interface Module B
FDIM	Front Display Interface Module
FDSM	Front Distance Sensing Module
FEM	Front Electronic Module
FFH	Fuel Fired Coolant Heating Module
FLM	Front Lighting Control Module
FTCM	Folding Top Control Module
GDM	Generic Display Module
GEM	Generic Electronic Module
GEM/SJB	Generic Electronic Module/Smart Junction Box

GFM	Generic Function Module
GFM-2	Generic Function Module 2
GPSM	Global Positioning System Module
GSM	Gear Shift Module
GWM	Gateway Module A
HCM	Headlamp Control Module
HCM-2	Headlamp Control Module 2B
HEC	Hybrid Electronic Cluster
HIM	HVAC Integrated Module
HSWM	Heated Steering Wheel Module
HUD	Head Up Display
HVAC	Heating Ventilation Air Conditioning
IC	Instrument Cluster
ICM1	Information Center Module
ICU	Injector Control Unit
ILCM	Interior Lighting Control Module
IPC	Instrument Panel Control Module
IPM-A	Image Processing Module A
IPM-B	Image Processing Module B
LPSDM	Left Power Sliding Door Module
LTM	Liftgate/Trunk Module
MC	Message Center Module
MRCM-A	Movable Roof Control Module A
MRCM-B	Movable Roof Control Module B
NAV	Navigation Controller
NGSC	Next Generation Speed Control Module
OCSM	Occupant Classification System Module
PAM	Parking Aid Module
PATS	Passive Anti-Theft System
PBM	Park Brake Control Module
PCM	Powertrain Control Module
PCSM	Passenger Climate-Control Seat Module
PDM	Passenger Front Door Module
PRB	Power Running Board
PSCM	Power Steering Control Module
P DCU	Passengers Door Control Unit
RACM	Rear Audio Control Module
RAP	Remote Anti-Theft/Personality Module
RBM	Running Board Control Module
RCM	Restraint Control Module
RCU	Audio Rear Control Unit
RDCM1	Reductant Control Module
REM	Rear Electronic Module
RETM	Rear Seat Entertainment Module
RFA	Remote Function Actuator
RGTM	Rear Gate/Trunk Module
RHVAC	Rear Heating Ventilation Air Conditioning
RKE	Remote Keyless Entry
RLCM A	Rear Lighting Control Module A

RL DCU	Rear Left Door Control Unit
RPSDM	Right Power Sliding Door Module
RR DCU	Rear Right Door Control Unit
RTM	Radio Transceiver Module
SASM	Steering Angle Sensor Module
SCCM	Steering Column Control Module
SCM-E	Seat Control Module E
SCM-G	Seat Control Module G
SCM-H	Seat Control Module H
SDARS	Satellite Digital Audio Receiver System
SECM	Steering Effort Control Module
SOBDM	Secondary OBD Control Module A
SOD-L	Side Obstacle Detection Control Module - Left
SOD-R	Side Obstacle Detection Control Module - Right
SRM	Speech Recognition Module
TBC	Trailer Brake Control Module
TBM	Tracking And Blocking Module
TCCM	Transfer Case Control Module
TCM	Transmission Control Module
TCU1	Telematic Control Unit Module
TPM	Tire Pressure Monitor
TRCM	Transmission Range Control Module
TRM	Trailer Module
VDM	Vehicle Dynamics Module
VSM	Vehicle Security Module
WACM	Wireless Accessory Charging Module

FORD BLD Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	BLD
B-Max	ALL	●
Bravo	ALL	●
CF/LCF	2006-2009	●
Contour	1996-2000	●
Cougar	1998-2002	●
Courier	1998-2001	●
Crown Victoria	1995-2011	●
E-Series	1995-2016	●
EcoSport	2003-2014	●
Edge	2007-2014	●
Escape	2001-2012	●
Escort	1997-2003	●
Excursion	2000-2005	●
Expedition	1997-2019	●
Expedition EL	2007-2014	●
Explorer	1996-2015	●
Explorer Sport	2000-2003	●
Explorer SportTrac	2000-2010	●
F-Series	1997-2014	●
Fairlane/LTD	2003-2006	●
Fairmont	2003-2006	●
Falcon	2003-2014	●
Fiesta	2001-2018	●
FIGO	2010-2011	●
Flex	2009-2012	●
Focus	1999-2011	●
Focus Cabriolet	2006-2008	●
Focus C-MAX	2002-2014	●
Ford GT	2005-2006	●
Freestar	2004-2007	●
Freestyle	2005-2007	●
Fusion	2006-2012	●
Galaxy	2006-2015	●
Granada	1991-1998	●
Kuga	2008-2013	●
Maverick	2001-2007	●
Mondeo	2013-2018	●
Mustang	1996-2010	●
V6 SOHC	1993-2011	●
S-Max	2006-2015	●
Scorpio	1991-1998	●
Taurus	1996-2012	●
Taurus X	2008-2009	●
Territory	2004-2014	●
Thunderbird	2002-2005	●
Tourneo Connect	2007-2009	●

Transit	2000-2009	●
Transit Courier	ALL	●
Troller	2011-2015	●
Windstar	1995-2003	●
Aviator	2004-2014	●
Blackwood	2008-2009	●
Continental	2004-2014	●
Everest	2002-2005	●
F-150	2007-2009	●
F-250	2000-2009	●
F-650	2002-2005	●
F-750	2006-2008	●
Falcon	2002-2014	●
Ikon	2005-2006	●
Five Hundred	2004-2007	●
Grand Marquis	2005-2007	●
Ikon	2006-2012	●
Kuga/Escape	2006-2015	●
LS	1991-1998	●
MKC	2001-2019	●
MKS	2000-2018	●
MKT	2008-2018	●
MKX	2004-2014	●
MKZ	2002-2017	●
Marauder	2007-2009	●
Mariner	2000-2009	●
Mark LT	2006-2008	●
Mark VIII	2002-2014	●
Milan	2005-2006	●
Montego	2004-2007	●
Monterey	2005-2007	●
Motorhome	2006-2012	●
Mountaineer	2006-2015	●
Mystique	1991-1998	●
Navigator	2008-2013	●
Ranger	2001-2007	●
Sable	2008-2009	●
Step Van	2004-2014	●
Stripped Chassis	2002-2005	●
Town Car	2007-2009	●
Tracer	2000-2009	●
Transit Connect	2006-2012	●

**BLD Function List**

ABS Service Bleeding
ABS/ESP Service Bleeding
Bleed Master Cylinder

## FORD BMS Function List (Note: For reference only)

**NOTES:**

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	BMS
C-MAX	2013-2018	●
Edge	2011-2019	●
Escape	2013-2019	●
Expedition	2005-2019	●
Explorer	2011-2019	●
F-Series	2011-2019	●
Flex	2013-2019	●
Focus	2012-2016	●
Focus	2017-2018	●
Focus C-MAX	2015-2019	●
Ford GT	2017-2018	●
Galaxy	2015-2019	●
Kuga	2013-2019	●
Mondeo	2013-2019	●
Mustang	2011-2019	●
S-Max	2015-2019	●
Taurus	2013-2019	●
Troller	2011-2015	●
Continental	2000-2017	●
Escort	2005-2015	●
Everest	1999-2016	●
F-150	2003-2019	●
Fiesta	2005-2015	●
Fusion	2002-2017	●
MKC	2005-2019	●
MKS	2005-2018	●
MKT	2007-2019	●
MKX	2003-2016	●
MKZ	2006-2017	●
Mariner	2009-2019	●
Milan	2005-2015	●
Navigator	2001-2014	●
Ranger	1998-2012	●
Transit	2007-2019	●
Transit Connect	1997-2012	●
Tribute	2005-2015	●
Zephyr	2000-2010	●

### BMS Function List

R-mode Rebalance

BMS (Battery Monitoring System) Resetting

FORD DPF Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	DPF
Focus C-MAX	2002-2014	●
Galaxy	2006-2015	●
Kuga	2008-2013	●
S-Max	2006-2015	●
Tourneo Connect	2007-2009	●
Transit	2006-2009	●
Transit Courier	ALL	●
Troller	2011-2015	●
B-Max	2002-2011	●
EcoSport	2000-2014	●
Edge	1998-2015	●
Escape	2004-2010	●
Everest	2007-2017	●
F-150	2006-2013	●
F-650	2001-2014	●
F-750	ALL	●
F-Series	2008-2018	●
Fiesta	2006-2011	●
Focus	2002-2013	●
Focus Cabriolet	2005-2017	●
Mondeo	ALL	●
Ranger	2010-2019	●
Transit Connect	2003-2013	●

**DPF Function List**

Reset the Diesel Particulate Filter differential Pressure Sensor Learned Values

DPF Assessment

DPF Regeneration

Reset The Diesel Particulate Filter Learned Values

Diesel Particulate Filter Static Regeneration

DPF Parameter Reset

DPF Regeneration Suspension

DPF Manual Regeneration

DPF Reset

**FORD EPB Function List (Note: For reference only)**

**NOTES:**

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	EPB
B-Max	ALL	●
Fiesta	2008-2018	●
Focus C-MAX	2002-2007	●
Galaxy	2006-2015	●
Mondeo	2013-2018	●
S-Max	2006-2015	●
C-MAX	2002-2018	●
Continental	2004-2019	●
Edge	2000-2013	●
Escape	2001-2016	●
F-150	2007-2015	●
Fusion	2006-2010	●
GALAXY	2005-2014	●
Kuga	2002-2018	●
MKC	2003-2019	●
MKZ	2008-2017	●
Taurus	2006-2012	●
Focus	2004-2011	●

**EPB Function List**

EPB - Calibrate the longitudinal acceleration

Parameter Reset/Configuration - EPB

Rear Brake Adjustment

PBM - Assembly Check

PBM - Maintenance Mode

PBM - Module Configuration

PBM - Inclination Sensor Calibration

PBM - Clear The Stored Clutch Engagement Point

PBM - Static Apply

EPB - Calibrate The Emergency Release

EPB - Calibrate The EPB Function Test

EPB - Calibrate a new EPB module

Electronic Integrated Park Brake - Apply And Release Test

Electronic Integrated Park Brake - Maintenance Mode

Manual Reset brakes

FORD ETC Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	ETC
B-Max	ALL	●
C-MAX	2013-2018	●
Crown Victoria	2002-2011	●
E-Series	2004-2016	●
EcoSport	2003-2012	●
Edge	2007-2019	●
Escape	2001-2019	●
Expedition	2005-2019	●
Expedition EL	2007-2014	●
Explorer	2001-2019	●
Explorer SportTrac	2007-2010	●
F-Series	2003-2019	●
Fairlane/LTD	2006-	●
Fairmont	2006-	●
Falcon	2003-2014	●
Fiesta	1996-2007	●
FIGO	2010-2017	●
Five Hundred	2005-2007	●
Flex	2009-2019	●
Focus	2003-2011	●
Focus Cabriolet	2006-2008	●
Focus C-MAX	2011-2014	●
Ford GT	2017-2018	●
Freestar	2004-2007	●
Freestyle	2005-2007	●
Fusion	2006-2019	●
Galaxy	2006-2015	●
KA	2008-2017	●
Kuga	2008-2019	●
Maverick	2005-2007	●
Mondeo	2017-2019	●
Motorhome	2006-2019	●
Mustang	2005-2019	●
V6 SOHC	2003-2011	●
S-Max	2006-2015	●
Scorpio	1995-1996	●
Step Van	2006-2019	●
Stripped Chassis	2006-2019	●
Taurus	2003-2019	●
Taurus X	2008-2009	●
Territory	2004-2013	●
Thunderbird	2002-2005	●
Transit	2010-2013	●
Transit Courier	ALL	●
Troller	2011-2015	●
Bantam	2003-2019	●

Blue Bird C-Class Vision	2003-2019	●
Continental	2003-2018	●
Courier	2003-2019	●
Escape	2006-2019	●
Escort	2004-2016	●
Everest	2003-2019	●
Excursion	2005-2019	●
F-150	2003-2017	●
F-650	2003-2019	●
F-750	2007-2015	●
Fiesta	2003-2019	●
Five Hundred	2003-2019	●
Freestar	2005-2019	●
Granada	2003-2015	●
Grand Marquis	2005-2017	●
Ikon	2003-2019	●
Ka	2003-2019	●
Kuga	2007-2019	●
LS	2003-2016	●
MKC	2003-2011	●
MKS	2009-2019	●
MKT	2003-2019	●
MKX	2003-2015	●
MKX/Nautilus	2003-2012	●
MKZ	2001-2019	●
Mariner	2002-2019	●
Mark LT	2003-2014	●
Milan	2006-2019	●
Montego	2003-2012	●
Mountaineer	2000-2019	●
NOVO KA	2003-2019	●
Navigator	2003-2018	●
Navigator L	2003-2019	●
Ranger	2003-2014	●
S-Max	2000-2019	●
Sable	2003-2019	●
Scorpio	2003-2010	●
Street Ka	2001-2019	●
Town Car	2003-2019	●
Transit Connect	2003-2018	●
i-MAX	2003-2019	●

### ETC Function List

Reset the intake Air Throttle Valve Learned Values

Reset the Throttle Body Learned Values

Reset KAM(Keep Alive Memory)

Reset KAM(Keep Alive Memory) - PCM

ETB / EGR Initialization

ETB Check

Electronic Throttle Control

Reset KAM(Keep Alive Memory) - TCM

Reset KAM(Keep Alive Memory) - SOBDM-C

## FORD INJ Function List (Note: For reference only)

### NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	INJ
Focus C-MAX	2002-2014	●
Galaxy	2006-2015	●
Kuga	2008-2013	●
S-Max	2006-2015	●
Tourneo Connect	2002-2009	●
Transit	2000-2009	●
Transit Courier	ALL	●
Troller	2011-2015	●
B-Max	2000-2014	●
C-MAX	2002-2017	●
EcoSport	2008-2019	●
Edge	2004-2016	●
Escape	2001-2011	●
Everest	2003-2018	●
F-650	2005-2012	●
F-750	2007-2010	●
F-Series	2004-2016	●
Fiesta	2003-2015	●
Focus	2002-2017	●
Focus Cabriolet	2002-2018	●
Fusion	2000-2014	●
Mondeo	ALL	●
Ranger	2004-2016	●
Territory	2007-2013	●
Transit Connect	2002-2014	●

## INJ Function List

Fuel Injector Correction Factors

Reset the Fuel Injector Learned Values

Reset the Knock Sensor Learned Values

Reset the Fuel Injector Learned Values-cylinder

Fuel Injection Pump Learn

Fuel Injector Pilot Correction Learn

Enter The Fuel Injector Default Count Value

IQA - Injector Quantity Adjustment

Injector programming Code

FORD OIL Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	OIL
EcoSport	2007-2012	●
Endeavour	ALL	●
Everest	ALL	●
KA	2008-2011	●
Aviator	2003-2005	●
C-MAX Hybrid	2013-2015	●
Crown Victoria	2006-2011	●
Edge	ALL	●
Escape	2005-2016	●
E-Series	2006-2016	●
E-Series Shuttle Bus	ALL	●
Everest	ALL	●
Expedition	2007-2015	●
Explorer	1996-2016	●
Explorer Sport	2000-2003	●
Explorer SportTrac	ALL	●
F-150	ALL	●
F-250	ALL	●
F-650	2006-2007	●
Fiesta	2013-2016	●
Five Hundred	2005-2007	●
Flex	2009-2012	●
Focus	2015-2016	●
Freestar	2004-2007	●
Freestyle	2005-2007	●
Fusion	2014-2016	●
Mondeo	ALL	●
Mustang	2015-2016	●
Taurus	ALL	●
Taurus X	2008-2009	●
Tourneo Connect	2002-2009	●
Transit	ALL	●
Transit Connect	ALL	●
Windstar	1995-2003	●

OIL Function List

Reset the oil change indicator

Reset Maintenance Lamp

Data Reset

Maintenance Version Status

FORD SAS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	SAS
B-Max	ALL	●
C-MAX	2013-2018	●
E-Series	2004-2016	●
EcoSport	2007-2012	●
Edge	2007-2019	●
Escape	2001-2019	●
Expedition	2003-2019	●
Expedition EL	2007-2014	●
Explorer	2001-2019	●
Explorer SportTrac	2007-2010	●
F-Series	2003-2019	●
Falcon	2006-2014	●
Fiesta	2001-2018	●
Flex	2009-2012	●
Focus	1999-2018	●
Focus C-MAX	2011-2014	●
Freestar	2004-2007	●
Fusion	2006-2019	●
Galaxy	2006-2015	●
Kuga	2013-2019	●
Mondeo	2013-2019	●
Motorhome	2006-2019	●
Mustang	2005-2019	●
V6 SOHC	2003-2011	●
S-Max	2006-2015	●
Step Van	2006-2019	●
Stripped Chassis	2006-2019	●
Territory	2004-2014	●
Thunderbird	2002-2005	●
Transit	2006-2013	●
Transit Courier	ALL	●
Troller	2015-	●
Windstar	1995-2003	●
Aviator	2001-2019	●
Continental	2004-2016	●
Courier	2000-2013	●
Escort	2007-2017	●
Everest	2005-2014	●
F-150	2009-2018	●
Figo	2002-2019	●
Galaxy	2008-2012	●
KA	2003-2010	●
LS	2006-2015	●
MKC	2001-2014	●
MKT	2000-2018	●
MKX	2002-2019	●

MKZ	2009-2011	●
Mariner	2002-2016	●
Milan	2005-2017	●
Monterey	2005-2012	●
Mountaineer	2009-2018	●
Navigator	2004-2016	●
Ranger	2007-2014	●
Taurus	2003-2016	●
Transit Connect	2002-2017	●
Tribute	2001-2015	●
Zephyr	2001-2012	●

### SAS Function List

ESP - Configure Steering Angle Sensor
IVD (Interactive Vehicle Dynamic Feature) Initialization Sequence
Braking - Steering Angle Sensor Calibration
Steering Wheel Position Sensor Calibration
EPS - Calibrate Steering Angle Sensor
EPS - Steering Column Assembly Configuration
EPS - Intermediate Shaft Configuration
EPS - Pull Drift Compensation
EPS - Pull Drift Compensation Enable / Disable
EPS - Straight Ahead Adaption Angle Reset
EPS - Steering Rack Limiter Configuration
Steering Torque Sensor Trim
AFS - Steering Wheel Angle Trim
AFS - Reset SASM Module
AFS - Steering Motor Angle Trim
AFS - Steering Toe Adjustment

**FORD TPM Function List (Note: For reference only)**

**NOTES:**

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	TPM
C-MAX	2013-2018	●
EcoSport	2007-2012	●
Escape	2013-2019	●
Focus	2012-2018	●
Focus Cabriolet	2006-2008	●
Focus C-MAX	2007-2010	●
Ford GT	2017-2018	●
Galaxy	2006-2015	●
Mondeo	2017-2019	●
Mustang	2011-2019	●
S-Max	2006-2015	●
Troller	2015-	●
Continental	2006-2019	●
Edge	2000-2016	●
Escort	2008-2012	●
Everest	2001-2015	●
Explorer	2006-2016	●
F-150	2003-2014	●
F-Series	2007-2010	●
Fusion	2002-2013	●
Galaxy	2005-2014	●
Kuga	2009-2018	●
LASER	2010-2017	●
MKC	2012-2015	●
MKX	2004-2012	●
MKZ	2009-2013	●
Mariner Hybrid	2003-2014	●
Ranger	2005-2012	●
Taurus	2000-2019	●
Transit	2007-2012	●
Transit Connect	2006-2014	●

**TPM Function List**

Reset TPMS

Reset TPMS After ABS Module Replacement

TPMS Function - Workshop Test

TPMS Functions

TPMS Functions - Sensor Learning Routine

TPMS Sensor Training Mode

TPMS Reset